





USER'S MANUAL

kids Adjustable Desk and Chair Set HW67394



Before You Start


-  Please read all instructions carefully.
-  Retain instructions for future reference.
-  Separate and count all parts and hardware.
-  Read through each step carefully and follow the proper order.
-  We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
-  Always place the product on a flat, steady and stable surface.
-  Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.



B1



B2x2




B3


B4




B5



B6



B7




B8



B9



B10x2



B11



B12



Φ6.5xΦ10.3mm

A1x8



M6x20mm

A2x12



Φ6.5xΦ15.3mm

A3x8



M5x25mm

A4x4



M6x40mm

A5x4



M6x15mm

A6x2



A7x1



M4


A8x1

CAUTION!


1. For indoor use only.
2. This product should be placed on a flat surface.
3. Please immediately wipe clean the desktop surface if any liquid is splashed on it.
4. Please check screws regularly to ensure there are no loose parts during daily use.
5. Do not tighten all the screws until the desk and chair have been assembled properly.
6. Use a damp cloth to clean the desktop surface.

CHAIR ASSEMBLY INSTRUCTIONS


1




2




3




4




5




6



7




8




DESK ASSEMBLY INSTRUCTIONS


9




10




11




12




13



14



HEIGHT ADJUSTMENT



How to lift up

Desk and chair can be adjusted higher by directly pulling up. Step on the support bar with one foot and pull up desk/chair to the height needed.

How to lower down

Pull up to the max height and slowly lower down to the min height. Pull up again to the height needed.

Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



US:cs.us@costway.com

UK:cs.uk@costway.com

AU:cs.au@costway.com