

4 in 1 Laser Cat Toy

Smart Sense

- Cat teaser
- Cat laser
- Track balls
- Natural feather

Instruction manual

SPECIFICATIONS

Product name 4 in 1 Laser Cat Toy

Material ABS

Size 190mm X 130mm

Weight 540g

USB 5V 1A

Charging time 2-3 hours


Running time 6-20 hours
after fully charged

RUNNING MODE

1. The toy will automatically run for five minutes once turns on.
2. The toy will stand by for four hours if the cat stops to play with it after 5 minutes. It will restart if the cat touches it within four hours.
3. The toy will turn off if cat doesn't play with it in four hours. You need to push the switch to turn it on.
4. We suggest to pack the toy up every time after playing to maintain the cat's interest.

WARNING: Protect your eyes from the direct laser!!!

FUNCTION SELECTION



Function switch


1. Turn on the toy by long pushing the function switch. When the toy makes beep sound twice and the indicator light turns green, the feather will work.
2. Push the function switch once, when the indicator light turns blue, the laser will work.
3. Push the function switch second time, the indicator light turns yellow, the laser & feather will work simultaneously.
4. Push the function switch third time, when the indicator light turns pink, the feather & laser will work alternately. The feather will work 50 seconds, then the laser will work 50 seconds. This circle will repeat 4 times. There are total 400 seconds in this mode. (After 400 seconds, enter standby mode, touch to restart.)
5. Turn off the toy by long pushing the function switch and it will make beep sound once.

Speed switch


1. The speed switch only works in laser mode. It is low speed mode when blue light, it is fast speed mode when red light and it is random speed mode when pink light. (Automatically restore to the initial mode state upon each startup.)
2. Pushing the speed switch in feather mode, go into feather replacing mode, while the feather will come out from the hole for replacing the feather. Push the function switch to resume the feather mode.

1. TO ADJUST THE LASER DISTANCE

1. Push the adjusting bar up for longer distance.




2. Push the adjusting bar down for shorter distance.




2. TO INSTALL/UNINSTALL THE FEATHER

1. Push down the feather.




2. Press the buckles and pull up the feather.




3. REPLACE FEATHER

1. Pushing the speed switch in feather mode, then unscrew the feather anticlockwise.




2. Screw the new feather clockwise.




4. CHARGING

1. Insert the USB cable to charging port.



2. Connect to adapter.



TIPS

1. It's charging when the indicator light is red.
- All functions are not applicable during charging.
- It's full charged when the indicator light is blue.