

Action Camera Accessories
Quick Start Guide

GA300

Package List



A1
Short
Thumbscrew



A2
Long
Thumbscrew



B1
Extension
Arm



B2
Short Vertical
Extension Arm



B3
Long Vertical
Extension Arm



C1
J-hook
Buckle



C2
Water-proof
Case Mount



D1
180° Rotating
Mount



D2+D3
360° Rotating
Mount

1



E1
Bicycle Handlebar
Mount



F1
Helmet Mount
with Screw



F2
Helmet
Mount



G
Hand/Helmet
Strap



H
Anti-lost
Insurance Strap



I
Reinforced
Strap


2




Made in China Version 1.1

Installation Guideline


A2+C2



A2+C2+F1




A2+C2+F1+G




3

A1+E1



A1+B2+E1




A2+D1




4


A2+D1+D2+D3



A2+C1



A2+C2+H



5

Warm tip: This Quick Start Guide is mainly designed for WOLFANG
Action Camera GA300
Support Team: support@wolfang.co