


CAPOXO



H06

User Manual

Customer Service

- ✉ Email: aftersale@capoxo.store
- ☎ WhatsApp: (+86) 139 2349 0475
- 🌐 Web: www.capoxo.store 🔍

Packing List

- ▶ Charging Case *1
- ▶ Type-C Cable *1
- ▶ Wireless Earbuds *2
- ▶ User Manual *1

Specifications

- ▶ Model Name: H06
- ▶ Bluetooth Version: V5.3
- ▶ Earbud Battery Capacity: 35mAh
- ▶ Case Battery Capacity: 500mAh
- ▶ Charging Time: about 2H
- ▶ Case Size/Weight: 53.5*50 28.5mm/45.5g
- ▶ Earbud Size/Weight: 33.1*17.5*17.7mm/3.6g
- ▶ Transmission Rang: 39 feet(without obstacle)

Overview



LED Indicator

Touch Control Area

Built-in Mic

LED Bar for Earbuds

Charging Case
LED Power Display



Type-C Charging Port

Note:

- 1-Please REMOVE protective film on the earbuds' charging point before using.
- 2-The WIRELESS CHARGING AREA is on the back of the charging case.

Power On/Off

Auto Power On

The earbuds will turn on automatically when you open the charging case.

Auto Power Off

Put the earbuds back into the charging case and close the case, the earbuds will turn off automatically and enter charging mode.

Manually Power On

If the earbuds are not in the case and power off, press & hold them about 2 seconds, they will turn on.

(At this time, light on earbuds will flash blue for 1 second.)

Manually Power Off

Press & hold the earbuds about 5 seconds, light on earbuds will flash red and then they will power off.

Bluetooth Connection

Prior to first use (or not in use for long time), please fully charge both earbuds and charging case.

First Time Pairing

Step 1 - The twin earbuds will automatically power on and enter pairing mode when you open the charging case.

At this time, led indicator of master earbud will flash Blue & Red light alternately, and the vice earbud led indicator flashes Blue light 2 times every 2 seconds.

Step 2 - Activate the Bluetooth setting on your phone, search and connect "H06".

Once connected, the led light of both earbuds goes off.



Note: If the earbuds are not connected to your device over 5 minutes, the earbuds will power off automatically.

For Second Time Use

If the earbuds have already connected with your device, and the Bluetooth setting of this device is on, in the second time using, when you take out the earbuds from the charging case, they will connect with your device automatically.

Pair with Other Device

H06 Earbuds have memory function, they usually auto connect with the last paired device.

Thus, if you want to pair them with other device, you should disconnect “H06” from the last paired device, AND forget the pairing record on the last device.

Then try to connect it to a new device, it should work properly.

Mono Mode (Only Left/Right Earbud is being Used)

You can use one earbud alone, leave another earbud in the charging case.

- When in Dual mode, put one earbud into the charging case and close the case.
- Turn on the Bluetooth setting on your phone, then search & connect “H06” on your device.

▶ Factory Restore Settings ◀

When should I reset?

1. Only one earbud plays music.
2. Both earbuds can not work with together.
3. Occur connection issues.

How to reset?

Step 1: Delete the pairing name “H06” on your phone and deactivate the Bluetooth setting of all devices near by the earbuds.

Step 2: Take out the two earbuds from the charging case and keep them powering on.

Step 3: Tap both earbuds 5 times , then put the earbuds back into the charging case and close the lid.

(Both earbuds will flash **Blue** & **Red** light alternately for 3s, then the Red lights keep 1s and go off.)


Step 4: Now, open the charging case to turn them on, activate the Bluetooth setting on your phone, search and select "H06" to connect, they should work properly.

If it doesn't work, please repeat the steps above to try again.

Earbuds Charging

To Charge Earbuds

Insert the Earbuds into charging case properly and close the case, they will power off & get charged.



 Flash for 10 secs after charging starts and then turns off.

Low Battery Alarm


When the battery is less than 10% (and the voltage is lower than 3.4V), a prompt voice “Please charge” will be advised, announce once every 5 minutes and 5 times in total, earbud led indicator flashes red light one time every 5 seconds. And then the earbuds will power off as normal.

Charging Case Charging

Type-C Charging

(There is a Type-C charging cable in the small black paper box inside the packing box.)

Please use the provided Type-C cable with a 5V/1A adapter(not included) to charge the charging case.



- ⑩ When the case is being charged, the digital display will show current power, the end digital number flashes 10 seconds and then goes off. Once fully charged, when you open the charging case to view it, the number will be display as 100 and then go off.

Wireless Charging

Easy to charge your charging case without cables, just put the charging case on a wireless charging pad. Please keep LED power display facing up when charging.

If the charging case doesn't start to charge, please try to reposition it until the LED power display flashes. (Wireless Charging Pad Not Included)



Tips:

If the earbuds don't charge or even can't turn on, that may be because there is an oxidized layer or something else on the charging pin.

You can solve this problem by cleaning the magnet connector on the earbuds with alcohol wipes.

Multi-Function Operations



For Call

Answer Call: Tap Once

End Call: Quick Double-Tap

Reject Call: Long Press 2S



"L" or "R" Earbud
Both OK



Voice Assistance

Activate Siri or other voice assistances:

Quick triple-click on L or R



"L" or "R" Earbud
Both OK

Note: Must in non-music or standby mode. There will be a prompt sound “di” when activating the voice assistant.



For Music

[Functions on "R Earbud"]

Play/Pause: Quick Double-Tap

Next Track: Quick Triple-Tap

Volume +: Long Press & Hold



"R" Earbud

(* In mono mode, R earbuds only supports next song and volume +.)

[Functions on "L Earbud"]

Play/Pause: Quick Double-Tap

Previous Track: Quick Triple-Tap

Volume -: Long Press & Hold



"L" Earbud

(* In mono mode, L earbud only supports previous song and volume -)

How to Sync Volume on Android?

To protect users from potential hearing damage, Android's limit on max volume is quite low for Bluetooth audio devices.

If you feel the volume is too low, please access developer options and enable absolute volume, so you'll be able to max the volume at your own volition and to the full capabilities of your Bluetooth earbuds.

(Please scan this QR code to watch a video to learn more details.)



Find Build Number Firstly

Android 4.1 and lower: the Developer options screen is available by default.

Android 4.2 and higher: the Developer options in Android phones are hidden, you must enable this screen through Build Number.

Android 7.1 and lower: Settings > About Phone > Build Number

Android 8.0.0 and Android 8.1.0 : Settings > System > About Phone > Build Number


Android 9 and higher: Settings > About Phone > Build Number

Enable Developer Options

Developer options. You may also have to tap in your PIN for verification. Once developer options are activated, you will see a message that reads "You are now a developer".

Go back to the Settings pane, search Developer options as an entry. At the top of the Developer options screen, you can toggle the options as figure 1.

Developer Options



(figure 1)

Enable Absolute Volume

Scroll down until you reach the Networking section. Once there, enable (toggle ON) the absolute volume option as figure 2.

Enable absolute volume



(figure 2)

Note: These options in the figures may be different from the device you're using. Typically, the choices depend on the type and model of the device you are working with.