




NEHEME

Never define your vision

NH760 Tracker Drone



QUICK START



www.neheme.com




usa@neheme.com (US)


eu@neheme.com (EU)

14+
age


PACKING LIST



NH760 Drone



Batteries x 2



Remote
(batteries not included)



USB Charger x 1



Blades x 4
(A+B)



Screwdriver




User Manual




Quick Start


PRODUCT OVERVIEW



1. Prepare the Drone




While battery is charging, the LED light on USB is on. When fully charged, the LED light goes off. Charging takes approximately 150-180 minutes.




NOTE: a. Insert the battery into the rear of the drone in the right direction (the tab on the battery should be facing up) b. Slide the battery all the way in, until it securely slots into place. c. Press 'LOCK' to lock the battery with drone; press 'UNLOCK' before taking out the battery.


2. Prepare the remote




3. Pair the Remote with the Drone



1. Turn on the drone first




2. Turn on the remote second.




3. LED solid on

4. Flight Calibration




The light on drone flashing,
and then solid on.


5. Take-off




OR




OR



6. Flight Directions



7. Landing



Application Control



IOS / Google Play

APP name: Neheme Tracker

WiFi name: NEHEME_NH760_***

Never define your vision

