

Q&A

Q: Lid opens slower than usual.

A: It happens when the battery is low, please try replacing batteries.

Q: Having trouble turn on the product.

A: Firstly, Check the batteries are still good to use and installed correctly. Press and hold the left button for 3 seconds.

Q: How to clean the lid?

A: This product is waterproof, just simply rinse the lid with water.

NEED HELP?


CONTACT US VIA EMAIL ON THE RIGHT >> elpheco@erhuitech.com

ELPHECO®

**WATERPROOF
SENSOR TRASH CAN**



1. Install 2pcs AA Batteries



2. Fixed Trash Bag Ring



3. Place Odor Filter

Each carbon filter lasts for about 2 months.



4. Turn On The Product

Press the left button gently and hold it for 3 seconds to turn on the product. Press again to turn off.



5. Smart Sensor

The lid stays open if you keep your hands above the infrared motion sensor. Lid closes after 5 seconds automatically if none movement is detected by sensor.



6. Manual Control Feature

Press the right button to open/close the lid manually, the lid will stay open until you press the button again. (Smart sensor will be disabled after lid opened manually)

