

Zeta Pro Instant Cabin Tent with Half Fly, Big

The product in instruction sheet may look different from yours.

It is for illustration purpose only.

Before you begin

- Read all instructions before set up.
- Select a level site clear of rocks, branches, and other hard or sharp objects, to install your tent.



WARNING: Keep clear of overhead power lines.

- Do not set up your tent under trees because of potential lightning strikes or falling tree limbs in inclement weather.
- NOTICE: Secure product with all ground stakes, guylines and fly attachments for optimal performance and to prevent property damage or personal injury.
- For best results in windy conditions, position narrow end of tent into the wind.
- Two people recommended for setup.

Things You Should Know

- Condensation is normal and IS NOT LEAKAGE. It can be minimized by providing good ventilation.
- Tree limbs, tree sap, bird droppings, or moisture steadily dripping off tree limbs can cause damage to the tent fabric and its coating.
- Do not store tents without drying it off thoroughly and brushing off caked dirt.
- Stakes should be removed by pulling on the stake itself.
- According to international standards, the tent defines 7' X 2' as the area for one person to sleep, please arrange the number of people reasonably

NEVER PULL ON THE TENT TO REMOVE STAKES AS THIS COULD RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.




- Prolonged exposure to the sun can seriously damage material and/or cause it to become discolored.



WARNING: Keep all flame and heat sources away from this tent fabric.


This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

Part List

A	Inner tent with integrated frame		X 1
B	Carry Bag		X 1
C	Rainfly		X 1
D	Room Divider		X 1
E	Gear Loft		X 1
F	welcome mat		X 1
G	Peg Bag		X 1
H	Stake		X 14


How to set up

1. LAYOUT & POSITIONING OF TENT



2. First Extend **telescoping roof poles** until they snap into place.
Then Extend telescoping leg poles until they snap into place.


Caution! Make sure to extend all roof poles before extend leg poles. Otherwise it may damage the pole frame.



Not setup alone




Not setup same side




NOTE:Gently pull out the tent pole

3. VERIFY CONNECTIONS BETWEEN TENT AND FRAME POLES




4. STAKE DOWN THE INNER TENT



5. ATTACH RAINFLY



6. GUY OUT THE TENT AND ASSEMBLE WELCOME MAT



Note: Do not camp on ground that is too soft, as this may prevent the stakes from holding securely. When driving the stakes into the ground, angle them outward at a 45° angle.

How to disassemble


1. REMOVE PEGS AND GUYROPES





2. DETACH RAINFLY




3. RELEASE BUTTON OF POLES




4. TO TAKE DOWN THE TENT'S POLES FOLLOW THE PREVIOUS STEPS AND INSTRUCTIONS IN THE REVERS ORDER



5. FOLD THE FRAMES



6. PACK INNER TENT AND ALL ACCESSORIES TO CARRYBAG.



1 Year Limited Warranty

FanttikOutdoor warrants for a period of 1 year from the date of purchase, this product against any defects in materials or workmanship. At its discretion, FanttikOutdoor may provide replacement parts to the original purchaser. Original receipt or proof of purchase as well as proof of defect is required. FanttikOutdoor will not be responsible for shipping costs incurred outside the continental USA.

Warranty is valid for the original purchaser 1 year from the date of purchase and is not transferable. This Warranty does not cover any product purchased through unauthorized dealers and/or online auction websites.

To Obtain Warranty Service

Please send mail to support@fanttik.com to get warranty service or any support.

929-693-6066 MON-FRI 9AM-5PM(ET)

www.fanttik.com

support@fanttik.com

Distributor/Händler: METASEE LLC

Distributor/Händler: 12 GREENWAY PLZ STE 1161A HOUSTON, TX 77046-1203

FanttikOutdoor[®]