





## IOOI00 peripage printer video, FAQ, trouble shooting, quick start, user manual v231028




Customer service email: [iooioo@qq.com](mailto:iooioo@qq.com), whatsapp: 008614775058163

Quick Start Video (Video also available at amazon product page):	
1	How to connect with phone? <a href="https://www.amazon.com/live/video/0bd3567f363c4cfc82fa06da3d128ffb?ref=asvh_vdp">https://www.amazon.com/live/video/0bd3567f363c4cfc82fa06da3d128ffb?ref=asvh_vdp</a>
2	How to connect Windows PC with USB cable? <a href="https://www.amazon.com/vdp/0b509862895d44f8ab7e1cd410b2a3c0?ref=dp_vse_ibvc1">https://www.amazon.com/vdp/0b509862895d44f8ab7e1cd410b2a3c0?ref=dp_vse_ibvc1</a>
3	How to connect Mac PC with USB cable? <a href="https://www.amazon.com/vdp/089783806d894420badeb74c9b567633?ref=dp_vse_ibvc0">https://www.amazon.com/vdp/089783806d894420badeb74c9b567633?ref=dp_vse_ibvc0</a>
4	How to install letter rolled paper? <a href="https://www.amazon.com/vdp/04731c0d4f2b4882bab22785b98962ab?ref=dp_vse_ibvc2">https://www.amazon.com/vdp/04731c0d4f2b4882bab22785b98962ab?ref=dp_vse_ibvc2</a>
5	How to install letter folded paper? <a href="https://www.amazon.com/vdp/012555e47c414c748397433923692a98?ref=dp_vse_ibvc3">https://www.amazon.com/vdp/012555e47c414c748397433923692a98?ref=dp_vse_ibvc3</a>
6	How to make the rolled curled paper flat? <a href="https://www.amazon.com/vdp/03414bd189f943a5b154650f643e5baa?ref=dp_vse_ibvc4">https://www.amazon.com/vdp/03414bd189f943a5b154650f643e5baa?ref=dp_vse_ibvc4</a>

### FAQ and trouble shooting:

Problem	Root Cause	Solution
Why some android phone could not import word or PDF file into APP to print?	Need to close the APP Peripage page first, then open the file with Peripage.	Import document into APP to print: ( For some Android phone, close the App Peripage first (Remove the Peripage from the phone App manager on the background by swiping from the bottom of the phone home screen, and select Peripage to swipe it out), ) . Open the document with "Peripage". Open your document from another app, such as Whatsapp/Gmail, click the document in Whatsapp/Gmail to open it, then click the bottom-left icon, then click "... " and select Peripage to import the file into Peripage. Then in the Peripage app, click the file, then click the print logo to print. ( tips: make sure phone Internet is active to use the APP, otherwise many functions is not available )
Bluetooth could not connect with phone or Windows PC (Every unit was double tested by seller before	Connect it in the wrong way.	Follow the video on our product page to connect it by Bluetooth or USB.
	The phone is in lower battery or power saving mode.	Charge the phone.
	Internet of the phone is not available.	Please activate your Internet access to use printer.
	Try to connect the printer in the phone Bluetooth setting, which is a wrong way to	Do not try to connect it at the phone Bluetooth list, please connect it within the Peripage APP, after activating the Bluetooth of the phone.

shipment)	connect the printer with Bluetooth.	Please refer to the step-by-step guideline in this document chapter 3.1 on how to connect the Android, iPhone with Bluetooth.
	The phone is not compatible, such as the phone is too old.	Change a newer phone to test and confirm if the phone causing the problem. And make sure the phone version and PC version meets the minimum requirement. Only Bluetooth for Android 8 or later; iPhone 12 or later. PC with USB cable for Win PC 10 or later, Mac PC 11 or later with M1 or later chip are supported.
	The printer is connecting with the 1 <sup>st</sup> phone. The 2 <sup>nd</sup> phone could not connect.	1. Disconnect with the 1 <sup>st</sup> phone, and connect the 2 <sup>nd</sup> phone again. Charge the phone.
How to make the curled paper flat?	The paper was printed from the rolled paper	<p>1. Slide at the edge of the desk to make it flat, the sharper the edge, the better it will be:</p>  <p>2. Buy the folded paper, but not rolled paper.</p>
The rolled letter size paper could not be installed. 	The two holders are not removed	<p>Remove the two holders which stop the rolled letter paper.</p> 
Why print nothing? 	The paper is upside down. Only one side is printable.	Please print with another side.
Why the printing is not clear?	Density/Concentration/Darkness is not set to max 5, but 2.	Set density/Concentration/ Darkness to 5
	The text font size or lines is too small	Enlarge the font size or line

	The picture is too small	Enlarge the picture in the paper
	The thermal paper quality is not good	Use the good quality general thermal paper or use the IOOIOO thermal paper which is available at our store
	The DPI (Dots Per Inch) is just 203DPI, but not 300DPI	Buy our high DPI resolution version of print A40 Plus with 300DPI
Why print at the broken line of the folded paper when printing about 10 pages continuously ?	The folded paper without the black mark for printer to recognize it is not well compatible with the printer.	<p>1. If you are using other not compatible paper, please set the parameter to be 11(Or the actual shifting of each page) as the following:</p>  <p>2. Or buy the peripage compatible folded paper at our store or at amazon.</p>
Why some tattoo transfer paper was stuck or the tattoo paper are melted?	The tattoo paper was too bright to mislead the sensor to stop the printing.	Block the sensor with label: 
	The newer version V1.4.3_SD upgrade the printing quality, it does not support tattoo printing any more.	Double click the power button to print the version. 
	The transfer paper was melted, because the printer head temperature is too high to the transfer paper.	<p>1. Adjust the darkness of the printing from 5 to 0.</p> <p>2. Print the transfer paper upside down.</p>
What's the meaning of the LED status	Green light on:	Normal use status/fully charged
	Red light on:	Cover open/No paper/Over-heat/Charging
	Green light flashing:	Folded paper mode, please insert paper
	Red light flashing:	Low battery, please charge
How to handle the charging	5V-2A, recommend to use phone charger to charge it	
	Recommend to fully charge it before using	
	Please charge it every 3 months if you did not use it for long time to avoid the battery not being able to be charged.	
How to clean	Step1: Turn off printer, and open the cover, and take out the paper	

printer head	Step2: Dip a cotton cloth or cotton swab with medical alcohol, and wipe gently along the center to the periphery of the printer head
	Step3: After cleaning the printer head, do not use it immediately. Please wait for 1 to 2 minutes, use the printer after the alcohol has completely evaporated.
What version of phone and PC are support?	Windows 7 8 10 11 MAC PC 10-13.6 ANDROID phone OS 8-13 Iphone 12-16

#### Step-by-step Quick Start Guide:


1.How to install newest Windows PC driver? .....	4
2.How to install newest Mac PC driver?.....	13
3.How to install APP in iPhone and android? How to print email in iPhone and android?.....	27
3.1 How to install APP and connect the printer in iPhone and android phone by Bluetooth? .....	27
3.2 How to print email in iPhone?.....	28
3.3 How to print gmail in android phone? .....	28
4.How to print 4"x 6" shipping label in Windows? .....	28
5. How to print 4"x6" shipping label in Mac PC? .....	33

#### 1.How to install newest Windows PC driver?

Step1: Double click the power key to print the hardware version (When the paper is installed and the power key is green), according to the hardware version to click the following link to download the newest driver:



For hardware older than V1.4.3_SD:	For hardware equal or newer than V1.4.3_SD:
------------------------------------	---

	
<a href="https://www.ileadtek.com/resource/drive/cn/%E7%88%B1%E7%AB%8B%E7%86%8APeriPage_A4_203dpi_PC%E9%A9%B1%E5%8A%A8%E5%AE%89%E8%A3%85%E5%8C%85.zip">https://www.ileadtek.com/resource/drive/cn/%E7%88%B1%E7%AB%8B%E7%86%8APeriPage_A4_203dpi_PC%E9%A9%B1%E5%8A%A8%E5%AE%89%E8%A3%85%E5%8C%85.zip</a>	<a href="https://www.ileadtek.com/resource/drive/en/PeriPage_A40_PC_driver_installation_Windows_3.0.1.435.zip">https://www.ileadtek.com/resource/drive/en/PeriPage_A40_PC_driver_installation_Windows_3.0.1.435.zip</a>



Size: 72 MB total of 3 files and 1 folder Compression rate 77.9% Already selected 83 MB (1 file)

Step2: Click the global icon to change the language into English. And then click Next.






Step3: Long press the power button of the printer for 2 seconds, until the green light is on. Then plug in the USB cable.




The following page will show up, then click next continuously.

When the printer is on, double click the printer power button to print out the hardware version, and find out the driver is one of Peripage A40, PPG A40 SD (For 200 DPI version), Peripage A40, PPG A40 HD(For 300 DPI), Peripage A40 or Peripage A40+(For 300 DPI version):



Then select the right driver for your printer.





Printer Driver Wizard 3.0.1.435

### Select Printer Driver

Q

	model
<input checked="" type="checkbox"/>	PeriPage A40
<input type="checkbox"/>	PeriPage A40+
<input type="checkbox"/>	SQAI_PP_G40
<input type="checkbox"/>	PeriPage A2 SD
<input type="checkbox"/>	PeriPage H2
<input type="checkbox"/>	PeriPage H2+
<input type="checkbox"/>	PeriPage A3X
<input type="checkbox"/>	PeriPage A6

Previous Next Cancel

Step5: Deselect the item "Use this printer as default", then click next.

Printer Driver Wiza 3.0.1.418


### Specify the printer name

Enter printer name

Printer name: PeriPage A40


☒ Use this printer as default

Previous Next Cancel




Step4: If the printer does not show up on the searching printer page, please make sure that: before plugging in the USB cable, the green light of the printer is still on. And make sure the "print spooler" service is running on your PC.


If you need to activate the "print spooler" service for your PC. Please select Windows logo key + R to open Run. Then type "services.msc", and select OK.



Then Right-click "Print Spooler". Then select Start.



Step5: Open the file to be printed, such as a TXT file. And select “PeripageA40” and then click “More settings”.



Step6: Then select actual paper size, such as “A4[204\*291]”. And then select the “Density” to be 5.

Printing Preferences

Stock Grapha About

Paper

Default A4[204\*291]

Paper Type Stock Form

Density 5


0  
1  
2  
3  
4  
5

Paper feed at the beginning of each 0 mm

Paper feed at the end of each page 0 mm

OK Cancel

Step8: Click OK button to print:




## 2.How to install newest Mac PC driver?


Step1: Double click the power key to print the hardware version (When the paper is installed and the power key is green), according to the hardware version to click the following link to download the newest driver:

For hardware older than V1.4.3_SD:	For hardware equal or newer than V1.4.3_SD:
------------------------------------	---


	
<a href="https://www.ileadtek.com/resource/drive/cn/%E7%88%B1%E7%AB%8B%E7%86%8APeriPage_A4_203dpi_Mac%E6%89%93%E5%8D%B0%E9%A9%B1%E5%8A%A8%E5%AE%89%E8%A3%85%E5%8C%85.zip">https://www.ileadtek.com/resource/drive/cn/%E7%88%B1%E7%AB%8B%E7%86%8APeriPage_A4_203dpi_Mac%E6%89%93%E5%8D%B0%E9%A9%B1%E5%8A%A8%E5%AE%89%E8%A3%85%E5%8C%85.zip</a>	<a href="https://www.ileadtek.com/resource/drive/en/PeriPage_A40_PC_driver_installation_Mac_3.0.1_434.zip">https://www.ileadtek.com/resource/drive/en/PeriPage_A40_PC_driver_installation_Mac_3.0.1_434.zip</a>





Step2: Click and run the .pkg file.






Step3: Go to System Preference->Security&Privacy, then click the following red rectangle sequentially.














Step4: Go to System Preference->Printers&Scanners, then click the following red rectangle sequentially.






Step5: Long press the power button of the printer for 2 seconds, until the green light is on. Then plug in the USB cable.





The following page will show up, then click the red rectangle consequentially.





**Note:**

When the printer is on, double click the printer power button to print out your printer hardware version, and find out the driver is one of PeriPage A40, PPG A40 SD (For 200 DPI version), PeriPage A40, PPG A40 HD(For 300 DPI), PeriPage A40 or PeriPage A40+(For 300 DPI version):












Step5: Open the file to be printed. Such as a Microsoft Word.







3.How to install APP in iPhone and android? How to print email in iPhone and android?


3.1 How to install APP and connect the printer in iPhone and android phone by Bluetooth?

Step1: Search “Peripage” in apple store or google play and install it.

Step2: Long press the power button of the printer for 2 seconds, until the light is green. If the light is not green, it will not connect the phone.

Step3: Turn the phone Bluetooth on.


Step4: Run the Peripage app. And connect the printer as the following picture:



Step5: If the device name did not popup. When the printer light is green, double click the power button to print the QR code. And then click the “Scan Code” in App to scan it to connect. (tips: make sure the Internet is always activated when using the APP, otherwise the document could not be imported to print.)


Step6: Import document into APP to print: (For some Android phone, close the App Peripage first (Remove the Peripage from the phone App manager on the background by swiping from the bottom of the phone home screen, and select Peripage to swipe it out), ). Open the document with "Peripage". Open your document from another app, such as Whatsapp/Gmail, click the document in Whatsapp/Gmail to open it, then click the bottom-left icon, then click “...” and select Peripage to import the file into Peripage. Then in the Peripage app, click the file, then click the print logo to print. (tips: make sure phone Internet is active to use the APP, otherwise many functions is not available)

### 3.2 How to print email in iPhone?



### 3.3 How to print gmail in android phone?

Save the email as PDF and run Peripage to print the PDF file.




### 4.How to print 4"x 6" shipping label in Windows?

Step1: After installing the printer driver, install the 4"x6" shipping label by moving the two stoppers to the 4" locations successfully.



Step2: Go to windows settings.



Step3: Create a 4\*6inch form.

Print Server Properties

Forms Ports Drivers Security Advanced

Forms on: BEN

4x6inch  
4x6inch(100x150mm)  
50\*1000  
50\*297

Delete

Save Form

Form name: 4x6inch(100x150mm)

☒ Create a new form

Define a new form by editing the existing name and measurements. Then click Save Form.

Form description (measurements)

Units: ☐ Metric ☒ English

Paper size: Printer area margins:


Width: 4in Left: 0.00in Top: 0.00in

Height: 6in Right: 0.00in Bottom: 0.00in


Change Form Settings

OK Cancel Apply

Step4: Right click the 4"x6" shipping PDF file and open with edge browser.



Step5:



Step6:





Step7: The print will come out.




5. How to print 4"x6" shipping label in Mac PC?


Step1: After installing the printer driver, install the 4"x6" shipping label by moving the two stoppers to the 4" locations successfully.




Step2: Open the 4"x6" shipping label file with Sarafi.



Step3: Click the print menu.



Step4:



Step5:

Paper Size:  Width  Height

Non-Printable Area:

Top

Left  Right

Bottom

Step6:

4X6 INCH

Paper Size:  Width  Height

Non-Printable Area:

Top

Left  Right

Bottom

Step7:



**FBA** 纸箱编号: 1, 共 5 个纸箱 - 29 磅

目的地: FBA Shenzhen jaybei kej youan gongli  
MOLB  
4812 W 300 N  
GREENFIELD, IN 46030-7099  
美国

发货地: IOOIOO  
Guangdong-shenzhen-518000  
Guangdong-shenzhen-518000  
中国

Single SKU  
A4804d10  
数量: 12  
A4804d10

请不要通过此标签

Printer: PeriPage A4

Presets: Default Settings

Copies: 1

Pages: ☒ All  
☐ From: 1 to: 1

Paper Size: 4X6 INCH 4.00 by 6.00 inches

Orientation: ☒ Portrait ☐ Landscape Scale: 100%

Layout

Pages per Sheet: 1

Layout Direction: ☒ Z ☐ S ☐ N ☐ N

Border: None

Two-Sided: Off

☐ Reverse page orientation  
☐ Flip horizontally

1 of 5

PDF Hide Details

Cancel Print

Step8: The print will come out as the following.

