




2022-03-07

JYX 深圳市佳誉祥音响电子有限公司			
绘 图：		品 名：	JYX-T9说明书
电子/结构确认：		版 本：	A/0
业务确认：		规格材质：	115x165mm 157g铜版
核 准：		物料编号：	440-JYXT90-000

Catalogue		Dear users: Thanks for your purchasing.Please read the directions carefully before using and follow the correct instructions. Matters needing attention: To ensure safety, please read carefully and follow the following safety instructions: 1.The equipment is up to The China Compulsory Certification. 2.The equipment should be used in a dry environment. 3.Do not place a fire source near the equipment. 4.Do not use near water source to avoid corrosion of products and accessories. 5.Do not open or disassemble or repair the battery module by yourself.There will be a risk of explosion if the battery is not replaced properly.Do not put the battery into water, fire or any overheated environment. 6.When taking an airplane, please follow the relevant regulations and regulations of the airline company to turn off this product before the airplane takes off to avoid any hidden danger. 7.The charging cable cannot be squeezed, pulled, bent, knotted, or suspended from heavy objects in order to avoid damage to the insulation layer of it and cause electric shock.
Important Note.....	1	
Key function diagram.....	2	
Key function operation guide.....	3	
Remote control function diagram	4-5	
Bluetooth Connection	6	
Instructions for Microphone Operation.....	7	
Function and parameter.....	8	
List of items.....	8	1
FAQ.....	9	

Key Function Diagram



2

Instructions Of Key Operation

- 1.Master: Main volume control knob;
- 2.Mode: Default to Bluetooth mode after power on. Press to switch between bluetooth,flash card,TF card and AUX mode. When bluetooth has already connected,press and hold to disconnect Bluetooth. When USB or TF card is working, press and hold to switch between single song loop and full loop;
- 3.LED Mode: Switching different display modes of LED lights;
- 4.Play/Pause
- 5.NEXT: When working with USB/TF card, press for next song, long press for fast forward; when playing on Bluetooth,short press for the next song;
- 6.Previous: When working with USB/TF card, press for previous song, long press for fast rewind; when playing on Bluetooth short press for the previous song;
- 7.ECHO-
- 8.ECHO+
- 9.REC: Long press this key to start recording, short press it to stop recording and play the current recording; when U disk or TF card is with recording files, short press it to play the recording files inside the device; (Note: REC function is only available when a USB stick or SD card is inserted and a microphone is connected;Storage device memory needs to be less than 16G);
- 10.MIC VOL+
- 11.MIC VOL-
- 12.5V-1A Output: Can be used to charge mobile phones;
- 13.TF Card Port
- 14.USB Port
- 15.AUX IN Port
- 16.Dynamic MIC Input 1
- 17.Dynamic MIC Input 2
- 18.15V-1.5A Charging Port
- 19.Power

3

Remote control



Instructions For Using Remote Control

1. Silent: Press to Silent ON,press again to Silent OFF.
2. Mode: Press to switch the system between USB,TF card,Radio station,AUX IN and Bluetooth modes.
3. BT: Press to switch to Bluetooth mode in any working state.
4. Play/Pause
5. Next
6. REC: Long press this key to start recording, short press it to stop recording and play the current recording(Note: REC function is only available when a USB stick or SD card is inserted and a microphone is connected;Storage device memory needs to be less than 16G);
7. Digital keys: Press to play the program with the corresponding serial number.
8. Loop: Press for single loop and list loop.
9. Vol+
10. PREV.
11. Vol-
12. REC Play: Press to play the recording audio.

Bluetooth Connection

- 1. Turn on bluetooth on your mobile device.
- 2. Press "Mode" key and switch the speaker to BT mode.
- 3. Select "JYX-T9" from devices. (If JYX-T9 is unavailable, please switch back to Bluetooth mode and try again)


AUX- IN

Transmit audio without Bluetooth by plug 3.5mm audio cable into AUX IN jack, the speaker will play the audio from input device automatically.

USB and TF Input

When insert USB or TF card into speaker, the speaker will play the audio from USB/TF card automatically.

Wireless microphone



Instructions for Microphone Operation

(Notes: The microphone included in the package will be automatically connected to the speaker system when it's turned on without additional operation)

Product Parameters

Model: JYX-T9
Speaker size: 8 inch bass unit*2 + 3 inch treble unit
RMS: 30W
Input voltage: 15V

Package includes

- Speaker system.....1PC
- Wireless microphone.....2PCS
- Charging cable.....1PC
- User manual..... 1PC
- Remote control.....1PC
- 3.55mm audio cable.....1PC

FAQ

Q:The system can not start up?

A:Charging the built-in battery;If the machine ran out of power during its last use, it will trigger the battery protection, so please wait 24 hours before switching it on again.

Q:Microphone cannot be connected to the speaker?

A: Try replacing the battery for the microphone, if it still does not work by then, please contact the seller.

CONTACT US:

If you have any questions about the product, please contact us.
If you have more orders, we can give you're the lowest price.

E-mail: service-us@szjyx.com.cn