

343 x 165

TECHNICAL DATA

Voltage	:	230V, 50Hz, 1φ, A.C.
Power	:	1000 / 2000 Watt (+5%, -10%)
Class	:	I
Insulation Class	:	E
Pollution Degree	:	II
Degree Of Protection	:	IP20

NOTE

- In view of continuous improvement, the design and specifications of the product are subject to change without prior notice.
- Company reserves the rights to provide service at home or service center.
- Parts illustrated in this use and care manual are indicative only, parts provided with the product may differ with illustrations.
- This Element Fan heater is intended for household use only.

Condition of Warranty for Alternative Product Offered in Replacement

There may be instances where ORPAT no longer keeps spare Parts or Products that have been brought before the authorised service center for necessary replacement as the said Product may have been deemed as "Outdate" by ORPAT even though they may be covered under the applicable warranty terms. Under such circumstances, the Company shall provide alternative products that offer similar functionalities and of similar value to the product subjected to the following conditions:

1. When Spare Part(s) are no longer available, all other parts that make the product complete must be submitted for replacement, even though these parts may or may not be in working condition.
2. If the alternative product is of lesser value, however bearing similar functionality, there shall be no refunds.
3. If the alternative product is higher in value, however bearing similar functionality, the customer shall be required to pay for the difference in value.

Certificate of Warranty

Warranty for 1 Year Free Service

Dear Customer,

We thank you for purchasing this ORPAT world-class ELEMENT FAN HEATER which is higher than the price paid by you.

ASSURANCE :

Ajanta LLP assures you that this ORPAT ELEMENT FAN HEATER is manufactured under strict quality control by expert technicians. All plastic parts used are made of virgin, high strength engineering, plastic raw materials moulded in advanced micro processor controlled moulding machines.

WARRANTY CONDITIONS :

1. This ORPAT ELEMENT FAN HEATER is warranted for the period of 1 year from the date of purchase against any manufacturing defects arising during the period of warranty. This warranty is only for India.
2. If this ORPAT ELEMENT FAN HEATER develops any defect during the period of warranty, it will be repaired at free of charge.
3. If this ORPAT ELEMENT FAN HEATER develops any defect during the period of warranty, please bring the same with the warranty card / Sales Receipt to the Dealer from whom the ELEMENT FAN HEATER is purchased or contact customer care number, at your own expenses.
4. The defective product should be brought to the dealer at the consumer's cost.
5. This warranty is valid only if this card is duly signed and stamped by our dealer and is produced along with the original customer's copy of the purchase bill.
6. The motor of this appliance is warranted for 1 year against all manufacturing defect
7. In any event, if the company becomes liable for damages incurred in connection with the agreement, then the liability of the company will be limited to the amount equal to the sale invoice amount paid by you.
8. The Appliance is meant for domestic use only.
9. Parts repaired or replaced under this warranty are warranted only for the remainder of the original warranty period, that is no fresh warranty period shall commence for the said replaced / repaired part.
10. Liability under terms of warranty is limited to the value of the repairs / replacement of the parts found to be defective with in the warranty period. All parts which are replaced shall become the property of the company.
11. Company will not be held responsible for any delay in servicing due to non-availability of any components or due to any reasons beyond the control of the company.
12. This warranty is issued at Morbi and courts at Morbi shall have exclusive jurisdiction over matter by or following from this warranty. In case of any dispute arising out of this the same shall be settled by an Arbitrator, in accordance with the provisions of Arbitration and conciliation Act, 1996.
13. The customer is requested to preserve the original invoice for necessary verification and product the same, as and when required.

WARRANTY DOES NOT COVER :

- ◆ If the product has not been installed, used and maintained in accordance with the instruction manual.
- ◆ If the Model No., Serial No. or production date code on the product or any part thereof has been deleted, defaced, damaged, altered, obliterated or tempered with or removal for any reason whatsoever.
- ◆ If the warranty card is not completely filled, signed & stamped on the purchase of the product.
- ◆ For the damage resulting from accident, attempted repairs, mishandling or negligence on the part of customer or unauthorized persons.
- ◆ For normal wear & tear, ageing effect or chipping, peeling off or any other damage to the painted, plated, metalized parts, plastic parts, metal parts, element heater, thermal fuse assembly, switch & supply cord.
- ◆ For the damages caused during transshipment, handling and the defect caused due to natural calamity.
- ◆ For the damage resulting due to heater installed / operated in abnormal or hostile environment or due to exposure or entrapment of water from any source.
- ◆ If the ORPAT ELEMENT FAN HEATER is tampered with or opened by any unauthorized person.
- ◆ In case the Proof of Purchase has been altered or tempered with any manner whatsoever or has made illegible.

ORPAT IT'S PERFECT


Ajanta LLP

Orpat Industrial Estate, Rajkot Highway
Morbi - 363641. INDIA
Customer Care Tel No: +91 2822 230491
Email: customercare@orpatgroup.com
www.orpatgroup.com
ISO 9001 & 14001 Certified Company

ORPAT[®]

INSTRUCTION MANUAL CUM WARRANTY CARD

ELEMENT FAN HEATER (ELECTRIC RADIATOR)



OEH-1220

Model No.			
Serial No.			
Colour			
Purchase Date	(DD)	(MM)	(YYYY)
Bill No.			
Customer Name & Address			

Dealer Name

Dealer's Signature & Stamp

Customer's Signature

I accept the Terms & Condition of the Warranty

We welcome your valuable suggestions, if any to improve our Products & Services. Please mail us at customercare@orpatgroup.com
FOR PRODUCT SERVICE
Call Customer Care No. : +91 - 2822-230491 (9:00 AM to 6:00 PM)

IMPORTANT SAFEGUARDS

1. Please read the following instructions carefully before using the heater.
2. Remove the packing and make sure that appliance is intact. In case of doubt do not use the appliance and contact a qualified technician to have the unit checked. Do not leave packaging materials like bags and staples within reach of children.
3. Before switching on the appliance check if the electrical voltage and frequency of the circuit correspond to those indicated on the appliance.
4. Always plug the heater into a properly grounded power socket, which is also protected by ELCB (Earth Leakage Circuit Breaker)
5. Do not use this heater other than for its intended use.
6. Do not use it for any other purpose as it could be dangerous. The Manufacturer is not responsible for any eventual damages caused by improper or faulty use.
7. Always place the heater on a hard stable, plane & heat resistant surface and away from hot objects and naked flame.
8. The heater must not be located immediately below a socket outlet.
9. Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
10. Leave sufficient space all around the heater. Do not place any objects in front of the heater.
11. The use of this electrical appliance calls for the awareness of some basic rules, such as :
 - Never touch the appliance with wet or damp hands or feet.
 - Never expose the appliance to atmospheric conditions (rain, sun, etc)
12. In order to avoid overheating, do not cover the heater.
13. To reduce the risk of fire, the heater must not be installed close to curtains, clothes, beds and other combustible materials.
14. Do not use this heater with a programmer, timer or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
15. The heater must be switched off and the plug must be removed from the socket outlet before cleaning or when the heater is not in use. Remove the plug by pulling the plug & not the cord.
16. Plug directly into a power socket as extension cords may not be adequate to carry the load of the heater.
17. Do not use the appliance near liquids or inflammable-matters or explosive gas.
18. The fireguard of the heater is intended to prevent direct access to heating elements and must be in place when heater is in use.
19. The fireguard does not give full protection for young children and for infirm persons.
20. Never allow children to operate the heater. Extreme care must be taken when the heater is used near children and infirm persons.
21. Do not let the power cord overhang the edge of a tabletop where a child could reach.
22. The heater is hot when in use. To avoid burns, do not let the bare skin touch the hot surface. Do not move the heater when plugged or hot.
23. The heater has hot, arcing & sparking parts inside. Do not use it in areas where gasoline, paint or other volatile or flammable liquids are used or stored.

24. Do not immerse the heater, cord or plug in water or any other liquid.
25. In case the power cord is damaged, do not try to fix it yourself. Show it to a qualified technician.
26. Children, old people and disabled people are not often aware of the dangers, which can derive from improper use of the appliance. The appliance should never be use without an adult supervision.
27. Do not put the cable on the appliance when it is still warm.
28. The heater must be installed and kept vertically.
29. To avoid personal injury or damage, never insert fingers, pencils or any other objects through the front grill and any slot.
30. The heater is designed to provide supplemental heat only for residential applications and should not be used as a continuous primary heat source. Do not use outdoors.
31. If the appliance does not work, switch it off without tampering with it. If any repair is required please contact a qualified technician.
 - When switching ON Heater for the first time, there might be some emission of smoke fumes. These fumes are caused due to the action of the heat on locking adhesives. It is not a product fault and will disappear after a few minutes automatically.

INSTALLATION


This appliance requires no installation. It should be used solely as a portable appliance. Portable appliances are not suitable for use in a bathroom.

OPERATION

- Summer service (Ventilation only) : Turn the knob to setting fan.
- Heating at reduced power : Turn the knob (right) to setting | (1000W).
- Heating at full power : Turn the knob (right) to setting || (2000W).
- Switching off : Turn the knob (left) to setting 0.


GETTING TO KNOW YOUR HEATER

1. Function control knob
2. Main body
3. Guard
4. Element Heater
5. Legs
6. Power Cord



PLACEMENT GUIDE FOR THE HEATER

The heater should only be operated at a minimum distance of 1m from a wall or any other object. Position the air flow in order to optimize the heating of the room.



OVERHEAT PROTECTION

This heater has an overheat protection safety device that switches off the heater automatically in case of overheating. This may happen, if the heater is in operation for a long period of time. In this case, unplug the heater and let it cool down for about half an hour before using it again.

CLEANING AND MAINTENANCE

- (1) Always make sure to disconnect the heater from the power supply and allow the heater to cool down completely, before you start cleaning heater.
- (2) Never immerse the heater or its parts, power cord or plug in water or any other liquids for cleaning.
- (3) The main body of the heater may be wiped clean with a slightly damp, lint free cloth and then with a soft dry cloth.
- (4) Do not use any cleaning chemicals such as detergents and abrasives, as this will damage the product beyond repair.
- (5) If necessary, dust particles accumulated on the front grill / guard may be removed with a vacuum cleaner.
- (6) In case of any malfunction, do not try to repair the product by yourself, as this may result in a fire hazard or electric shock. Always contact a qualified technician.
- (7) To use after a long gap, please run the appliance on " Fan only" position for 10 minutes to ensure that the motor becomes free. In case the motor does not start, DO NOT turn switch to heating.