

Electric Towel Rack
INSTRUCTION MANUAL



Model: FED67965A

SPECIFICATION

Unit Size:	91cm x 53.5cm x 35cm
Input:	AC230V~50/60Hz
Output:	90W
IP Rating:	IP22, Class I

Page 1

CAUTION:

- This device only operates in UPRIGHT position.
- Store this device in Cool Dry environment when not in use.
- Do not store this device until it has cooled down.
- Suggest not putting more than 5KG products on this device.
- This device must not be located immediately below a socket-outlet.
- Any other servicing should be performed by a qualified representative.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or metal capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with this device.

CLEANING AND MAINTENANCE

- Cool down and unplug the dryer before cleaning it.
- Do not use abrasive and solvents. Only wipe clean the dryer with soft wet cloth.
- Clean the dryer surface's dust regularly.
- If you intended not to use this dryer, switch off and unplug it.
- If the mains cable is damaged, it must be replaced by qualified person in order to avoid hazard.
- Cleaning and user maintenance shall not be made by children without supervision.

This marking indicates that this product should not be disposed with other household wastes throughout the UK/EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.



Far East Direct (UK) Ltd.
Unit one, Johnlands Edworthy Concrete, Bow, Devon, EX17 6HG, United Kingdom.
Email: marketing@far-eastdirect.co.uk Telephone no. 0136382293


Page 6

FED67965A240925/V1.0

IMPORTANT SAFETY INSTRUCTIONS

- Read the instruction manual carefully before using this device, especially the safety instructions, and keep the instruction manual for future use.
- This device is FOR INDOOR USE ONLY.
- Extreme caution is necessary when this device is used by or near children or invalids and whenever the device is left operating and unattended.
- Always unplug this device when not in use.
- Do not operate this device with a damaged cord or plug or after this device malfunctions, has been dropped or damaged in any manner.
- Never locate this device where it may fall into a bathtub or other water containers.
- Does not run cord under carpeting. Do not cover cord with throw rugs, runners. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect this device, remove plug from outlet.
- Do not use it in area where gasoline, paints or flammable liquids.
- Use this device only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

PARTS DESCRIPTION



Page 3

EACH INDIVIDUAL PACKING INCLUDES:

1 x Towel Rack Unit with Mains Cable
1 x Accessories Kit (Feet, Wall-mounted Bracket, Screw, Rawl Plug)
1 x Instruction Manual


Accessories Kit, includes:

1		Feet x 2 pcs
2		Screw A x 8 pcs (for Feet installation)
3		Wall-mounted Bracket x 4pcs
4		Screw B x 16pcs (for fixing wall-mounted brackets to the unit)
5		Screw C & Rawl Plug x 4 sets (for Wall-mounted)

INSTALLATION INSTRUCTION

1. Please read the installation instruction carefully to understand how to install this device.
2. Take this Towel Warmer complete unit (with Mains Cable) and Accessories out of the box.
3. Remove all packing materials.


For Free-Standing Installation:




Install the feet with Screw A

For Wall-Mounted Installation:

Fix the wall-mounted bracket using Screw B



Follow the arrow direction and use the screws and rawl plugs fixed on the wall



WARNING:

This DEVICE IS INTENDED ONLY FOR DRYING TEXTILES WASHED IN WATER

- ❖ This appliance only allowed to be installed at a distance of at least 600mm above the floor.
- ❖ This appliance is to be installed so that switches and other controls cannot be touched by a person in the Bath or Shower.

OPERATING THE TOWEL WARMER

Switch turns to "0" position the device OFF
Switch turns to "I" position the device ON

1. Make sure to complete the installation. Press the switch to "0" position (Power indicator is off)
2. For Free-Standing, make sure the towel warmer is in the Upright Position and place on a flat surface.
3. Plug the power cord into an electric outlet.
4. Press the switch to "I" position (Power indicator lights up), then the warmer function starts working.

Page 4

Page 5