


TOZO®
www.tozostore.com



NC9 ACTIVE NOISE
CANCELLATION


User Manual

1.0 Product Overview and Features

The package contains TOZO NC9 earbuds preinstalled with M-size ear tips, a charging case, a USB-C cable, extra ear tips, and instructions.




Display Screen



USB C


Reset Button



User Manual




Quick Guide



Indicator Light/
Noise Canceling MIC

MIC



Charging Pin

Pressure Relief Hole

2.0 Wearing Guide

Adjust the wearing angle slightly after putting on the earbuds to push them gently into the ear canal for a better fit.



3.0 Pairing and Connectivity

Take out the earbuds from the charging case. They'll reconnect to the last paired device if paired before. If not paired or pairing canceled, the earbuds enter pairing mode with a slow white light blink. Search for [TOZO NC9] on your phone and connect.



4.0 Power On/Off

4.1 Earbuds Auto Power On

Open the lid, the earbuds will power on automatically.



4.2 Earbuds Auto Power Off

Placing the earbuds back in the charging case and close the lid will automatically power off.

4.3 Another Method of Earbuds Power On/Off

Tap and hold the "L" or "R" for 3 seconds; it will turn on when the earbuds power off.


Tap and hold the "L" or "R" for 5 seconds; it will turn off when not playing audio.

The earbuds will automatically turn off if they remain disconnected in ANC Off Mode for more than 5 minutes.




5.0 Operation and Controls


5.1 Wearing Both Earbuds



5.2 Wearing One Earbud




5.3 Calling Control




5.4 Active Noise Cancellation Control

The Active Noise Cancellation function is not available when using a single earbud.




5.5 Voice Assistant



5.6 Reset

If only one earbud is working, please follow these steps:

1. Delete all [TOZO NC9] Bluetooth records on your phone and turn off Bluetooth.
2. Put the earbuds into the charging case, close the lid, and wait for 12 seconds.
3. Tap and hold the RESET button on the charging case for 8 seconds to complete the reset.



6.0 Active Noise Cancellation Mode and Transparency Mode

6.1 Active Noise Cancellation Mode

With Active Noise Cancellation, TOZO NC9 earbuds detect external sounds through an outward-facing microphone and counter them with anti-noise, cancelling them before they reach your ears. Additionally, an inward-facing microphone listens for unwanted internal sounds, which are also negated by the anti-noise feature.



Active Noise Cancellation

6.2 Normal Mode

Normal mode is the default mode.

6.3 Transparency Mode

Transparency Mode enhances the voice frequency band, improving awareness of your surroundings, so you can hear what's around you without removing your earbuds. Both Active Noise Cancellation and Transparency Mode work best when your TOZO NC9 fits and is worn properly.



7.0 Charging and Battery

7.1 Charging Case Indicators

1. Open the charging case lid or insert the earphones into the charging case, the screen will show the battery levels of both the charging case and the earbuds. The screen will turn off after 5 seconds.
2. While charging, the battery percentage of the charging case will flash on the screen, and at the same time, it will show the earbuds' battery levels. The screen will turn off after 5 seconds.
3. If you single-click the Reset button on the charging case, it will display the battery levels of both the charging case and the earbuds. The screen will turn off after 5 seconds.



8.0 TOZO App

Download the TOZO App for UI customization, EQ settings, and more.

- UI customization: Most of the controls can be customized in the app.
- EQ settings: There are lots of EQ settings you can choose from in the app to optimize your experience while enjoying different music genres.
- Earbuds firmware update: The earbuds firmware can be updated in the app.

Once you connect the earbuds to the app, you will be informed if a new version of firmware is detected.



9.0 TOZO App Pairing


Step 1:

Download the TOZO app on your phone.



Step 2:

Pair your earbuds with Bluetooth.



Step 3:

Pair your earbuds with the TOZO app.

**10.0 EU Battery Regulation**

This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided with this product shall not be treated as household waste. Instead, please separate battery(ies) from other types of waste and recycle it (them) through your local recycling system to protect environment and health. (When Cd is more than 20ppm or Pb is more than 40ppm, the chemical symbol of the excess substance shall be marked under the separate collection symbol) For more detailed information about recycling of this battery(ies), please contact your local authority or the shop where you purchased the product or battery(ies).

11.0 FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

12.0 ISED Compliance Statements

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet émetteur ne doit pas être colocalisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.

13.0 CE-DOC

Hereby, [Manufacturer] declares that the radio equipment type [Model No.] is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
www.tozostore.com



The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 5.0 Watts in order to achieve the maximum charging speed.



Points de collecte sur www.quelinfoirmecodechets.fr
Privilégiez la réparation ou le don de votre appareil !

Model No.: T11124

Thank you for purchasing the TOZO authentic product.

For more latest products, parts and accessories,

please visit: www.tozostore.com

For any assistance please contact Email: info@tozostore.com



Scan the QR code to get the manual in other languages