


Introduction

Thank you for choosing SoundPEATS Value Bluetooth headset. Please read the manual carefully, and keep it for further reference. If you need any further assistance, please contact our customer support team by sending email to support@soundpeatsaudio.com.


Package Content



- ① 1 x SoundPEATS Value Bluetooth Headset
- ② 1 x Slide Line Buckle
- ③ 1 x Cord Clip
- ④ 1 x Carrying Case
- ⑤ 6 x Interchangeable Ear Tips
- ⑥ 6 x Interchangeable Ear Fins
- ⑦ 1 x USB Charging Cable
- ⑧ 1 x User Manual



Product Diagram



- ① USB Charging Port
- ② Volume+ / Next Track
- ③ Multifunction Button
- ④ LED Indicator
/ Microphone
- ⑤ Volume- / Previous Track

Specifications

Bluetooth Version	Bluetooth 5.0
Bluetooth Profile	HSP、HFP、A2DP、AVRCP
Bluetooth Chip	BK 3266
Audio Codec	SBC
Maximum Working Range	33 feet (10m)
Lithium Polymer Battery	3.7V / 55mAh*2
Working Time	Up to 7 hours (8 hours when the volume at 60%)
Charging Time	1-2 hours
Standby Time	Up to 100 hours
Dimension (L * W * H)	25 x 0.98 x 1.26 inches / 635 x 25 x 32 mm
Weight	0.53 oz / 15.0g

Get Comfortable

Fit in your ears

The Value headset comes with 6 interchangeable ear tips and 6 ear fins. The ear tips and ear fins are in different sizes, two of which are equipped on the headset. Please choose the right size of ear tips and ear fins to find the most secure and comfortable option for yourself (normally the medium ones are suitable for 75% of people).

Wearing the headset

1. Identify the right and left earpieces.
2. Insert the earbuds into your ears. Adjust the ear fins direction and put them into your ears.
3. Adjust each earpiece until it fits flush in your ear and the ear tip seals in the ear canal.



Getting Started

Charging

The headset is partially charged in the factory. Please make sure it is fully charged before first use.

1. Connect the charging port with any USB charging adapter or active computer USB port.
2. Charging starts automatically with LED indicator turning red and the headset turns off.
3. The headset is fully charged when LED indicator turns blue.

Notes:

1. The LED indicator flashes red when the battery is low, and you will hear a voice prompt "battery low". Please recharge the headset.
2. Charge the headset at least once every 3 months when not using for a long time.
- 3. When charging with a USB adapter, the charging current should not be greater than 1A.**

Pairing

1. Please turn off other Bluetooth devices nearby, and make sure the headset and your Bluetooth device are close enough (within 3 feet).
2. Power on the headset, press and hold the Multifunction button for approximately 3 seconds until the LED indicator flashes blue quickly, then you will hear the voice prompt "power on". Now the headset is in pairing mode.

3. Active the Bluetooth function on your device and search for the nearby Bluetooth connection:

For iPhone/iPad/iPod®: Settings -> Bluetooth -> On

For Android™: Setting ->Wireless & Networks -> Bluetooth -> On -> Scan for devices

For Windows® Phone devices: Settings -> Bluetooth -> On

4.“SoundPEATS Value” should be listed in the search result. Select the name to connect. Once connected, the indicator light is solid blue. You will hear a voice prompt “your headset is connected”.

Notes:

1. The Value headset will automatically power off with the LED light flashes red once Bluetooth disconnects for 2 minutes .
2. Maximum operating range for the Bluetooth headset is 33ft (10m). If you move out of range, the headset will lose connection. You will need to move back to be within the range and reconnect to your Bluetooth audio device.
3. When you want to unpair the headset with the device, just press the volume buttons + and - simultaneously for about 3s, it will lose connection with the device.

Re-pairing

The Value Bluetooth headset can remember previously paired devices. If you have previously paired the headset with a device, simply turn on your device and the headset (by pressing the multifunction button for 3 seconds) will automatically connect without going into pairing mode.

Reset

Value bluetooth earphones can be reset by pressing the Multifunction button and "-" button simultaneously for 3s when the headset is on(haven't connected to any devices). The earphones will be reset successfully when the LED indicator flashes blue for 1.5 s.

Controls and Voice Notification

Button Controls

Once connected, the Value headset can manage media and phone calls on a smartphone or tablet.

Function	Operation
Power On	Press and hold the Multifunction Button for 3s until the led light flashes blue
Power Off	Press and hold the Multifunction Button for 3s until the led light flashes red
Play/Pause	Short press the Multifunction Button
Volume +/-	Short press the +/- button
Play Next/Previous	Long press the +/- button for 2 seconds
Answer Phone Call	Short press the Multifunction Button
Hang Up	Short press the Multifunction Button in an active call
Reject Phone Call	Press the Multifunction Button for 1.5s
Transfer Between Headset and Phone	Press the Multifunction button for 1.5s during a call
Call Switching	Double Press the Multifunction Button to switch between two active calls.
Siri (for iOS)	Double press the Multifunction while in playing or pausing mode

Voice Prompt

Action	You will hear
Turn on the headset	Power on
Turn off the headset	Power off
Successfully paired	Your headset is connected
Battery level low	Battery low
Unpaired	Your headset is disconnected

LED Indicator

The LED indicator gives a good indication of what the headset is doing.

LED Indicator	Status
LED indicator is solid red	Charging
LED indicator is solid blue	Fully charged
LED indicator flashes red once every 6 seconds	Low battery
LED indicator is solid blue for 1.5s	Reset

Trouble Shooting

Q: The headset is on, but it is not connecting to my device?

A: To connect the headset to your device, please check if the Bluetooth of the device is on at first, then select the name of the headset on the Bluetooth list to get paired. If the headset still can't connect to your device, please try to reset it by reading the reset section.

Q: The sound is not very clear / the caller cannot hear my voice clearly?

A: Please adjust the volume on your phone and headset. Make sure there is no source of interference nearby. Stay close to your smartphone.

Q: I have established connection with my smartphone, but I am not hearing any sound?

A: Please make sure that you turn up the volume of both devices. Some smartphones require you to setup the Bluetooth headset as an audio output device before sound is transmitted. Please read the instruction of your smartphone for details. If you are using music players or other Bluetooth devices, please make sure they support A2DP stereo music profile.

Q: Can I use the headset while it is charging?

A: No, you can't use the headset while it is charging.

Q: Why the connection is not stable and cuts out intermittently?

A: Please make sure there are no objects between the headset and your Bluetooth device, and also make sure there is no radio or WIFI interference nearby.

Q: What is the range of Bluetooth headset?

A: Bluetooth headset has maximum range of 33 feet (10m). However, the actual range will depend on usage and environment. Connection is usually good within 15-25 feet with no major obstacles between.

Q: My headset will not switch on.

A: Please recharge it and make sure it has enough battery power. If it is fully charged and still nothing happens or if you are not able to charge the unit, please contact our customer support for further information.

Care and Maintenance

- Keep the earbuds away from heat and humidity.
- Do not put the product under direct sunlight or hot areas. High temperatures will shorten lifespan of the earbuds, battery and / or the internal circuit board.
- Power off the earbuds when not in use and before storing.
- Do not try to take the product apart.
- Do not drop or knock your earbuds on hard surfaces.
- Do not use chemicals or detergents to clean the product.
- Do not scrape the surface with sharp objects.

Warranty and Support

Customer Support

If you need any assistance or support, please email **support@soundpeatsaudio.com** with details. You will hear back from us within 24 hours. We will do our best to provide you with a viable solution.

For more information, please visit **www.soundpeatsaudio.com**.

Warranty

We warrant this device **12 MONTHS** from date of the original purchase for manufacturer defects.

If the device fails due to a manufacturing defect, please contact seller directly to initiate return and warranty process.

The following are excluded from **SoundPEATS** warranty cover:

- Device purchased as second hand, used or from unauthorized seller.
- Damage resulted from misuse and abusive action.
- Damage resulted from chemical, fire, radioactive substance, poison, liquid.
- Damage resulted from natural disaster.
- Damage caused to any third party / person / object and beyond.

Please do not return the product without seller / SoundPEATS authorization.

Statement

We can only provide after sale service for products purchased directly from SoundPEATS or SoundPEATS authorized distributor. If you have purchased from a different seller, please contact them for any exchange or refund request.