


IN THE BOX

EN



Times Gate



USB-C Charging cable



User manual



Thank you for purchasing a Divoom product. Please read through this manual carefully. Visit divoom.com to learn more about your products.

Due to the nature of a technology product, the information on this manual is subject to change without prior notice. For any question, please contact support@divoom.com.

CONTROLS

EN

1. LIGHT

Press: Switch between ambient light "sets"

2. MODE

Press: Switch between the LCD's "display set"

3. POWER

Press: Turn OFF both LCD displays & ambient light
Hold: Reset Times Gate to Network Settings



4. LEFT Arrow

Press: lower "display set" brightness by 10%
Hold: lower "display set" brightness at a rapid rate

5. RIGHT Arrow

Press: Increase "display set" brightness by 10%
Hold: Increase "display set" brightness at a rapid rate


6. USB-C Power Port



SETUP

EN

1 Download Divoom APP




2 APP Device



Download the Divoom from the App Store and Google Play™

3 Setup the WiFi




RESET NETWORK

EN



**Power on and long press 8 seconds
to reset network settings**



TROUBLESHOOT

EN

1. Device is powered, but it is unresponsive/restart in loop/not started properly

- A) Make sure it's connected to 5V==1A USB charger.
- B) Try a different USB adapter/cable.
- C) Make sure none of the buttons is held or stuck while inserting the power cable.

2. Network pairing failed

- A) Make sure place both device and phone near the WiFi router.
- B) Use a 2.4G WiFi connection. 5G WiFi/Public WiFi are not supported.
- C) Try the WiFi setup on a different phone or with a different WiFi network
- D) Download the latest Divoom APP from the APP store or Google Play.

TECH SPEC

Dimension (mm): 283*47*97

Output: 5W

Weight: 406.4g

Microphone: MEMS

LED : 4.0×2.0×1.6mm(45 RGB light beads)

Charge: via USB cable, 5V==1A

Screen: 5 x 1.44" LCD modules