

105x148mm

105x148mm



made in China

## Hair Dryer



HDG-06

### INSTRUCTION MANUAL

Please read these instructions carefully  
and retain for future reference

### SPECIFICATION:

1. Item: Hair Dryer
2. Item NO.: HDG-06
3. Voltage/Frequency Range: 125V | 60Hz
4. Wattage Range: 1600W

- ① Removable back cover
- ② Special Speed control
- ③ Speed & Temperature Control Button
- ④ Indicate light
- ⑤ Diffuser
- ⑥ Styling concentrator



### Power Switch:

Position 0: OFF

Position  : Cool air

Position 2: Mid-power, medium temperature for gentle drying and styling

Position 3: Full power, high temperature for quick drying

### Rotary Switch:

Rotate this switch and flexibly adjust wind speed during drying or styling, meet all the needs and care for your hair without damage.

### Indication Lights:

Showing different settings

### Package includes:

1 \* Hair Dryer; 1 \* Diffuser; 1 \* Styling concentrator; 1 \* User Manual.

### Styling concentrator:

Keeps the surface of the attachments cool for easy adjustment and close-up styling. Dries hair gently using smooth air. Fast, precise airflow for controlled styling, one section at a time.



### Diffuser:

Evenly disperses airflow to dry curls gently and help reduce frizz. Recommended for use on the low temperature and flow settings.



### Installation and disassembly

**Installation method:** This product is equipped with one nozzle and one diffuser.  
Please select the nozzle you want to use.  
Align the bottom of the air nozzle with the air outlet and lightly buckle.  
When you hear a "click", the nozzle is fixed.



**Disassembly method:** Take down the nozzle from the hair dryer and remove the nozzle.



**Note:** Please install and remove the nozzle in the off status. Do not adjust, load and unload the nozzle during use.  
When disassembling the nozzle after use, wait for the nozzle to cool before removing it to avoid burns.

### Cleaning and maintenance

When cleaning the air outlet, please make sure that the product is not plugged into the power plug. Please remove the air nozzle, use a cotton swab to remove the attachments on the air outlet, and wipe the product with a dry cloth.



When cleaning the air inlet, please make sure that the product is not plug, use a cotton swab or teeth brush to remove the attachments on the air inlet.



### Notice For USE:

1. Wash your hair and dry with towel to remove excess moisture.
2. Use hairdryer with styling brush, blow the hair in sections. Notice to keep a distance between hair dryer and the hair.
3. Concentrate nozzle is designed for daily drying or straight hair; while diffuser can spread the air for curl or fluffy hair
4. Do not concentrate the blow air on one section for long time in order to avoid over drying, keep airflow moving for styling.

**Attention** :

Things you should be attention base on daily use.

1. Keep the power switch on "0" position and make sure it's unplugged when your hair dryer is not in use.
2. Keep your hair away from air inlet / filter when the hair dryer is working.
3. Do not choke the air inlet / filter, otherwise overheating will happen.
4. We suggest high power for drying hair, and low power for styling;
5. When the hair dryer breaks in any situations , unplug the power source at once to cool it down.
6. If the hairdryer falls into water, unplug and cut the electricity immediately, Do not put your hand into the water.
7. Do not twist, pull, bend, or wrap the cable around the dryer. Keep the cable untwisted during use.
8. Keep the hair dryer in a safe, dry circumstance, make sure it won't be reached by kids.



**The air exit and metal ring may be hot during use.**

**Allow to cool before handling.**

**WARNING** :

To avoid the risk of burning, electrocution, fire, or injury:

1. This appliance should never be plugged under the unattended situation.
2. It should be attention when this appliance is used by, near children or disabled.
3. Do not use during bathing.
4. Do not store appliance where it may fall or be pulled into a water tub or sink.
5. Do not drop it into water or other liquid.
6. Do not detach the hair dryer without professional maintainer.
7. Do not use irrelevant attachments on the hair dryer. In the package there're diffuser and nozzle for this hair dryer.
8. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid the risk.
9. Never operate this appliance with damaged cord or plug , do not use if it's damaged, or dropped into water.
10. Keep the cord away from heating situation, Do not wrap the cord around the appliance.
11. Never block the air openings of the appliance or place it on a surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair and the like.
12. Never drop or insert any object into any opening or hose.
13. Do not use outdoors or operate where aerosol(spray)products are being used or where oxygen is being administered.
14. Do not use an extension cord with this appliance.
15. Do not direct hot air toward eyes or other heat sensitive areas.
16. Attachments may be hot during use, do not touch them until cool down.
17. Do not put any stuffs on the surface of hairdryer while it is operating.
18. For additional protection the installation of a residual current device(RCD)with a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom, ask your installer for advice.