






Note: this garment rack can be configured into two styles, depending on your needs.




USER MANUAL

Garment Rack

SKU: EA_423 EA_424

Attention: There is no need to return this garment rack. Should you have any problems or concerns regarding this item, please contact us through Amazon, thank you!




Attention:

- Prior to assembly, spread out all parts to check if any part is missing; should any part be found missing or damaged , kindly reach out to us for further assistance.
- Please be sure to keep any parts and/or packing material in the package away from infants/toddlers/small children during the process of assembling this garment rack.
- Any unauthorized modification to this item will void its warranty.

Parts List

Ⓐ X8PCS



Metal Shelf

Ⓑ X8PCS




Lower Pole

Ⓒ X16PCS




Middle Pole

Ⓓ X8PCS




Upper Pole

Ⓔ X4PCS




Clothes Hanger Rod

Ⓕ X2PCS



Support Rail

Ⓖ X72PCS+2
(2PCS are for spare use)




Plastic Clip

Ⓗ X6PCS




Hook Bracket

Ⓘ X8PCS



Screw

Ⓙ X4PCS




Hooks


Ⓚ X1PCS

Anti-Tip Device


Important:





Location for holding
the plastic clips in place



Plastic Clips'arrow shall
be Pointed up









Why is there a gap with clips clamps?

Item structure design need the gap instead of quality problem, the heavier the shelf loaded, the tighter the clip clamps; the clips clamps to support each wire shelf as weight loaded increased.




Note:Hit hard along the edges of the
metal shelf with a rubber mallet
it is firmly fastened to the poles


Step 1




Step 2




Step 3







Step 4




Step 5








Step 6




Step 7












Step 8







Step 9





Step 10




Step 11












Step 12







Step 13




Step 14




Step 15




Step 16




Note:This is an optional step; you can fasten the assembled garment rack to the wall using anti-tip devices included in the package.






Instructions for another configuration are as follows:


Step 1




Step 2





Step3






Step 4







Step 5




Step 6








Step 7




Step8













Step 9












Step 10




Step 11




Step12




Step 13




Step 14



Note:This is an optional step; you can fasten the assembled garment rack to the wall using anti-tip devices included in the package.





SAFETY PRECAUTIONS

⚠ WARNING

- This unit contains small parts which could be a choking hazard for small children. Children should be under supervision at all times or serious injury could occur.
- Always unload unit prior to moving the unit. The weight of personal belongings can cause the unit to become unstable and either tip or collapse. Serious bodily injury and/ or damage to personal belongings may occur.
- Don't overload unit. If any shelf, top, or bottom of unit bows or bends, it is overloaded. The shelf, top, or bottom could collapse and cause serious bodily injury and/ or damage to personal belongings.
- Do not climb or step on the unit. The unit may become unstable and either tip or collapse. Serious bodily injury and/ or damage to personal belongings may occur.
- Do not mount or attach anything to the sides, rear, or front of the unit as this can create a force which can cause the unit tip. Serious bodily injury and/ or damage to personal belongings may occur.
- Do not stack units. Stacking of units can cause an unsafe tip-over hazard which may cause serious bodily injury and/ or damage to personal belongings.
- Follow proper safety procedures if using power tools and ladders.
- We recommend you protect your work surface during assembly to prevent scratching or damage to table tops, wood floors, etc.



FOLLOW INSTRUCTIONS CAREFULLY

Please do not return product to the retail store. For product assistance and warranty information please call Consumer Affairs at 1-844-386-8309.

Manufacturer Warranty

Manufacturer will replace any missing or damaged part due to manufacturer defect. Please have proof of purchase.

