

CONTENTS


English 01~10

Deutsch 11~20


English

Thank you for choosing the **wireless sport stereo headphone**. Please read this user manual carefully and keep it for future reference.


Package Contents




1 x wireless
sport headphone



1 x USB Charging Cable




6 x Ear Buds And
1 x Cable Clothing Clip
1 x Line buckle



1 x User Guide

Congratulations on purchasing the wireless headphone. Your headphone allows for hands-free use on the go. It includes echo elimination technology that provides superior sound quality. For best results, read this user manual in full before you use the product.

Product Overview



Power on	Long press the MFB for 3 seconds
Power off	Long press the MFB for 3 seconds
Pairing mode	Long press the MFB for 8 seconds
Answer call	Short press the MFB one time
Cancel/end call	Short press the MFB one time
Reject call	Long press the MFB for 1 second
Activate Siri	Double press the MFB
Mic mute switch	Press +/- simultaneously
Transfer audio	Long press the MFB for 1 second
Pause/play	Short press the MFB
vol-/vol+	Short press vol-/vol+
Previous/next song	Long press vol-/vol+ for 3 seconds

How to connect

1. Keep your Bluetooth device within 1 meter of your wireless headphone when pairing.
2. Enter pairing mode as follows: First, ensure your headphone is off. Next, press and hold the MFB for approximately eight seconds. You will know that the device has entered pairing mode when the red and blue LEDs flash rapidly.
3. Using your Bluetooth device, scan/search for available Bluetooth devices. Select the headphone from the list of devices shown.
4. If prompted for a password or PIN, enter the following: 0000
5. Some cell phone models can connect automatically and others will provide a prompt. If prompted by your cell phone to connect, select 'Yes'.

Warning: Please dry the headphone after each work

Multi-pairing

1. Start by long pressing the MFB for three seconds to turn the wireless headphone off. Next, long press the MFB for about eight seconds, until the red and blue LEDs on the headphone flash repeatedly. This indicates entry to the search and pairing state.
2. Turn on the bluetooth of mobile phone and search for the headphone, then click to complete the connection.

3. Turn off mobile phone Bluetooth. Then turn off the headphone by long pressing the MFB until the red LED turns on.
4. Long press the MFB for three seconds to turn it on again. Then long press the MFB for eight seconds, until you see the red and blue LEDs on the headphone flash repeatedly again, indicating entry to the search and pairing state.
5. Turn on the Bluetooth function of mobile phone #2. Search for the headphone and click to complete the connection.
6. Turn on mobile phone #1's Bluetooth function and find the connected wireless headphone. Click to complete the connection.

Keep your wireless headphone in close proximity to your cell phone. The headphone works much better if it has a clear line of sight to your cell phone. Assuming there are no obstacles between your cell phone and the headphone, it has a range of about 10 meters. Beyond this distance, the connection may become less reliable and sound quality may deteriorate.

Reconnect the headphone

1. If the connection is lost, your headphone will attempt to reconnect automatically.
2. If your wireless headphone is not able to reconnect automatically, press the MFB once or use your cell phone's Bluetooth settings to reconnect manually.

Specifications

Input Power : 5V  1A

Support Protocols : HFP/A2DP/AVRCP/SPP

Support Codec : SBC/AAC

Talk Time : About 12 Hours

Music Time : About 15 Hours

Standby Time : About 250 Hours

Charging Time : About 2 Hours

Charging

Your headphone comes with a built-in rechargeable battery. Before using the device for the first time, it is recommended to charge the battery fully.

1. Connect the headphone to your USB charger.
 - Red LED indicates the device is charging
 - Blue LED indicates the device is fully charged
2. It takes 1.5-2 hours to charge the battery fully.
3. Please note the input power should be no more than DC 5V/1A, to avoid potential damage to the headphone.

Warning: Please avoid to use low quality USB charger

Restore to factory settings

Long press the MFB button for about three seconds while charging. The red and blue LEDs will flash three times to indicate that factory settings have been restored.

Common problems and solutions

1. Cell phone does not detect the headphone

Solutions:

- 1) Confirm that the wireless headphone is turned on and in pairing mode. If the blue and red LEDs are flashing alternately, the headphone is in pairing mode.
- 2) If the wireless headphone is turned on but still can't be found on your Bluetooth device, restart both the cell phone and the wireless headphone and then try again.

2. After connecting the wireless headphone with your mobile phone, you experience disconnections or low sound quality.

Solutions:

- 1) This wireless headphone may have low battery. Recharge the device as needed.
- 2) There may be an obstacle between your cell phone and the wireless headphone. Ensure this is not the case. You should be aware that your hand may obstruct communication if you are holding it against the headphone. Make sure the line of communication is clear of any obstruction between these two devices.
- 3) Your wireless headphone may be out of range. Try to move it closer to your cell phone for best results.

3. The wireless headphone has connected successfully, but you can't listen to music.

Solutions:

- 1) Some cell phones do not have a complete Bluetooth function and stereo Bluetooth module that are required to listen to music. Please test whether this is the case by connecting your wireless headphone with another cell phone. If you can listen to music through the other cell phone, the wireless headphone is functioning as it should.
- 2) Check your Bluetooth settings of handsfree mode.

4. How to use wireless headphone to listen to music or chat on computer?

Solutions:

If your computer has a Bluetooth function, simply open it and search for the wireless headphone.

If your computer does not have a Bluetooth function, then you will need a wireless adapter in order to connect your computer to the headphone. We recommend IVT wireless adapters.

5. What's the Bluetooth pairing password?

Solutions:

The Bluetooth pairing password is 0000. Only a very small proportion of cell phones require manual password entry. Most cell phones enter this password automatically.

6. Do these block out outside noise to a good degree? How does its noise cancellation function work?

Solution:

The headphone is featured with a passive noise cancellation. Please try silicone ear tips, they won't block sound from your environment as foam ones. It could prevent higher-frequency noise from reaching the ear, it does have passive noise isolation function- soundproofing.

7. What is the Bluetooth connection range?

Solution:

The available distance between the Bluetooth headphone and the mobile phone or other Bluetooth devices is about 30ft in Open Space and up to 10ft in Inner Space. It would lose connection or cause noise while outside the Bluetooth connection range.

8. How to connect two smart phones at the same time?

Solution:

Please turn on the headphone, when it is in pairing mode turn on the first phone bluetooth, connect the headphone to the first smart phone via bluetooth. After connecting successfully, turn off the first smart phone bluetooth and turn on the second smart phone bluetooth, connect the headphone to the second smart phone via bluetooth, then turn on the first smart phone bluetooth again and connect it to the headphone. And it would finally show that both smart phones are successfully connected to the headphone.

9. How is the waterproof level of the headphone?

Solution:

The headphone is coated with nano waterproof material. The headphone will not be damaged by rain or even in the shower - but we strongly do not recommend using them in a pool.

10. The red light is not on when charging.

Solution:

If the bluetooth headphone has not been used for a long time, it may need to be charged. Try charging the headphone for 30 minutes. The red light should come on again.

11. How long does this headphone last before it needs to be charged?

Solution:

The headphone has a better battery efficiency with up to 15 hours of play. Its standby time is about 220 hours without using.

12. The headphone could not hold a charge anymore?

Solution:

It might have two reasons. One is that the charging cord is broken, please try to use other charging cord to charge the headphone. Another one is that there might be something wrong with the battery. If it is kept too long time without using and charging, the capacity and the life of the battery will reduce.

Warranty

We guarantee every product has undergone rigorous tests prior to shipping. We are so confident in the quality of our products that we offer a one year warranty from the date of purchase.

Note: this headphone conforms to IPX7 waterproof standard:

Suitable	* Splashes * Rain or Snow * Showering * Incidental exposure to water of up to 1 meter for up to 30 minutes
Unsuitable	* Swimming * Diving into water * Snorkeling or Scuba Diving * High-speed watersports

EC REP	eVatmaster Consulting GmbH Bettinastr. 30 60325 Frankfurt am Main, Germany contact@evatmaster.com
UK REP	E VATOST CONSULTING LTD Suite 11, First Floor, Moy Road Business Centre, Taffs Well, Cardiff, Wales, CF15 7QR contact@evatmaster.com