

SelePow

Electric Mason Jar Vacuum Sealer VP06+ User Manual




Parts and Functions




Type-c charging port
LED digital display area, display content:
1. Working time display
2. Power display
3. Charging display

Keystrokes:
1. Click to start or stop
2. Long press to view power




Main machine (suitable for 3.39in wide mouth mason jar)

Regular mouth sealing converter (suitable for 2.76in regular mouth mason jar/removable)



Wide mouth sealer sealing silicone ring(When working, please check that the silicone ring is installed properly, and do not let the silicone ring break away from the host)

Wide mouth sealer



Regular mouth sealing converter silicone ring (When working, please check that the silicone ring is installed properly, and do not let the silicone ring break away from the host)

Regular mouth sealing converter (Remove it from the main unit when you need to use the wide mouth seal)

How to use

1. How to use sealed mason jars

1.1. Correctly select the required caliber sealer (wide mouth/regular mouth);

1.2. Put the food into the mason jar (do not let the food be completely filled, it is recommended that the food should not exceed the bottom thread of the mason jar mouth, in order to achieve a better vacuum sealing effect)




It is recommended that the food does not exceed this thread, in order to achieve a better vacuum sealing effect.

1.3. Wipe the mouth of the bottle and the sealing cap clean, and there should be no dirt or liquid residue;


1.4. Align the bottle cap with the mouth of the bottle (see the picture below)



1.5. Align the electric mason jar sealer with the mouth of the jar and press down until the sealer compresses the bottle cap (see the figure below)




Schematic Diagram of Operation of Regular Mouth Mason Jar



Schematic Diagram of Operation of Wide Mouth Mason Jar

1.6. Press the "Switch" button to start the machine, until the air in the bottle is evacuated, then press the "Switch" button again (see the figure below)




Reminder :

1. Due to the vacuum pressure generated between the electric mason jar sealer and the mouth of the jar, it is necessary to press with greater force during the pressing down process to confirm that the sealer is tightly pressed against the bottle cap.
2. When the power display is lower than 20%, please charge it in time;
3. It is recommended to keep vacuumizing for more than 40s ;

2、How to disassemble the regular port converter

2.1. To remove the "Regular mouth sealing converter" from the host, please rotate the "Regular mouth sealing converter" counterclockwise, after hearing a "click", (🔓) corresponds to (🔒), and then pull up the "Regular mouth sealing converter" (See below).



Troubleshooting

Wide Mouth Mason Jars Won't Seal	1. Check whether there are particles or liquids in the sealing area of the mason jar bottle mouth and lid. If there is any, please wipe it clean.
	2. Check whether the sealing silicone ring in the wide-mouth sealing area is offset, if so, please install it in place.
	3. Check whether the sealer is pressed to the bottom when using the sealer. If you cannot be sure, please repeat the operation to ensure that the sealer is pressed to the bottom.
	4. If sealing liquid items, please keep the liquid items under the mason jar thread to ensure a reliable sealing effect.
Regular Mouth Mason Jars Won't Seal	1. Check the above four points.
	2. Check whether the regular mouth sealer has been inserted into the sealing silicone ring in the wide mouth sealing area. If you are not sure, please repeat the operation to ensure that it is completed as required.

Product Specification

Product Name	SelePow Electric Mason Jar Vacuum Sealer
Plastic Material	ABS, silicone
Battery Bapacity	1300mA
Charging Voltage	DC5V
Charging Current	1A
Power Rating	< 5W
Charging Time	2.5h

Precautions for Safe Use

1、The working voltage of this product is DC3.7V, please fully charge it before use.
2、All accessories of this product are not allowed to be sterilized by microwave ovens, so as not to be damaged by thermal deformation.
3、Do not put the host into water or other liquids, and do not wash it under water or other liquids. It is strictly forbidden to wash all parts at high temperatures above 60°C.
4、Do not use steel wool, abrasive cleaners or corrosive liquids (such as gasoline, acetone, etc.) to clean the product.
5、Do not put any parts of this product into the dishwasher.
6、This product is not waterproof.
7、Do not plug or unplug the charging cable with wet hands.

After-sales Service

We will provide for 6-Months warranty. If you have any questions about our Mason jar vacuum sealer, please contact us immediately and we will provide you with satisfactory service within 24 hours.
Contact email: selepow@outlook.com