


Thank you for your purchase!
We hope you love your chair.


Important note: CLIQ Chair is designed to break-in with use.
Buttons may be hard to depress during break-in period, but will loosen up after 10 uses.

Setup For more help: watch the instructional video at www.cliqproducts.com/setup.


1) Undo the velcro strap




2) Allow spring-loaded legs to unfold and click into place




3) Extend **front** telescoping arms until buttons are locked into place
*One button per front arm



4) Extend **back** telescoping arms until buttons are locked into place
*Two buttons per back arm



5) Confirm all **6** spring-loaded buttons are locked in place
*One button for each front arm and two buttons for each back arm




6) Sit and enjoy!




Takedown

1) Collapse all 4 arms by depressing the 6 spring-loaded buttons


Important note: Buttons may be hard to depress during break-in period, but will loosen up after 10 uses.



2) Press center button located on the Hub and fold legs upward until compact



3) Use velcro strap to secure your chair



1 Year Warranty & 45-Day Money Back Guarantee

If for any reason you are not 100% satisfied with your chair purchase please contact us at support@cliqproducts.com