


# NERF

AGES 8+

**CAUTION:**  
Do not aim at eyes or face. TO AVOID INJURY: Use only darts designed for this product. Do not modify darts or dart blaster.



NOTE: Accessories from other N-STRIKE blasters (sold separately) may work with the tactical rail.



## STRONGARM™\*

Be sure to read and follow all instructions carefully before using this product.

**Hey NERF Nation!**  
Join us online and keep up with the latest and greatest news from NERF!



Ask a parent before going online.

Questions? Call 1-800-327-8264


Product and colors may vary.




YouTube and the YouTube logo are trademarks of Google Inc. ©\* and/or TM\* & © 2011 Hasbro. All Rights Reserved. TM & © denote U.S. Trademarks. U.S. Pat. No. 5529050, US, BR, CN & EM Pats. Pending.

36033 PN 7247400000


## LOADING



1. Press **BARREL RELEASE BUTTON** to open **ROTATING BARREL**.




2. Load all 6 darts into **ROTATING BARREL**. Be sure to completely push darts into tubes.




3. Push **ROTATING BARREL** until it snaps back into place.

## TO FIRE 1 DART




1. Pull back **SLAM FIRE SLIDE** until it clicks.



2. Pull **TRIGGER** to launch dart.

## SLAM FIRE



1. Hold **TRIGGER** down.

2. Rapidly move **SLAM FIRE SLIDE** all the way back, then all the way forward. Repeat to continue firing.