

llano

Laptop Cooler

User Manual

No light version



Preface

Thank you for choosing to purchase and use our product. In order to make the best use of all the features of this product, please read this manual thoroughly before use and operate the product correctly. The product specifications and information mentioned in this manual are for reference only, and we reserve the right to update the content without prior notice. Unless otherwise specified, this manual serves as a user guide, and all statements and information contained herein do not constitute any form of warranty.

Notes

1. Please do not disassemble, repair, or modify this product on your own.
2. If the product is not in use for an extended period of time, please store it properly.
3. Please use the original accessories to prevent damage to the product.
4. If any problems arise during the use of this product, please contact the dealer you purchased from or our customer service center immediately.
5. For your safety, please do not put your fingers into the safety guard.

Package Contents

Laptop Cooler*1	12V3A Adapter*1	Data cable (1M) *1
User Manual*1	Memory foam*1	Dust filter cotton*1

Product Information

Dimensions	430*330*70 mm
Weight	Approximately 2KG
Material	ABS+Metal
Suitable for	Laptops over 15.6 inches and above
Power Supply	External 12V/3A 36w
Fan Speed	300-2800rpm
USB Expansion Ports	3
Power Interface	5.5*2.1mm
Fan Operating Noise	20-70decibels


Usage Steps

1. Open the support feet at the bottom and adjust to an appropriate angle (this product has 3 levels of height adjustment: flat, level 1, level 2).


Flat




level 1



level 2



2. Place the memory foam into the frame slot




3. Open the two baffles at the bottom.




4. Lay the laptop flat on the memory foam and hold it in place with the baffles.

5. Connect the adapter to the cooler and long press the power button for 2 seconds to turn it on.




6. After powering on, adjust to the appropriate cooling speed (roller speed adjustment: "+" to increase airflow, "-" to decrease airflow. The initial speed is 300, and it increases by 100 rpm for every level from 300-2800).



7. ⏻ Long press the power button for 2 seconds to turn off.


8. Data Transfer

- One Type-C port is the data input port.
- Three USB-A ports are data output ports.



9. Replace the dust filter cotton.

- Open the dust cover.
- Remove the dust filter cotton.
- Replace the dust filter cotton.
- Close the dust cover.
- Depending on the individual usage scenario and environment, it's recommended to replace the dust filter cotton every 3-6 months.



Warranty Card

For your rights and interests, please fill in the details and keep it properly. This copy is used as a proof before maintenance:

User name:

User address:

Postal code:

Contact number:

E-mail:

Purchase date/order number:

Return reason:

--

Product after-sales warranty service: 365 days

(Note: gift accessories are not covered by the warranty)