Download APP

ACEFAST

GET IT'ON Google Play

Google Play and the Google Play logo are trademarks of Google Inc.

Download on the App Store

Apple and the Apple logo are trademarks of Apple Inc.

EN: More functional settings can be explored after downloading the APP. Search for 'ACEFAST' in Apple APP Store or Google Play to download APP.

RU: После загрузки приложения можно исследовать дополнительные функциональные настройки. Чтобы скачать приложение, найдите "ACEFAST" в магазине приложений Apple или Google Play.

ES: Una vez descargado el APP, puede explorar configuraciones funcionales adicionales. Busque "ACEFAST" en la tienda de aplicaciones Apple o Google Play para descargar el APP.

DE: Nach dem Herunterladen der APP können weitere funktionale Einstellungen erkundet werden. Suchen Sie im Apple APP Store oder Google Play nach 'ACEFAST', um die APP herunterzuladen.

IT: Dopo aver scaricato l'APP, è possibile esplorare ulteriori impostazioni funzionali. Cerca 'ACEFAST' sull'Apple APP Store o su Google Play per scaricare l'APP.

PL: Po pobraniu aplikacji można rozważyć więcej ustawień funkcjonalnych. Wyszukaj "ACEFAST" w sklepie aplikacji Apple lub w Google Play, aby pobrać aplikację.

FR: Après avoir téléchargé l'application, vous pouvez explorer d'autres paramètres fonctionnels. Recherchez "ACEFAST" dans l'Apple APP Store ou sur Google Play pour télécharger l'application.


JP: 専用アプリをダウンロードすると､より多くの機能設定が可能になります｡Apple App Store や AndroidのApp Store で｢ACEFAST｣を検索するとダウンロードできます｡

ZH: 在下载应用程序后，可以探索更多功能设置。在 Apple APP Store和国内各大安卓市场搜索"ACEFAST"均可下载。

AR: بعد تحميل التطبيق ، يمكن استكشاف المزيد من الإعدادات الوظيفية. ابحث عن "ACEFAST" في متجر Apple APP أو Google Play لتنزيل التطبيق.

UA: Після завантаження додатку можна досліджувати більше функціональних налаштувань. Шукайте «ACEFAST» в магазині додатків Apple або Google Play, щоб завантажити додаток.


Product information (EN)



1. Main mic inlet sound hole
2. Earbuds charging pins
3. Speaker rear sound hole-1
4. Speaker sound hole
5. Charging case
6. USB-C charging port
7. Charging case status indicator
8. Speaker rear sound hole-2
9. Multi-function key
10. Sub-mic inlet sound hole
11. Earbuds status indicator

*Device activation:
For first time use, you need to take the earbuds out of the charging case, tear off the insulation sticker on the charging contacts of the earbuds, then put the earbuds into the charging case and close the cover, then open the cover again, the activation is complete when you see the earbuds light on.
Please charge the earbuds first when the power is low.

Product list




Earbuds × 2 | Charging case × 1 | C to C charging cable × 1 | Manual × 1

Parameter / Product list

BT pairing name: ACEFAST ACEFIT Air	Charging case battery capacity: 500mAh, 3.7V/ 1.85 Wh can charge 3 times
BT version: BT 5.4	Earbuds charging time: Approx 1 hour
Audio decoding protocol: SBC / AAC	Charging case charging time: Approx 2 hours
Transmission distance: 10m	Charging port: USB-C
Speaker type: Ultra-Linear Multi-Circuit Moving Coil	Charging case input: 5V ⎓ 0.7A
Speaker size: 20×8mm	Earbuds size: Approx 49 x 29 x 20mm
Speaker sensitivity: 90±2dB	Overall size: Approx 78.9×62.6×24.0mm
Frequency response range: 50Hz~20kHz	Earbuds weight: Approx 7.5g for one earbud
Music playback time: Approx 6 hours (at 60% volume)	Overall weight: Approx 54.8g
Earbuds usage time after 10 minutes of charging: 2 hours (Music)	Material: ABS+PC+Silicone
Talk time: Approx 5 hours (at 60% volume)	Waterproof: IP54
Total working time: Approx 25 hours	Operating frequency range: 2400-2483.5MHz
Earbuds battery capacity: 60mAh	RF output power: ≤20dBm(EIRP)


Instructions for use

The left and right earbuds are paired successfully by default when the product leaves the factory. Follow the steps below when connecting to the phone for the first time.
1. Take out the earbuds to automatically turn on, wait for about 3 seconds, the earbuds will be automatically paired.
2. Turn on the BT of your phone, search for ACEFAST ACEFIT Air and click to connect. After the pairing is successful, you will hear a tone and your phone will show that it is connected.
When you use it again, after the earbuds is turned on and paired, it will automatically connect back to the connected mobile phone. If you cannot connect to the mobile phone, please manually connect to the earbuds from the BT menu of the mobile phone.



Prompt:
*When earbuds connected to the device, in order to avoid the failure of the connection between the left and right earbuds, keep both earbuds in the case with open cover, or take out both earbuds at same time to ensure that both earbuds are turned on.
*You have 5 minutes to connect the earbuds and your device, otherwise the earbuds will automatically shut down. Put the earbuds back into the charging case to re-enter pairing mode.
*Power on without any device connected, it will automatically shut down after 5 minutes.
*The left and right earbuds can be used separately.
*If the pairing fails for a long time, please put the earbuds back into the charging case for reconnection.
*If there is no sound after the left and right earbuds are connected, please put the earbuds back into the charging case for reconnection.

Operation mode



Calls:
1) Power On: Opening the charging case lid automatically powers on the earbuds.
2) Power Off: Placing the earbuds into the charging case and closing the lid automatically powers off the earbuds.
3) Answering Calls: When receiving a call, double-click the multi-function key.
4) Ending calls: Double click the multi-function key during a call.
5) Rejecting a call: When an incoming call comes in, press and hold the multi-function key for 2 seconds.
6) Cancel dialling: During a call, double-click the multi-function key.

Playing music:
1) Playing music: Double-click the multi-function key or operate the music player on your phone (some phones automatically start the music player when connected to BT stereo).
2) Pausing music: Double-click the multi-function key while playing music or operate the music player on your phone.
3) Next track: Triple-click the right earbud multi-function key while playing music.
4) Previous track: Triple-click the left earbud multi-function key while playing music.
5) Volume +: Click the right earbud multi-function key.
6) Volume -: click the left earbud multi-function key.
7) Voice assistant wake-up/exit: Long press the multi-function key for 2 seconds.
Restore factory settings: both earbuds in the charging case and the lid is open, press and hold left and right earbuds multi-function keys for 3 seconds at the same time to clear the phone pairing record.

*Due to the characteristics of BT earbuds, electromagnetic wave interference in the area may cause connection interruptions or freezes. Based on the characteristics of wireless technology, when the device performs the display function and transmits the BT sound signal at the same time, there may be a "delay" in the audio signal and the video signal, that is, the sound is not synchronized with the picture.
*For more function definitions, please set them up in the APP.

Charging case charging:
LED is flashing during charging: Open lid condition:
LED breathes continuously during charging
When fully charged, LED is always on
LED off when cover is closed
The charging case is not charged, the lid is opened:
≥1% power, the LED flashes once
= 0% power, LED flashes continuously and fast, 2 times per second
When the power of the charging case is =0%, the charging case does not charge the earbuds, only supports switching the earbuds on and off.

Precautions for charging:
Use a charger with an output voltage of DC 5V, a USB port of a PC (must choose a charger that has been certified by a manufacturer).

Tips:
This product contains a built-in rechargeable lithium battery, please read battery safety warnings.
It is forbidden to hit, squeeze or throw into fire. If severe swelling occurs, please do not continue to use it. Do not place it in a high temperature environment. It is forbidden to use the battery after it is immersed in water.
Do not try to remove the battery from the earbuds to avoid damage to the earbuds.
The earbuds will automatically consume power when it is shelved. It is recommended to charge the earbuds every 3 - 6 months.

Precautions
● Do not leave the earbuds in a damp, dusty, greasy or steamy place, or exposed to direct sunlight. Do not leave the earbuds in the car for a long time. Failure to do so may result in malfunction.
● Listening at high volumes with this earbud may affect your hearing. For traffic safety, do not use this earbuds while driving or cycling.
● Do not use the earbuds in places where it would be dangerous not to be able to hear ambient sounds, such as railway crossings, railway station platforms, pedestrian crossings and construction sites.
● Do not place heavy objects or apply pressure on the earbuds, as this may cause them to deform during long-term storage.
- Be careful not to drop the earbuds into a sink or other container filled with water.
- Do not use the earbuds in wet places or in bad weather such as rain or snow.
- Do not get the earbuds wet. If you touch the earbud with wet hands or place the earbuds in damp clothing, the earbuds will get wet, which may cause the earbuds to malfunction.
● Keep this product away from electronic products such as bank cards, mobile phones, computer monitors, televisions, etc., as it is magnetic.
● If you feel uncomfortable after using the BT device, stop using it immediately. If the problem persists, contact your local dealer.
● If you have any questions or problems with earbuds not covered in this manual, contact your local dealer.

FCC

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

IC Caution:

This device complies with Industry Canada's licence-exempt RSSs. Operation is subjectto the following two conditions:
(1) This device may not cause interference; and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
The device has been evaluated to meet general RF exposure requirement. The device can be usedin portable exposure condition without restriction.

Le présent appareil est conforme aux ZHR d'Industrie Canada applicables aux apparei ls radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radio électrique subi, méme si le brouillage est susceptible d'en compromettre le fonctionnement.

L'appa reil a été éval ué pour répondre aux exi gences générales d'exposi t ion R F. L'appa reil peut être util isé dans des conditions d'exposit i on port abl es sans restriction.

Warranty

Subject to the following terms and conditions, ACEFAST will provide consumers with a three-year warranty for any quality problems caused by raw materials or the production process.
1. These terms and conditions only apply to ACEFAST products sold in mainland China.
2. These terms and conditions only apply to consumers who own ACEFAST products through purchase or other legal means (hereinafter referred to as consumers).
3. Consumers should read the product manual in detail before using the product.
4.Warranty service is only limited to under normal circumstances within the effective warranty period (no date of purchase to the date of production shall prevail), due to product quality problems caused by non-man-made damage to the fault, with the invoice and warranty card will enjoy the following services.
4.1) Within seven days from the date of purchase, consumers can enjoy free return, exchange or warranty service at the original purchase place.
4.2) Within 15 days from the date of purchase, consumers can enjoy free exchange or warranty service at the original place of purchase.
4.3) Within 18 months from the date of purchase, consumers are entitled to free warranty service at our designated repair points.
5. The following conditions are not covered by the three guarantees:
5.1)All human factor damage, including failure and damage caused by use in non-normal working environment, use not in accordance with the instructions or use in an environment not in accordance with the instructions;
5.2)Without the consent of the Company, the user privately dismantles, repairs and modifies the machine by himself;
5.3)Natural wear and tear of the product and its resulting periodic inspection, maintenance, repair or replacement of parts.
5.4)The contents on the valid invoice and warranty card do not match the actual product or are altered;
5.5)Damage to the barcode of the body.
5.6)Damage caused by force majeure.
6. After the expiration of the three packages of service, or in the three packages of the period but does not belong to the scope of service, the company can provide paid maintenance services.
7. If there is any inconsistency between the warranty description of this product and the national three packages, the national three packages shall prevail.

Model: FA001 Date:
Code: Number:
Name: Phone:
Add:

Product maintenance records

Repair date	Repair number	Maintenance records	Signature

Warranty & Customer Support
For questions, support, or warranty claims, contact us at the mail below.
Support@acefast.com

*Please note, ACEFAST can provide after sales service for products purchased from any official ACEFAST store. If you have purchased from local seller, you can also contact them directly for service or warranty issues.

Shenzhen Houshuxia Technology Co., LTD
www.acefast.com | support@acefast.com
Shenzhen, 518000, China

Brand: ACEFAST
Shenzhen Houshuxia Technology Co., LTD
Address: Rm203, 2nd Floor, Building C, Youth Pioneer Park, Jianshe East Road, Tsinghua Community, Longhua Street, Longhua District, Shenzhen, P. R. China
中国制造 Made in China