Sdpeia

360 photo booth product

Instructions for use



Catalogue

1.Caution 01

2.Component Introduction.....01

3.Installation guide 02

4.Operation Instructions.....08

1、Caution

1、The power plug is used as a disconnecting device for this product. To completely disconnect the power input, the power plug of the product should be unplugged from the power supply.
2、The product's power plug should be within reach, or should be easily unplugged when it needs to be used.
3、Making changes or modifications to the product may make it impossible to operate this device.
4、Please do not go up and down the platform during the product rotation to avoid accidents.
5、Before using, please check whether the power cord, base LED Strip cord and other items are stuck on the rotating table or not, to prevent the cables from being damaged.
6、For users safety, don'tjump hard on the Stage.
7、Don't make the edge of the Stage bear too much weight, better distribute the weight evenly on the stage.
8、The Stage should be adjusted paralleled to the ground by rotating the foot cup before using.
9、Do not stop the rotating rod deliberately when it was running.
10、Do not put heavy objects on the Angle Adjuster and Selfie Telescopic Rod.
11、Children should not use it alone, but must be accompanied by an adult
12、Pls take off the foot cups when put the photo booth into the flight case fbr transportation.

2、Component Introduction

Accessory products are as follows
1、Tablet Holder
2、Mobile Holder
3、Metal Bracket
4、Fixed Bracket
5、Rgb Ring Light
6、Platform Base
7、Fixing Screw
8、Angle Adjuster
9、Rotary table connecting rod
10、Selfie Telescopic Rod
11.、LED strip light control line
12、AC-DC Adapter
13、Remote control
14、Money Gun
15、LED Strip
16、Storage bag
17、LED strip remote control
18、LOGO Sticker



Tablet Holder



Mobile Holder



Metal Bracket



Fixed Bracket



Rgb Ring Light



Platform Base



Fixing Screw



Angle Adjuster



Rotary table connecting rod



LED strip light control line



AC-DC Adapter



Angle Adjuster



Remote control



Money Gun



LED Strip



Storage bag



LED strip remote control




LOGO Sticker

3、Installation guide

Step 1: Take the Stage out of the package, install all the 8 Foot Cups and adjust the Stage parallel to the ground.



Step 2: Stick the LED Strip to the base and connect it to 5V Adapter (for LED Strip).




Step 3: Install the Angle Adjuster, and lock it with Fixed Screw.




Step 4: Install the Selfie Telescopic Rod.



Step 5: Install RGB Ring Light.



Step 6: Install Fixed Bracket and Phone Holders.



Step 7: Power bank, lithium battery connection and usage (Power Bank and lithium battery are not our standard accessories).
The RGB Ring Light should connect with USB port of the power bank. The motor controller should connect with the lithium battery s DC 24V power port. And the LED strip should connect with the lithium battery s DC 5V USB port.Then connect the AC-DC adapter to the Motor Controller.



RGB Ring Light

This product is key control to control the light, five buttons are three color mode (three color mode contains warm light, normal light, cold light), RGB mode, brightness plus, brightness minus, switch, three color mode has four models, respectively, 3000K, 6000K, 3000K and 6000K together with light off, RGB Ring Light has 41 color modes

Warm Light



Normal Light



Cold Light



Color Light



1、RGB Ring Light USB connectio with Power Bank.
2、Brightness Increase Button
3、Brightness Decrease buRon
4、Power Button



4、Operation Instructions

nstall suitable batteries for all remote controls.
Power up the AC-DC adapter.
Plug the two USB(Ring Light& LED Strip) into the power bank and 5V adapter.


Remote Control Instructions

Suitable batteries are 23A Alkaline Battery
- ON/OFF
- Change Direction
- Speed Up
- Speed Down



LED strip remote control Instructions

Suitable batteries are **CR-2025**



Operation Instructions of Controller

1. Specifications:

Working temperature	-20-60°C
Supply voltage	DC5-24V
Product size	L62xW35xH23mm
Packaga size	L105xW65xH55mm
Net weight	60g
Gross weight	70g
Output	Three CMOS drain-open output
Connecting Mode	Common anode
Max load current	2A each color

2. Control Method

Adopt IR remotre to control the led controller , which has 24 buttons,the function of each button as the table below

Brightness +(Speed up)	Brightness -(Speed down)	Off	On
BrighStatic red	Static green	Staffe blue	Static white
Static orange	Static Pea green	Static dark blue	7 color jumpy change
Static dark yellow	Static cyan	State brown	All fade out&fade in
Static yellow	Static light blue	Static pink	7 color fade change
Static straw yellow	Static sky blue	Static purple	3 basa color jumpy


3、Panel specification and connecting drawing as follows:

LED CONTROLLER

With Remots Control

Peak Output Current:3*4A

Common Node



Warning

1. Supply vlotage of this product is DC5-24V never connect to DC24V or AC220V.
2. Never connect two wires directly in case of short circuit
3. Lead wire should be connected correctly according to colors that connecting diagram offers.

Actual rendering





360 photo booth product

Support@sdpeia-global.com