

INSTRUCTION MANUAL

Nutri-blend CKM

Complete Kitchen Machine

2
YEARS
WARRANTY
230V-50Hz, 400W



 **ISTITUTO ITALIANO DESIGN**
PERUGIA
WONDERCHEF Design Partner

 **22000 RPM**
• Mixer • Grinder • Blender
• Juicer • Chopper



Thank you for purchasing the **WONDERCHEF “Nutri-blend CKM”**.
Please read these instructions carefully before your first use of this product.


IMPORTANT SAFE GUARDS

1. Make sure your electricity supply is 230V-50Hz.
2. Use the unit only as described in this manual.
3. To prevent from electrical shock, do not immerse the motor base and the cord set into water.
4. This is not a toy. Close supervision is required when the unit is used by or near children.
5. This unit is intended for household use only. Do not use the unit at outdoors or for other purpose than intended.
6. Never leave the unit unattended while it is in operation. Avoid contacting with the moving parts.
7. Ensure to unplug the unit when not in use, assembling or disassembling, and before cleaning.
8. The use of attachments, including the jars, not recommended by the manufacturer may cause a risk of injury to persons.
9. Blades are sharp. Handle with care.
10. Do not place the unit near any explosives, heated oven or hot surfaces.
11. Place the unit on a flat heat-resistant surface.
12. Do not let the cords hang over the edge of table or the like.
13. Please hold the plug to disconnect from the power socket.
14. Do not run the unit continuously for longer than 1 minute at a time. Wait at least 3 minutes before running the unit again.
15. This unit is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.


NOTE :

To avoid danger of electric shock, unplug the unit from outlet when not in use or before cleaning. If the supply cord is damaged, stop to use immediately and bring it back to service centre for repair.


PARTS DIAGRAM




Chopper Lid



Pusher



Short Jar




Chopper Blade




Lid




Blade for Grinding




Chopper Bowl




Big Mixer Jar Lid



Tall Jar




Gear Box




Juice Extractor Mesh



Blade for Blending



Main Unit



Big Mixer Jar



Stay Fresh Lid



Seasoning Lid

FIRST USE

1. Remove all packaging materials and labels.
2. Clean the motor base and the parts thoroughly before use
(See "Cleaning and Maintenance")
3. Plug in the unit into the power outlet, the unit is now ready for use.

OPERATING INSTRUCTIONS

1. Plug the unit into a proper power socket at 230V—50Hz.
2. The unit is designed with a built-in safety system. If the Jar is not securely locked into the motor base, the unit will not function.
3. The Nutri-blend can be used for blending or grinding. You can use the unit with different modes as below :

A. Blending:

1. Put the prepared fruit (eg. apple, carrot, kiwi, strawberry, etc.) into the Tall Jar.
2. Cover the Tall Jar with the blade for blending (Fig. 1)
3. Put the Jar onto the motor. Make sure the Ledges of the Jar are in correct position on two grooves of the motor base. (Fig. 2)
4. Push down the Jar and turn it clockwise to lock into the motor base (Fig. 3).
The unit starts operating.
5. When the blending is completed, turn the Jar anti-clockwise to release from the motor base (Fig. 4). The operation will stop.
6. Take out the Jar and open the blade holder. Pour the blended juice into a container and serve.
7. Or you can cover the Jar with the Lid (Fig. 5). Keep in the refrigerator for serving later.



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5

OPERATING INSTRUCTIONS

B. Grinding:

1. Put the prepared ingredient (eg. coffee bean, soya bean, rock sugar, sesame, etc.) into the Short Jar.
2. Cover the Short Jar with the blade for grinding (Fig. 6)
3. Put the Jar onto the motor. Make sure the Ledges of the Jar are in correct position on two grooves of the motor base. (Fig. 7)
4. Push down the Jar and turn it clockwise to lock into the motor base (Fig. 8). The unit starts operating.
5. When the grinding is finished, turn the Jar anti-clockwise to release from the motor base (Fig. 9). The operation will stop.
6. Take out the Jar and open the Blade holder. Pour the grinded food into a container and use.
7. Or you can cover the Jar with the Seasoning Cap for use directly (Fig. 10).



Fig. 6



Fig. 7



Fig. 8



Fig. 9



Fig. 10

NOTE :

1. The blades are sharp. Please handle with care.
2. Do not run the unit continuously for longer than 1 minute at a time. Wait at least 3 minutes before running the unit again.
3. Do not overload the Jar with food. Maximum loading capacity for Short Jar is 200gms and Tall Jar is 300gms - Dry/Wet Grinding & 350ml - Liquid Blending.

C. Big Mixer Jar

The Big Mixer Jar is ideal for blending in large quantity like milkshake, juices, ice crushing. The lid attachment makes filling the ingredients easier, hold the jar from top while operating. Stop the operation before opening the jar (Fig. 11).




Fig. 11

D. Juicer Attachment & Pusher

Both of these parts make a juicer attachment out of your mixer. Put the Juicer attachment into the mixer. Now shut the mixer with the lid. Cut the fruits into small pieces. Switch on the unit and put the fruits through the small opening of the Juicer attachment. Use the pusher to press down the fruits. Switch off the unit and pour the juice (Fig. 12).




Fig. 12

E. Chopping:

- 1) Insert the blade into drive shaft of container and ensure it is fixed in the right place as shown in the Fig. 13
- 2) Cut the ingredients into four half and put into the chopper bowl. Filled capacity should not exceed 2/3 capacity of the bowl.
- 3) Put on the chopper cover, then press it and rotate it clock wise to lock
- 4) Fix the chopping bowl attachment with main motor unit and the plug in the power cord in socket, machine will start chopping the ingredients.
- 6) After chopping, turn off the main switch and also plug off, take out the chopping bowl attachment and open chopper cover, take out the food.
- 7) Please do according to the above information, if need reuse.




Fig. 13

CLEANING AND MAINTENANCE

1. Unplug the unit before cleaning.
2. Take off all the parts and clean under the running water (Fig. 14). Rinse and dry.
3. Do not immerse the motor base and power cord set into water (Fig. 15). Clean the motor base with a damp cloth and wipe it dry (Fig. 16).



Fig. 14



Fig. 15



Fig. 16

NOTE :

1. Do not immerse the motor base and power cord set into water.
2. The Blades are sharp. Handle with care and patience.
3. Make sure the blades are thoroughly dry after each cleaning in order to avoid furring.
4. Cleaning is required after each operation.


WARNING

Blending




Tall Jar with "+" Blade

Grinding



Short Jar with "-" Blade

Blending



Short Jar with "+" Blade

Grinding



Tall Jar with "-" Blade

Picture 1

Picture 2

STORAGE

1. Follow above Cleaning Instruction to well maintain the unit before storage.
2. Tidy up the power cord.
3. Keep the unit away from children's easy access.
4. Store the unit and the accessories at a dry, cool place.

SPECIFICATIONS

RPM: 22000

Voltage: 230V~50Hz

Power: 400W

Protection against electric shock:

Class II

IP20

Model Codes:

Black: WCNBD02B2CKM01

White: WCNBD02B2CKM02

Red: WCNBD02B2CKM03

Champagne: WCNBD02B2CKM06

PARTS & CAPACITY CHART

Type	Jar Capacity	Usage	Dry / Wet Grinding		Liquid Blending	
			Loading Capacity (Min)	Loading Capacity (Max)	Loading Capacity (Min)	Loading Capacity (Max)
Big Mixer Jar	1150ml	Blending	NA	NA	250ml	1000ml
Tall Jar	500ml	Blending	200gms	300gms	250ml	350ml
Short Jar	300ml	Grinding	100gms	200gms	NA	NA
Chopper	600ml	Chopping	250gms	400gms	NA	NA

IMPORTANT :

1. The unit is designed for household use only.
2. Commercial users will not obtain the regular warranty as stated in the terms of the warranty card.

