

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate www.vevor.com/support

JUICE MACHINE

MODEL: NS2000E-2T

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR®

TOUGH TOOLS, HALF PRICE

JUICE MACHINE

MODEL: NS2000E-2T



NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

	Warning-To reduce the risk of injury, user must read instructions manual carefully.
	Indoor Use Only
	CORRECT DISPOSAL This product is subject to the provision of European Directive 2012/19/EC. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should be followed, including the following.

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

1. There shouldn't be anything else on the counter.
2. There is no abnormal phenomenon after the power is switched on .
3. It must be placed on the horizontal plane in order to avoid danger due to shaking back and forth during use.
4. Do not plug the power cord into the socket when not in use. Please unplug the power cord after use and before cleaning or maintenance.
5. Please unplug the power of the machine before cleaning, assembling or disassembling.
6. Do not place the product in the reach of children. Children should be supervised to ensure that they do not play with the appliance.
7. This appliance can be used by children aged from 8 years and above

and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

8. Don't unplug the machine before it stops operation.

9. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

10. Electric Shock Danger! Non-professional personnel are forbidden to repair the products, otherwise it may result in electrical shock. When failures happen, it should be repaired by a qualified maintenance personnel.

11. WARNING! It is strictly prohibited to put the main body into the water to clean. Only can be scrubbed with wet towel. The machine must be fully cool before cleaning.

12. Please check that the specified supply voltage in the product is consistent with the supply voltage(AC only).

13. Avoid power cords damage. Do not squeeze, bend or friction it, keep it away from heat sources and open fires. Power cord do not touch the blade.

14. Power cord should be laid flat. Do not pull the power cord and make the product fall down, which may cause damage.

15. Do not use the product on wet ground. Do not touch the product or power cord plug with wet hands.

16. Do not disassemble the product at will. Do not let something enter or insert into the product, which may cause damage.

17. Only accessories provided by the seller or manufacturer can be used for the product. We will not be responsible for any failure caused by the use of accessories from other manufacturers, which are not covered by warranty.

18. Do not use the product on uneven, damp, not heat-resistant surfaces to avoid damage or failure.

19. Do not place the product directly on the fire or near the source of fire, otherwise the product will be damaged or even result in danger.

20. When the plug is plugged into the socket, it must be plugged to the end, otherwise it will cause the components overheating and burning due to poor contact.

21. Do not leave the product to work with no one watching. If the machine is overheating, please stop working immediately and unplug the power.

22. Once part of the product is on fire, do not directly use water to extinguish the fire. Use a wet cloth to cover the fire site.

23. Please store the plastic bags and not allow children to play with them to prevent a risk of suffocation.

24. It is prohibited to put the main body of the machine and the power cord into any liquid.

SAVE THESE INSTRUCTIONS

The juicer is made up of stainless steel shell, trans-parent plastic cover, food-grade plastic parts (Convex ball and Concave ball) and remaining collector. The structure is well-organized and rational. It is anti-corrosion, easy to wash. It could produce fresh and delicious juice in a few seconds after operation. It is an ideal machine to make juice and widely used in entertainments, restaurants and hotels.

Φ40~Φ80mm oranges suitable for the juicer. The operation is simple and convenient. The juicer is small and easy to operate, it can produces instantly. The juice is original and tasty, green and trendy.

Please Read the Direction Before Operation:

1. Technical Parameters:

Auto Orange Juicer

1. Power Supply: 220V 50~60HZ/110V 60Hz

2. Power: 120W

3. Size of orange: 40-80mm

4. Output: 20 Oranges/Minute

2. Before operation:

1. The power supply must have the safety grounding system, and the


machine connection parts shall not be changed by self.

2. Check whether all parts are installed well. This product is equipped with safety system, only after the machine mask is correctly installed, it can work (whether the safety switch button is compressed), and otherwise it is difficult to start the machine.


3. Before first time using the product, please thoroughly clean the parts which contact with the food.

3. Operation process:


1. Put the juice storage container on the tray of the base (orange juicer 2000E user should self provide the juice container).




2. Put the fruit peel bucket in the two sides of the bottom of the machine body.




3. Pour the cleaned orange into the machine fruit basket.



4. Switch on the machine and prepares work.




5. Pressing the start switch (white 220V) or(green 110V) can feed the orange continuously into the feeding port (2000E needs artificial feeding), after out of the juice, the fresh orange juice will be discharged, and the fruit peel is automatically separated to enter into the fruit peel bucket.




6. When feeding, please do not insert the fingers or other objects into the

feeding port. If the juice storage container or the fruit peel bucket is filled up, switch off the power supply and then clean it.




7. After the use of this machine is completed, turn off the switch, disconnect the power supply.







4. Maintenance and cleaning:

1. Before cleaning the product, the start switch must be turned off, disconnect the power supply, wait until the machine stops completely.
2. Clean the product immediately after using.
3. The external of the main body can be wiped with wet cloth, please do not wash it with water directly, and the unloaded parts can be directly put into the water to clean.
4. Refer the following the steps below to disassembly the parts to clean:
(1) Unscrew the cover screw, take down the cover.



(2) In turn take down the knife combination (be careful the blade cutting hand), two groups of scraper combinations, unscrew the four screws, take down the two groups of concave and convex balls (each group of the concave and convex balls needed to be taken out at the same time).





(3) After the cleaning of the product is completed, re-install each part in the opposite order (especially pay attention whether the safety switch button is pressured).

5. Production troubleshooting and maintenance instruction

(1)Electrical fault

1. The safety switch does not work:

- (1) Check whether the safety switch is in good condition;

(2) Check whether the safety switch is in the closed state.
For orange juicer 2000E, pressure safety switch button form the top of the cover .

2. The starting switch does not work:

- (1) Check whether the starting switch is in good condition;
- (2) Check whether the starting switch socket end is plugged.

3. Motor does not work:

- (1) Check whether the socket at the two sides of the power line is tightened;
- (2) Check whether the fuse is in good condition;
- (3) Check whether the terminal in the motor switch box is solid connection.

(2) Mechanical failure:

1. The motor output shaft end bevel gear wheel transmission mesh:

- (1) Check whether the size of bevel gear wheel is damaged;
- (2) Check whether the meshing positions of the big and small bevel gears wheel are correct, the adjustable small bevel gears wheel is rising to the correct meshing position and tighten the hex screws on the gear(when the small bevel gear wheel on the motor shaft position is moved down).

2. The damage of transmission cylindrical gear


- (1) The size of transmission cylindrical gear is divided into a pair of large cylindrical gear ($Z = 52$), a pair of small cylindrical gear ($Z = 39$).
- (2) Iron gear is generally is tooth form damage
- (3) If the cylindrical gear transmission has abnormal sound, it can be judged that the cylindrical gear is damaged, in the initial stage of the gear damaged, the machine work must be stopped immediately, the damaged gear must be replaced, otherwise it will affect the relative position of the working parts of machine, thus aggravates the damage of the gear, and until damage the electrical machine and the working surface of the and concave and convex balls.

Replace the method of cylindrical gear:

A. Remove the damaged cylindrical gear and the elated parts according to

the assembly sequence

B. Use two square hole templates lock the upper two of four corner angle shaft parallels(figure 1), and then install two big cylindrical gears



(figure1)

C. Remove the two square hole templates.

D. Use one square and a triangle template to lock the left (or right) upper four corner angle shaft and lower triangular shaft (figure 2) under the ridge axis, and then install the small cylindrical gear.



(figure 2)

E. The installation method of the other side of the small cylindrical gear is the same as D.

Address : Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu, shanghai 200000 CN.

Imported to USA: Sanven Technology Ltd. Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730

Imported to AUS: SIHAO PTY LTD. 1 ROKEVA STREETEASTWOOD NSW 2122 Australia

UK	REP
----	-----

E-CrossStu GmbH.
Mainzer Landstr.69, 60329 Frankfurt am Main.

EC	REP
----	-----

YH CONSULTING LIMITED.
C/O YH Consulting Limited Office 147, Centurion House,
London Road, Staines-upon-Thames, Surrey, TW18 4AX

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support