

VESA-1



Supplied Parts List



VESA Plate
(x1)



Nut
(x1)



Allen Key
(x1)



M4x12 Bolt
(x4)



M4x30 Bolt
(x4)



Spacer
(x4)

Step 1

Step 1.1


Select TV Screws

Only one screw size fits your TV

M4x12 M4x30




Hand thread screws into the threaded inserts on the back of your TV to determine which screw diameter (M4x12 or M4x30) to use.




Step 1.2

Select Spacers (if needed)


NOT NEEDED



NEEDED FOR




Step 1.3a



For Monitor with Flat Back

Step 1.3b



For Monitor with Curved or Recessed Back



Thank you for choosing us!

We support the technology that brings your home to life.
We offer high quality products, professional customer service,
and extensive technical support.

If you have any questions, please contact us.

 1-844-SATTLER (18447288537)

 support@wallelectric.com

 www.wallelectric.com