


Product Information


Product Overview



English 1

Product Information

Packing List




English 2

Quick Start Guide


1. Open the case, take out the earbuds, remove sticky tapes on the back of earbuds.



Attention
Please tear off the protective film before use, otherwise the headset will not be charged.




2. Put back the earbuds into the case, make sure the lights of earbuds are on.




English 3

Quick Start Guide

3. Turn on the Bluetooth of smartphone to search the Bluetooth device.
4. Find the device name of "YHM Q2", connect it.



5. Wear the earbuds as shown below, enjoy it!



English 4

Quick Start Guide

Power on/off



On	Open the case cover, take earbuds out of charging case, they will automatically power on.
Off	Put the earbuds back into charging case, they will power off automatically. If the earbuds are not connected to your device over 5minutes, the earbuds will power off automatically.

English 5

Quick Start Guide

Bluetooth Connection

Hall Switch Makes More Convenience	
Case Cover Opened, Bluetooth connected.	Case Cover Closed, Bluetooth disconnected.



Return to Connect

YHM-Q2 Earbuds Bluetooth has memory function, it usually auto connects with the last paired device.

Clear Paring

Method 1: 4 continuous clicks on L/R earbuds and hold for 5s, earbuds will be disconnected and powered off. Paring record will be forget on current device.

Method 2: Manually remove/forget record on the last device paired.

Reset the Earbuds

Place the twin earbuds back to the charging case, shut down the case cover, and then open the cover, the earbuds white lights blink means reset is completed.


If the phone claims "Connection Unsuccessful", please forget all [YHM-Q2] records on your phone, then click to search and select [YHM-Q2].

English 6



Email: support@yuehemei.com
Web: www.yuehemei.com


Operation Instructions for earbud buttons



English 7


Quick Start Guide

Charging




*Charging the charging case properly with type-c cord.

- Prior to first use (or not in use for longtime), please charge both earbuds and charging case fully.
- If earbud's battery is lower than 20% (and the voltage is below 3.4V), you will hear alert tone several times and then "power off" in turns. The fully charged charging case can recharge twins earbuds for about 4 times without being plugged into power supply.



Earbud's Charging: Earbuds placed in, case closed, white light keeps on means "being charged", white light goes off means "fully charged".



Charging Case Charging: Red light flashes means "being charged", red light keeps on means "fully charged". If charging case is in low battery, white light flashes.

English 8

Specification Parameters

Bluetooth Version	BT5.3BLE
Bluetooth Chip	6983D4+ AW8010
Transmission Range	About 33 feet Max.
Frequency Response Range	20Hz-20kHz
Horn Size	16.2mm
Horn Impedance	16Ω
Headphone size	48.9*43.3*18.6mm
Charging Case Size	96*61.7*31.3mm
Earbuds Battery Capacity	50mAh x2
Charge Case Battery	3.7V/400mAh/DC 5V
Charging Port	Type-C
Button	Fingerprint Touch
Mono Earbud Mode	√
Game mode	√
Voice assistant	√
Music Time	About 6 Hours
Phone Call Time	3-5 Hours
Charging Time	1.5 Hours

English 9

Security Information

- Using a charging cable that is not approved by the manufacturer may cause fire, explosion or other dangers.
- Do not dismantle or repair or modify this product for any reason, otherwise it may lead to fire electronic breakdown or even complete damage to this product.
- Please use this equipment in the temperature range of 0°C~35°C, and store the equipment and its accessories in the range of -10°C~45°C. When the ambient temperature is too low or too high, it may cause equipment failure. When the charging temperature exceeds the temperature range, it can't be charged after flashing for 3 times.
- If charging is finished, please disconnect the charger from this product, and the continuous charging time should not exceed 12 hours.
- Please don't wet the product with liquid or soak it in liquid.
- This product is built-in with a non-removable lithium battery. It is forbidden to disassemble, impact, squeeze or throw the battery into the fire. If there is serious expansion, please do not use it intermittently.
- Do not put the magnetic charging cable or the magnetic charging port of the earphone near the metal object. The magnet is attracted to the metal object, which may cause the contact to be shorted and lead to danger, so as to avoid personal injury such as scald and burn caused by overheating of the battery.
- Do not put this product or battery into fire, otherwise it will cause fire or explosion.
- Don't expose the earphone to the sun for a long time, otherwise it will be easily deformed, aged and broken.

English 10

YUEHEMEI

OPEN WIRELESS STEREO

YHM Q2 | MANUAL

