


angels Horn


Quick Start Guide HP-H002





Installation





































Operation






















Stop the turntable











Note:

When the record is played to the end, it will enter the inner closed loop and continue to rotate, and you need to manually raise the tonearm to stop it.