Please refer to this manual before using the product

Thank you for buying NoiseFit Endure

Some functions may vary in certain versions of the

- Please charge the Noisefit Endure with the provided charger for 2.5 hours before use.
- 2. The NoiseFit Endure is IP68 waterproof rating. It can't be used under corrosive liquids or hot water, tea, etc. Meanwhile, it cannot be used during deep-sea diving over 3 meters.
- 3. Please download Da Fit app for using the NoiseFit Endure smartwatch.

Some smartphones may turn the app off in the

background by locking/whitelisting the app in

background (only in Android)

background. Please ensure the app is running in the

- Please ensure that there is no space between the watch and your wrist to ensure accuracy of health
- Please avoid collision with hard objects as it may break

medical reference.

· Use 5V, 1A version chargers. Please note the NoiseFit Endure smartwatch does not support a quick charge. Charge under watery (sweat) condition is prohibited to avoid short circuit and result in damage. This watch is an electronic monitoring product. The

data is for reference only and cannot be used as a

# PRODUCT OVERVIEW

Touch Screen Display Magnetic Charging Point Heart Rate Testing spot



### SYSTEM REQUIREMENTS

Scan the QR code to download the Da Fit app on your phone.









Note: Android app will be blocked in the background if

the phone is in standby mode for more than 2 hours.

Activate the app in the background platform via

Go to Settings. Choose Da Fit app. Choose Show

settings.

Notification.

### CONNECTION FOR APP AND WATCH

# Android Users -

 Go to the device page, Click the 'To add device' and select the Endure.

### iPhone Users -Go to device and select Add device, select Endure.

- Pair via bluetooth.
- Allow Da Fit to send notifications.

## Watch faces - Go to watch faces. Choose from the 3 options available.

Note: You can customize your watch face by using the editable version of the watch faces. Select the image for the gallery and save. For cloud based watch faces click on add more watch faces.

Shutter - Open the app and select shutter. Tap the

Charger or data line is working properly. If not then

Bluetooth hasn't connected to or unable to connect to

DA FIT APP SETTINGS

Notifications reminder - Tap to turn on/off and choose which apps' notifications to be pushed to your watch.

Alarms - Select the time in the alarm and number of alarms and save.

camera icon on the watch to capture the image

Note: Some phones may need to turn on the camera function first before using it.

## OTHERS

# Find Device - Upon tap, the watch will vibrate for the

Time Formats - Choose either 12-hour or 24-hour format.

Unit System - Choose either the Metric System or British System.

Do Not Disturb Mode - Set the start and end time and save. Note: Once turned on, notifications cannot be pushed to the NoiseFit Endure smartwatch.

Reminders to Move - Tap to set the daily reminder to

## QUICK VIEW

### Tap to turn on the quick view of the watch screen. Choose the validity period. Set start and end time and save.

Feed-in the city zip code to get that area's weather

Tap to turn on and provide the required information.

PHYSIOLOGICAL CYCLE REMINDER

# WEATHER

updates.

- Tap to turn on the weather notifications. Choose the temp system and hit done.
  - Note: For iPhones, please forget the devices in the phone's bluetooth setting to make sure the device is disconnected completely.

· Product has suffered any misconduct.

section on www.gonoise.com

CUSTOMER CARE TEAM

policy.

Update your firmware to get the best experience. Note: Please make sure that there is at least 50% battery life before upgrading. Keep your watch close to your Power on: Long press the button for 3 seconds to turn on the watch. Short press the button to wake the watch phone during upgrading. up if the watch is at standby mode.

Tap remove to unpair the device.

# select to turn the watch off. WATCH INTERFACE SHIFT PROCESS:

SMARTWATCH FUNCTIONS

1. Swipe right to check the notification bar. Swipe left to go to sports mode.

Power off: Long press the button for 3 seconds and

- Swipe up to go menu. Swipe down to display shortcuts menu.

# Register Warranty for your Product

www.gonoise.com/pages/warranty-registration







## Thank you for shopping from www.gonoise.com, For any assistance, please get in touch with our Customer Care Team at +918882132132 or just drop an email at support@nexxbase.com

replacement/refund related queries, please refer to the


terms and conditions mentioned in our return policy


We hope you have an amazing experience with the















### OPERATIONS ON THE DIAL

Shortcut interface - Swipe down on the status bar to see the functions. Visual presentation of the dial with the icons on the notification bar -

- · Find my phone
- Brightness Settings
- Connected Icor
- Battery Leve Day & Date

Watch Face - Long press the current watch face. Swipe left or right to choose the watch face.

Notifications - The Noisefit Endure can receive messages as long as it is synced with the smartphone and Da Fit app. You'll get notified of up to 8 messages. Click the empty button to clear the messages.

Note: Replying to text messages is not supported on

## PEDOMETER

The Pedometer will work as long as the watch is turned on and display today's steps, distance covered and calories burnt.

### SPORTS MODE

This mode has walking, running, cycling, skipping, badminton, basketball, yoga, football and workout.

Click the icon to enter the corresponding workout mode. Note: The data will only be saved when exercise time is more than 5 minutes or more than 200 steps. otherwise the exercise won't be saved.

the NoiseFit Endure smartwatch.

data is generated.

SPO2 Monitor - The NoiseFit Endure smartwatch will

Sleep Monitor - The default sleep monitor is set from 9:00 pm to 7:30 am. The watch can detect your sleep

# HEALTH (Heart rate and blood oxygen)

Heart Rate - The NoiseFit Endure smartwatch will start recording the heart rate using optical sensors. The result will be shown on the screen when the heart rate

> On the Da Fit app, go to the activity page and choose Heart rate to check history records over a day, week or with Da Fit app.

start recording the Oxygen level using optical sensors. The result will show on the NoiseFit Endure smartwatch when the oxygen data is generated. On the Da Fit app. go to the activity page and choose Blood Oxygen to check the last 7 trends.

Go to the watch face section on your Da Fit app. Select automatically if worn to sleep. You can check the sleep

### smartwatch will synchronize automatically once it is paired with Da Fit app. Note: There may be some variation in the actual

sleeping status due to the changing sleep modes. Music - You can control music from your smartwatch as ong as it is paired with your smartwatch and synced

duration on the Da Fit app following morning. The

Note: In a few cases, you may have to open the music player in your smartphone to be remotely controlled by the NoiseFit Endure smartwatch. The Noisefit Endure does not display music name or adjust the volume.

### WATCH FACE

the editable watch face. Choose the image and customize it as per your requirement and save. For cloud based watch faces click on add more watch

# Tap the start icon to start. Tap the play icon to start

Tap Settings to find more functions.

pause icon to pause and refresh icon to reset.

# SETTINGS

STOPWATCH

# SCREEN BRIGHTNESS Tap the screen to adjust brightness.

You can remotely control the camera once the NoiseFit Endure is paired with your smartwatch and synced with the Da Fit app.

Tap the camera on the NoiseFit Endure smartwatch.

Note: Smartphone's camera would also open.

### Select the frame you want to click. Tap on the NoiseFit Endure smartwatch camera to click images. Note: The image will be saved automatically in your phone's gallery.

Tap the left icon to exit and tap the right icon to reset. Note: Once reset, all the data will be cleared. The data of the paired phone will not be cleared until and unless the phone has also been reset.

RESET

You can see device address, bluetooth name, and firmware version here

# TROUBLESHOOTING malfunctioning.

Make sure to charge the watch before switching on

# watch has not been used for a long time

charge the watch before switching it on.

### Refer to the following steps in case of any smartwatch

 Unable to restart the watch . This issue may occur, if the watch button is not pressed for long enough. Press again for over 3

### the watch. · Use 5V/1V adapter to charge the watch in case the

Auto power off - This may be due to low battery, please

# Inaccurate sleep data -

the watch.

- · Please wear the watch at all times to avoid variation in
- . This may be due to an insufficient battery charge. Make sure that the battery is charged, for at least 2

# watch again.

change and get a new one.

· Check the charging port and try again.

- The sleep monitor is designed to imitate the natural pattern of falling asleep and waking up.
- data that may occur if going to bed late or only wearing during sleep. There may not be any sleeping Short battery life data generated if you go to bed at any time during the day as the defaulted sleeping time is preset to between 9:00pm to 7:30am.

# Restart the watch - Turn off the bluetooth of your phone, turn on the bluetooth again and connect to the

# Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the

instructions

communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

Risk of explosion if battery is replaced by an incorrect

type. Dispose of used batteries according to the

## 2. What are the things that are not covered in the warranty:

WARRANTY INFORMATION

· Product has been subject to unauthorized tampering modification or repairs.

> · Product has suffered physical damage on the account of abuse, neglect, or improper use, handling, storage, installation, or testing, including any use that is not in accordance with the product manual, documentation, or other instructions provided along with the node product.

What is covered in the limited warranty period?

including accessories on manufacturing defects (if

Warranty is applicable on the Noise product

any) for 1 Year from the date of purchase.

# Any other clause mentioned in our online return

Note: For further information on product





SCAN ME