User Manual: Oil Spray Bottle 180ml

Product Overview

The Oil Spray Bottle 180ml is a versatile kitchen tool designed to help you control and evenly distribute oil while cooking. This user manual provides instructions on how to use and maintain the oil spray bottle effectively.

Specifications

Capacity: 180ml

Material: Food-grade plastic

Spray Type: Adjustable nozzle for mist or stream

Usage: Ideal for olive oil, vegetable oil, vinegar, soy sauce, lemon juice, and more

How to Use

Fill the Bottle: Unscrew the top of the bottle and fill it with your preferred oil or liquid.

Adjust the Nozzle: Rotate the nozzle to adjust between a fine mist or a steady stream, depending on your needs.

Spray: Press the nozzle pump to spray the oil onto your food or cooking surface.

Clean: After use, rinse the bottle with warm soapy water and let it air dry.

Maintenance

Regular Cleaning: It is recommended to clean the bottle after each use to prevent clogs and ensure optimal performance.

Storage: Store the bottle in a cool, dry place away from direct sunlight.

Avoid Clogging: If the nozzle becomes clogged, soak it in warm soapy water and use a small brush to clean it.

Safety Precautions

Do not overfill the bottle: Leave some space at the top to allow for air pressure when pumping.

Avoid dropping: The bottle may break if dropped on hard surfaces.

Keep out of reach of children: The bottle contains small parts that may pose a choking hazard.

Troubleshooting

Clogged Nozzle: Soak the nozzle in warm soapy water and use a brush to clean it.

Leaking: Check the tightness of the cap and nozzle to ensure a proper seal.

Sprayer Not Working: Make sure the tube is properly inserted into the bottle and the pump is functioning correctly.

Warranty

This oil spray bottle comes with a 1-year warranty against manufacturing defects. Please contact customer service for any warranty claims.