USER MANUAL

HOFFEN™

Electronic Digital Scale



AN ISO 9001:2015 CERTIFIED CO
Manufactured & Marketed in India by :
Ace INCORPORATION
107, New Atish Market, Mansarover, JAIPUR- 302 020 (Rajasthan) India
For Consumer Complaints & Suggestions
Write us at : support@aceincorporation.com
Call us at : 84327 68147
Visit us at : www.aceincorporation.com

INTRODUCTION

Thank you for purchasing a HOFFEN Electronic Personal Scale it has been specifically designed for your use, with an easy to use interface and superior HOFFEN accuracy and design.

Your HOFFEN Electronic Personal Scale comes with the following :

* HOFFEN Electronic Personal Scale
* Instruction Manual
* 2 AAA Batteries
* 2 Year HOFFEN Warranty Card

Please read this instruction manual carefully before using your scale.

WARRANTY

HOFFEN Electronic Personal Scale India warranty cover defects in material and workmanship of the product under normal use a period of none (2) years from the date of retail purchase. The warranty dose not cover damages resulting from misuse, abuse, Immersion, normal ware and tear or unauthorized modification.

Should this scale require service (or replacement at our option while under warranty, please contact ACE Incorporation for return authorization and troubleshooting.

There are no expressed warranties except as listed above. This warranty gives you specific legal right which may vary from state to state. NOT LEGAL FOR TRADE

Please fill out your purchase information for future reference :

Date Purchased : .....

Place of Purchase : .....

Order IP (if any) : .....

OPERATION

Battery Installation and First Time Setup

1. This scale operates on 2 AAA batteries. Unwrap batteries before proceeding.
2. Locate the battery cover on the backside of the unit. Press the battery cover tabs inward and life to remove.
3. Insert batteries as indicated by the polarity symbols (+and-) as marked. Close the covers.
4. The scale need to be initialized and auto-calibrated before first use or after any time you move your scale Place the scale on a hard, flat surface. If the scale turns on while being moved, allow it time to turn off once on the ground.
5. Get on the scale and weigh yourself (please keep in mind the first reading may not be accurate and can be disregarded).
6. Get off the scale and allow it to turn off.
7. You can now step on and weigh yourself normally. If you move the scale again, you must repeat this calibration process. You will see your final weight the display locks in on a weight and blinks two times.
8. Replace batteries when scale indicates "LO" on the display.

NOTES

1. New batteries should last for approximately one year under moderate use (less than three times daily). Batteries included with your scale are trial batteries and may last a shorter length of time.
2. Dispose of batteries within the legal restrictions of local government.

WEIGHING PROCEDURE

Your HOFFEN Personal Scale operates as a basic body weighing scale. No special programming is required.

1. Select your desired measurement unit. Your scale is set to default to kilogram at the factory, but you can change the measurement units to pound or stone by clicking the unit button inside battery chamber at backside of your scale.
2. Place the scale on a hard, flat surface. Carpeted or uneven floors can negatively effect the accuracy of your reading. Optimal flooring surfaces include hardwood, ceramic tile or concrete.
3. Initialize the scale. If you are placing the scale down for the first time or moving unit you must auto-calibrate the scale (see steps 4-7 under the "Operation" tab of this manual).
4. Step on. Place both feet on the center of the platform and stand still.
5. Your weight will appear on the LCD. Your weight will blink two times when your final weight has been calculated.
6. Step off your scale. It will reset to ""0.0" and turn off automatically.
7. Move your scale as infrequently as possible. To ensure maximum accuracy and consistency digital scales generally should be moved as little as possible.

IMPORTANT :

Your HOFFEN Personal Scale operates with "Step-On" technology but still needs to be auto-calibrated after installation and when the scale is moved.

Place the scale on a hard, flat surface and weigh yourself. Ignore this reading and get off the scale. Then without moving the scale weigh yourself again. This is your true weight.

TROUBLESHOOTING

PROBLEM	SOLUTION
Scale is inaccurate or weight varies	Place feet in center of platform and stand still. Allow scale to shut off completely after weighing. Do not move scale unnecessarily.
First weight is higher then normal	Your scale must be allowed to auto calibrate. Follow instructions under "Operation" for proper use.
Scale display "Err"	Place scale on hard, flat surface. Allow scale to shut off and restart.
Low battery indicated "LO" No power	Check batteries for proper instillation (polarities are correct). Replace all two worm batteries.
Overload Indicated "Err"	Too much weight has been placed on the scale and it is overcapacity. Remove weight before proceeding.
Other condition	Email : support@aceincorporation.com

SPECIFICATIONS

Model	:	HOFFEN Electronic Personal Scale
Battery	:	1 Year(if used twice a day)
Measurement Units	:	Kg/lb/st
Capacity	:	180 kg/400 lbs/28st
LCD Screen	:	73 mm X 28.3 mm
Display	:	LCD screen
Low Battery Indicator	:	"LO"
Overload Indicator	:	"Err"
Re-test	:	C
Graduation	:	50g/0.2 lb/0.01 st
Net Weight	:	5.6 kg | Gross Weight : 6.9 kg
Accuracy	:	+_100g/0.2 lb
Warranty	:	2 Years
Battery	:	2 AAA Batteries (included)

CARE & MAINTENANCE

To maintain your HOFFEN Electronic Personal Scale in the best possible condition follow these directions as closely as possible.

1. Store and operate the unit in safe dry location. Drastic changes in temperature over time can effect the quality of weight measurement. Do not expose to direct sunlight, extreme hot/cold or humidity.
2. Clean with a soft, damp cloth. Avoid abrasive cleaners and never sink or submerge in water.
3. Remove batteries if not in use for three months or longer.
4. Use unit consistent with instruction provided in this manual.