Dear Customer,

Thank you very much for purchasing this set of 4 window Christmas lights.

Please read these operating instructions and follow the listed instructions and tips so that you can make the best use of your new decorative lighting.

Manual download
Manual / Mode d’emploi / Istruzioni / Οδηγίες / Instructies / Инструкции / Instrucciones / Ohjeet / Talimatlar

www.emall.com/a312370

A	ALB	AND	BE	BG	BLR	CY
CZ	DK	D	E	EST	F	FIN
GB	GR	H	HR	I	IRL	L
LT	LV	M	MDA	NL	NO	P
PL	RO	RUS	S	SK	SLO	TUR

Scope of delivery

- 4xWindow Christmas lights
- INSTRUCTIONS FOR USE

Additionally required: 3x AAA 1.5V batteriesVeach star

Technical data

power supply	3XAAA / Micro battery (1.5voltDC)
Timer function	for lighting cycle with 6hLight and 18hpause
Number of LEDs	10 LEDs
Light color	2700K(warm white)
Protection class	IP20
Star dimensions (Ø x D)	180x 10mm
Weight	approx. 66 g

Product details



1. Suspension with mode button on the front and suction cup on the back
2. LED star

use

Inserting/replacing batteries

1. Open the battery compartment on the back of the hanger.
2. If necessary, remove any old batteries and insert three new AAA/Micro batteries.Make sure to observe the correct polarity (marking in the battery compartment) of the batteries.

A NOTICE:

Use only batteries of the same manufacturer and type.Do not mix batteries from different manufacturers.

3. Replace the battery compartment cover and close the battery compartment.The lid should audibly click into place.

switch on the light

- Press the mode button to turn on the LEDs and keep them lit continuously.
- Press the mode button again to make the LEDs blink.
- Press the mode button a third time to turn off the LEDs.

A NOTICE:

The lights, when switched on, illuminate cyclically for 6 hours, with an 18-hour break.

Safety instructions

- This user manual is designed to familiarize you with how this product works.Therefore, keep these instructions in a safe place so that you can refer to them at any time.Pass them on to subsequent users.
- Please observe the safety instructions when using the product.
- Hang or attach the lighting in such a way that it does not create a tripping hazard.
- Modifying or altering the product will compromise product safety.Caution: Risk of injury!
- Never open the product yourself, except to insert/replace the batteries.
- Never attempt repairs yourself!
- Handle the product carefully.It can be damaged by bumps, blows, or falls from even a low height.
- Keep the product away from moisture, extreme heat, and direct sunlight.
- Never immerse the product in water or other liquids.
- Check the product for damage before use.Do not use it if it shows visible damage.

©REV2–July 10, 2026–BS/GW//CN

- Technical specifications subject to change without notice. Errors and omissions excepted.

Important information about batteries and their disposal

Batteries do NOT belong in household waste.As a consumer, you are legally obliged to return empty batteries for proper disposal.You can dispose of your batteries at public collection points in your community or anywhere that sells batteries of the same type.

- Batteries should be kept out of the reach of children.
- Batteries that leak fluid are dangerous.Only touch these while wearing suitable gloves.
- Do not attempt to open batteries and do not throw batteries into fire.
- Normal batteries must not be recharged.Warning: Risk of explosion!
- Remove the battery from the device if you will not be using it for an extended period of time.
- When inserting the battery, be sure to observe the correct polarity.An incorrectly inserted battery can destroy the device – risk of fire!
- The ideal storage temperature for batteries is 10 – 20 °C.Avoid direct sunlight at the storage location.

Important disposal information

This electrical appliance does NOT belong in household waste.For proper disposal, please contact the public collection points in your community.
Details regarding the location of such a collection point and any possiblyPlease refer to the information provided by the respective municipality for any existing quantity restrictions per day/month/year.

Declaration of Conformity

PEARL Inc. hereby declares that the product AX-2370-675 is in compliance with the RoHS Directive 2011/65/EU + (EU)2015/863 and the EMC Directive 2014/30/EU.



Product Compliance
Sebastian Herguijuela

The full declaration of conformity can be found at www.pearl.de/support.Enter the item number AX-2370 in the search field there.