USER MANUAL

Electric Jar Opener

KITCHENMUH



Thanks for buying KiTCHENMUH Electric Jar Opener

We're glad you purchased a KiTCHENMUH electric Jar opener. KiTCHENMUH cares about the old and disabled. Focus on researching kitchen tools for those who have hand problems, therefore our electric jar opener is suitable for disable, seniors with arthritis or who has weak hands.

Our mission is to empower everyone especially for who has hand problems to be able to have a more effortless can-opening experience, simplifying their lives.

Your KiTCHENMUH electric jar opener is well made, and we back it with a limited one-year warranty. We also stand behind it with a knowledgeable, dedicated Consumer Care department, so, should you ever have a problem, you'll receive fast, considerate assistance.

Thanks again, from all of us.

KiTCHENMUH

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING YOUR ELECTRIC JAR OPENER.

Take off the batteries when not in use before conducting maintenance.
When using an electric jar opener, basic precautions should be observed, including the following:

» The electric jar opener must be put into 2 AA batteries.
» Children should be supervised to ensure that they do not play with the appliance.
» Do not use with damaged or low powerful batteries.
» Do not allow it to be used as a toy.
» Do not immerse in water or liquid.
» Do not use for any purpose other than described in this User Guide.



IMPORTANT!

KiTCHENMUH is committed to providing the best shopping experience for our customers.

If you have any issues when using the KiTCHENMUH electric jar opener, please contact us without any hesitation and we will provide the best solution for you!

We would appreciate it if you could contact us with your precious advice for our electric jar opener.

KITCHENMUH



Electric Jar Opener

How To Install The Battery?

Please scan the QR code to know more about opening battery compartment.

Before using

electric jar opener, please wipe the surface of the jar body.
Scan the OR code and the video will help you open jars better.

To watch a quick

instructional video on
how to use
KiTCHENMUH
Electric Jar Opener.
Scan this QR Code!

Catalogue

Parts and Functions---------- 09

Install Battery---------- 10-11

Using Electric Jar Opener---------- 12-14

Trouble Shooting---------- 15

Warming Tips---------- 16

Safety Notices---------- 17

Service---------- 18

Parts and Functions

1. Start/Release Button
2. Battery Compartment
3. 4 Inner Jaws
5. 6 Outer Jaws



Install Battery



1 Press inward with thumb and forefinger



2 Pull back the battery cover

Install Battery



3 Put into 2 AA batteries according to "+" & "-" poles



4 Press inward and push into with thumb and forefinger

Using Electric Jar Opener



1 Push the button for 3-15 seconds



2 Inner & outer jaws start to grab inward

Using Electric Jar Opener



3 Auto rotate to open jars



4 Wait for reset of jaws

Using Electric Jar Opener



5 Remove the opener



6 Remove the lid

Trouble Shooting

1 Jaws cannot grip the jar tight enough and opener slips during operation.

Use a dry cloth to wipe the lid, jar/bottle and the Electric Jar Opener rubber grips.

2 Can't be used on too small or too big jars.

Jar lid opening size range diameter 1.2- 3.5", jar body opening size range: diameter 1- 3.5". It could not use on which exceed the size range above.

3 The Electric Jar Opener will slip off when running.

When used on some relatively small jars will cause top-heavy, so it is needed to hold the Electric Jar Opener slightly to avoid slipping.

4 It could not use on plastic jar.

The Electric Jar Opener is not suitable for plastic jars, jars with steep curves, or irregular shapes where the jaws grip.

Warming Tips

- This Electric Jar Opener is suitable for regular and vacuum-style glass screw-top jars and is intended for household use only. Anyother use is not recommended.
- DO NOT use the Electric Jar Opener to open jar lids smaller than 1.2 inch (30mm) or bigger than 3.5 inches (88mm) in diameter.
- DO NOT use the Electric Jar Opener to open jar body smaller than 1 inch (25mm) or bigger than 3.5 inches (88mm) in diameter.
- DO NOT use the Electric Jar Opener to open plastic jars, jars with steep curves, or irregular shapes where the jaws grip.
- DO NOT use the Electric Jar Opener if there are any signs of defects on the jar lid or chipped glass around the jar.
- Always place the jar on flat non-slippery surface.
- To prevent toppling and spillage when opening small or tall jars, please secure the jar with one hand and gently hold the Electric Jar Opener with your other hand.

Safety Notices



Don't use old and new batteries together.



Make sure the batteries are inserted in the correct polarity.



Don't immerse it in water or any other liquids.



Use under adult supervision.



Keep away from flammable and explosive products.



Remove the batteries when not in use for an extended period of time.

Service

Please do not return this product to the store.

Please contact KiTCHENMUH Consumer Care if you need information about repairs or have any questions about your warranty.

Mon-Fri 9AM-6PM(PST)

+1（808）666-2808
www.kitchenmuh.com
support@kitchenmuh.com

KITCHENMUH

Electric Jar Opener