反面

正面

PARWIN PRO
BEAUTY

www.haircaresshop.com

PARWIN PRO
BEAUTY



Parwin Pro 7 in 1 Curling Wand Set

IMPORTANT SAFETY & OPERATING INSTRUCTIONS

GREETINGS

Thank you for purchasing Parwin Pro products. We hope you will be pleased with both of the product and the service you received. We would like to hear from you about helpful suggestions on our products and customer services.
As a growing business brand, we hope to develop much better with all your suggestions and supports. We appreciate a lot!
To get more information and discounts, please visit our official website and the Facebook Page

Official Website: www.haircaresshop.com
Facebook: @HaircareshopBeauty

CONTENTS

IMPORTANT SAFETY INFORMATION 1
PRODUCT FEATURES 2
OPERATING INSTRUCTIONS 3
MAINTENANCE 8
SPECIFICATIONS 8
WARRANTY TERMS & CONDITIONS 9



3/4" wand for small curls



1/2-1" Reverse tapered wand for textured curls



1" wand for normal curls



1-1/2" Taper for relaxed curls



1" Infrared wand for softer curls



1" Bubble wand for lively waves



1 1/4" wand for large curls

Parwin Pro 7 in 1 Curling Wand Set

IMPORTANT SAFETY INFORMATION

⚠ **WARNING: TO REDUCE THE RISK OF SERIOUS INJURY, READ ALL INSTRUCTIONS AND WARNINGS COMPLETELY BEFORE USING THIS PRODUCT.**

Parwin Pro has been carefully engineered for both effectiveness and safety. However, basic safety precautions should always be followed when using any device, especially when children are present.



Parwin Pro 7 in 1 Curling Wand Set is not intended to use by children.

KEEP AWAY FROM WATER.

DANGER: As with most electrical appliances, electric parts are live even when the switch is off.
Warning to reduce the risk of burns, fires, electrical shock, injury or damage to property:
1. Always unplug the appliance immediately after using. Never do this with wet hands.
2. Never use the appliance while bathing. Never place or store it where it can fall or be pulled into a tub, toilet or sink, or any other water source. Do not use it near water. Do not place or drop it into water or other liquid. If it falls into water, do not reach into the water! Unplug device immediately.
3. Do not use attachments not made by the manufacturer.
4. NEVER operate the appliance if it has a damaged cord or plug, or if it is not working properly. If the power supply cord or plug is damaged, the appliance must be replaced by the manufacturer or an authorized service agent in order to avoid dangers. Keep this product and the cord away from water and heated surfaces. Do not wrap the cord around the appliances. And it should never be left unattended when plugged in.
5. Never use the appliance on the hair with hair spray or fixature. This product is designed for hair styling. Do not use for any other purpose.
6. Keep this product be away from excessive force or shock that may result in malfunction, shorter lifespan, or distorted parts.
7. Do not assemble the appliance's components on your own. To avoid any damage to the appliance.
8. Never use liquid cleaners, aerosol cleaners or any cleaner containing alcohol, detergent, abrasive, or corrosive materials.
9. Only use the appliance on clean, dry hair. It should never be used with any type of synthetic hair extension.
10. Children should be supervised to use the appliance, not used as a toy.

KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE AND MAKE SURE ANYONE WHO USES THIS PRODUCT ALSO READS THIS MANUAL.
READ ALL INSTRUCTIONS BEFORE USING THE APPLIANCE. NO ASSEMBLY REQUIRED. FOR HOUSEHOLD USE ONLY.

PRODUCT FEATURES

7 INTERCHANGEABLE BARRELS FOR ALL CURLS:
PARWIN PRO 7 in 1 curling wand set efficiently curls your hair with small and big curls, waves, corkscrew curls and ringlets. Choose the one you need: 3/4 inch (19/19mm), 1 inch (25/25mm), 1 inch (25/25mm) red infrared ray wand, 1 1/4 inch (32/32mm), a 1-1/2 inch (25/13mm) tapered wand, a 1/2-1 inch (13/25mm) reverse tapered wand, and a 1 inch (25mm) bubble barrel.

INFRARED MOISTURE-SEAL HEAT:
Infrared ray on the 1 inch barrel provides infrared moisture-seal heat fully penetrates hair cuticle and heats hair from the inside-out, sealing in hair's natural moisture and oil, adding silkier and longer lasting shine to the original look.

CHANGEABLE TEMPERATURE & MAX 450°F:
The curling wand handle equips with the rotating temperature control. 20°F a grade to adjust. Total 9 grades temperature to choose: 290°F-310°F-330°F-350°F-370°F-390°F-410°F-430°F-450°F. Heats up quickly within only a minute. High Heat for salon-style curling at home.

DUAL VOLTAGE & 360° SWIVEL CORD:
Dual voltage between 110-240V, convenient for travels. 360° Rotatable Swivel Cord is to prevent the winding, easy to use, safe to operate.

DIGITAL TUBE SCREEN:
Precise digital tube screen and temperature control for accurate setting and monitoring of temperature ranging from 290°F to 450 °F.

HUMANIZED FUNCTIONS:
Clip-free, interchangeable, and 100% ceramic barrels are lightweight and easy to use. Ceramic tourmaline technology offers superior heat generation that gives you quick and easy curls that have a smooth, silky shine. Negative ion seals the hair cuticle for a smooth, frizz-free, and glossy finish that lasts for days.
Soft touch handle for luxurious feeling with grains for better hand grip and comfortable use.
60 minutes auto-sleep mode is designed to ensure home safety and the appliance longevity. No more worry about rushing out, and temperature will remain constant throughout using.
8 ft. (2.5M) professional length, 360° swivel cord is for tangle free styling. You can hold the device at any angle for the best curling result.
Heat-resistant barrel top: Plastic material barrel top works an important role to protect users from heat when creating their hairstyles. No more worry about heat and inconvenience.
NTC thermal resistor: To protect the appliance from going into the open circuit and the short circuit circumstances.

HEAT RESISTANT GLOVE & BAG:

The attached heat resistant glove protects you from heat. Ensuring the safety during your using. Including a tidy bag, stores the curling wands together and shows convenience for taking it to travel.

OPERATING INSTRUCTIONS


HOW TO CHANGE CURLING WANDS:

⚠ **WARNING: The elements of the appliance will become very hot when plugged in and switched on. Before fixing or removing any attachments, ensure the appliance is switched off, cool down fully, and is unplugged.**

1. Grip the curling wand handle to unlock the locking dial. Rotate the dial by the counter-clockwise direction and make the string "|" on the dial points to the "🔓" icon.



2. Choose the changeable barrel you need and push along all of its guide pillars into the guide slot of the handle dial straightly.




3. Ensure the barrel is securely connected to the locking dial on the handle.



4. To lock the locking dial, turn it by the clockwise direction and make the string "|"points to the "🔒" icon to ensure the attachment is in place.

OPERATING INSTRUCTION:





Handle Size:
L=7 Inch

Wand Sizes:
Cylinder: 3/4 Inch, L=5.5 Inch
Infrared Cylinder: 1 Inch, L=5.5 Inch
Cylinder: 1 Inch,L=5.5 Inch
Cylinder: 1 1/4 Inch, L=5.5 Inch
Taper: 1 - 1/2 Inch, L=5.7 Inch
Reverse Taper: 1/2 – 1 Inch, L=5.5 Inch
Bubble Wand: 1 Inch, L=5.9 Inch

STEPS:

1.Before start to use, comb your dry hair to avoid from frizzy and knots.

2.Plug in the appliance and it shows "OFF" without heating up.

3.Then long press the "ON/OFF" power button for 2-3 seconds and the appliance turns on with a sound of "beep". The default temperature is 410°F.

4.Adjust the ideal temperature by the rotatable control. To increase temperature, turn it by the counter clockwise direction and to decrease inversely by turn it by the clockwise direction.



5.Temperature can be adjusted between 290°F to 450°F. 20°F a grade to adjust with a sound of "beep" during adjusting.
(290°F-310°F-330°F-350°F-370°F-390°F-410°F-430°F-450°F)

★Tips & Attention:
(1) The digital tube screen flickers three times when the appliance is power on or the temperature is being adjusted. Then it stops flickering and shows stably with a sign "🔒" and sound of "beeps" for twice.
(2) The appliance goes into temperature-locking condition after the temperature stably shown. If you try to adjust the temperature in this condition, the digital tube screen will show "LOC" and a "🔒". It means the temperature cannot be chosen at this time. Press the "ON/OFF" button once to make the numeric on the screen keeps flickering, then to adjust temperature again.
Important: The curling barrel gets really hot in several seconds. So please never make the high temperature barrel touch your skins or surface.

6.Separate hair into sections. Take one section of hair and wind it around the wand barrel.
★If you are using the reverse tapered wand attachment:
(1)Hold the appliance upside-down.
(2)Start wrapping hair around the wand from the thinner portion to the thicker part of the barrel.
★If you are using the infrared ray wand attachment: Just wrap your hair around the wand directly, no more further step to turn on the infrared ray.

7.Hold the ends of the hair in place at the cool tip for 5 to 8 seconds, depending on the hair type, and then release. For tighter, bouncier curls, roll less hair. For loose, free-flowing curls, roll more hair. To keep the curls stay longer, do not comb or brush your curly hair until they get cool down.

8.Repeat above process with all your hair sections until the hairstyle you desire is finished.

9.When your desired hair style is achieved, press the power button to turn off your curling appliance. Wait for some moments until it is completely cool down, then you can store it well.

10. Furthermore, if you need to change the barrel for different curly style. Please remember:
(1) Long press the power button for 2-3 seconds to turn off the curling iron.
(2) Wait for the curling wand to be totally cool down, then rotate the barrel dial to unlock it. Then take out the barrel.
(3) Choose another barrel and repeat the step mentioned before in "HOW TO CHANGE CURLING WANDS".
(4) Then you can start to make your different gorgeous hairstyle.

TEMPERATURE RECOMMENDATION:

- 290°F-350°F: Thin & Fine Hair
- 350°F-410°F: Normal Hair
- 410°F-450°F: Normal to Thick Hair

Curly Styles for Reference:



MAINTENANCE

The Parwin Pro curling wand set requires few maintenance. If it is necessary to clean, unplug the appliance and wait for it to cool down completely. Then wipe the surface of the appliance with a smooth cloth. Never attempt to repair the appliance on your own. If it is required, return it to an authorized service representative for a repair.

STORAGE:

To store your Parwin Pro curling wand set, unplug it and wait for it to cool down completely. Place all of the attachment in the bag and put the wand set in a safe and dry place that is out of the reach of children. Never pull the cord or wrap the cord around the appliance.

IMPORTANT:

A Heat-protective glove is attached in the set to protect your fingers from heat when you wrap the hair around the high temperature barrel. Please note that the heat-protective glove is only designed to give initial contact protection. Discomfort will be caused by prolonged contact with the hot surface. What's more, heat-resistant pouch has been supplied. After use the curling wand, unplug and store it in the pouch.

SPECIFICATIONS:

Name: 7 in 1 Curling Wand Set
Model Number:PW-C03B
Barrel Sizes: 3/4 Inch, 1 Inch, 1 Inch with infrared heat ray, 1 1/4 Inch, 1/2-1 Inch reverse tapered wand, 1-1/2 Inch, 1 Inch bubble wand
Input Voltage: 100-240V 50/60Hz
Power: Max 60W
Temperature Range: 290°F-450°F (290°F-310°F-330°F-350°F-370°F-390°F-410°F-430°F-450°F)
Color: Golden/Black

WARRANTY TERMS & CONDITIONS:

- DO NOT operate the appliance with a damaged plug or cord, or if the unit has been dropped, damaged, or dropped in water.
- To avoid the risk of electric shock, do not disassemble or attempt to repair the appliance
- If the supply cord is damaged, it must be replaced by a qualified electrician in order to avoid dangers. Incorrect reassembly or repair can cause a risk of electric shock or hurt to whom use the appliance.

ONE YEAR LIMITED REPLACEMENT WARRANTY STATEMENT:

- The item has not been misused, abused, neglected, altered, modified, or repaired by anyone. The item has not been used for trade, professional, or hire purposes
- The item has not sustained damage through other objects, substances, or accident.

Your warranty does not cover:
« Components that are subject to natural wear and tear caused by normal use in accordance with operating instructions.
« Unauthorized/improper maintenance/handling or overload is excluded from this warranty.
« For guarantee claims, you will need to submit a proof of purchase in the form of a valid receipt that displays date and place of purchase.
This warranty does not replace but is in addition to your statutory rights.
This warranty does not apply to accessories supplied with the item.
This warranty applies only to the original purchaser and may not be transferred. Replacement items will be covered by the limited warranty for the balance of the warranty period from the date of the original purchase.

Please note:
Only the defective products or parts can be replaced under this warranty.
Only valid if the product is purchased from an authorized seller of Parwin Pro Beauty and if the original serial number on the product has not been removed or otherwise tampered with.

Parwin Pro 7 in 1 Curling Wand Set:

Get even more tips & tricks on our social websites! Share your videos, tips, questions with other fans!
Visit Parwin Pro official Website: www.haircaresshop.com to complete your warranty registration and get more information!
And if you have any requests, please contact to our aftersales emails: service@haircareshop.com