
Customer Service:
support@bonsenglobal.com

BONSEN

Designed in Georgia
Made in China

Bonsen Electronics Inc.
Address: 5808C Peachtree Conrners East Norcross, GA, 30092
Contact: 1-844-728-6917
Customer Service:support@bonsenglobal.com

BONSEN



BONSEN PROJECTOR PJ8101
User Manual

Please read this manual throughly before using and keep it for future reference.

V3.01

This equipment has been tested and found to comply with the limits for a Class B digital device.pursuant to part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates.uses and can radiate radio frequency energy and.if not installed and used in accordance with the instructions.may cause harmful interference to radio communications However.there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception.which can be determined by turning the equipment off and on.the user is encouraged to try to correct the interference by one or more of the following measures;

- .Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced ridio/TV technician for help.

Caution;Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules.Operation is subject to the following two conditions; 1.This device may not cause harmful interference.and ;2 this device must accept any interference received.including interference that may cause undesired operation.
This equipment complies with FCC RF radiotion exposure limits set forth for an uncontrolled environment.This device and its antenna must not be located or operating in conjunction with any other antenna or transmitter.

This device has been evaluated to meet general RF exposure requirenent.The device can be used in portable exposure condition without restriction.

1.In order to extend the life of the speakers and your physical and mental health.please da not play music in large volume mode for a long time.

2.Please select headphone output mode to listen music in public place.so as not to disturb others


PACKING LIST




Leisure 450 | Power Cable | AV Cable | HD Cable | User Manual

NOTICE


Recommended





NOT Recommended




FUNCTION OVERVIEW










QUICK START



1 Plug the power cord into an outlet.



2 Take off the lens cover.




3 Connect your device to the projector correctly.



4 Press the power button to turn on the projector.




5 Press the button to select the correct input source.



6 Unfold the kickstand to adjust the image height.



7 Adjust the keystone and focus ring to get the best image performance.




8 Press the power button twice to turn off the projector.

INPUT SOURCE


Press the button on the projector/remote to enter the interface of **Input Source**.

A.Multimedia Connection




Please select **USB** or **TF** as the input source after installing the USB Drive or the microSD Card, then you will enter the main interface with icons of **MOVIE**, **MUSIC**, **PHOTO** and **TEXT**. Make sure to select the right icon for the file you'd like to play. For example, if you'd like to play videos, select **MOVIE** first and similarly as to the others.

B.HD Connection




C.VGA Connection



PROJECTOR CONNECTIONS



PROJECTION DISTANCE&SIZE



The recommended projection screen is around 87 inches with a projection distance of around 8.6FT.

SPECIFICATION

Native Resolution		Resolution Supported	576i、576P、720i、720P、1080i、1080P
Projection Distance	3.6FT-19.7FT	Projection Screen	34"~200"
Installation Type	Front/Rear/Ceiling	Aspect Ratio	4:3/16:9/auto
Focus	Manual	Keystone	±15°
Speakers	3W/4ohm*1	Power Supply	AC 110-240V, 50/60Hz
Unit Dimension	9.17*7.05*3.07 inches	Unit Net Weight	2.42 LBS
Photo Format Supported	BMP/JPG/PNG/GIF/JPEG	Audio Format Supported	AAC/MP2/MP3/PCM/FLAC/WMA
Video Format Supported	AVI/MP4/MKV/FLV/MOV/RMVB/3GP/MPEG1/MPEG2/H.264/XVID	Ports	HD In*1/USB2.0 Port*1/VGA Port*1/AV In*1/Audio Out*1/microSD Card Slot*1

TROUBLESHOOTING GUIDE

1. Blurry Image
   * Adjust focus ring/keystone.
   * Projector and screen/wall must be in effective distance.
2. Remote Unresponsive
   * Make sure remote points at IR receiver directly.
   * Do not cover IR receiver.
3. Up Side Down Images
   * Go to **Menu** > **OPTION** > **Projection Mode** to flip the projection image.
4. Adjust the Image Size
   * Go to **Menu > PICTURE > Reduce Display size** to adjust the image size.