材质：157g铜版纸
尺寸：140X140MM
装订方式:鞍形折
颜色:四色印刷

Petory

User Manual

Automatic Pet Feeder

F01

Please read this manual carefully before using.

V: 1.0_RD.R20-01-02

IMPORTANT SAFETY INFORMATION

Thank you for choosing Petory F01 Pet Feeder. F01 PET FEEDER is dedicated to using technology to create a better life for you and your pets.

WARNING

- Dispose of all packaging materials properly. Some items may be packed in plastic bags. Keep bags could out of reach of children to avoid suffocation hazard.
- Do NOT allow small children to play with, or in around the pet feeder.
- To reduce the risk of injury, please keep close supervision when an appliance is used near children.
- Do NOT use the pet feeder for anything other than its intended use. Misuse may cause injury.
- Do NOT immerse the base part in water at any time as it may damage electronic components in the the control panel.
- Do NOT place any foreign object in the pet feeder.
- Do NOT use outdoor. Check operation frequently to be sure the unit is dispensing properly.
- Do NOT use wet, canned or moist food.
- Use only accessories and attachments that are instructed in this User Guide.
- Do NOT use the feeder for anything other than its intended use.
- Only use attachments recommended or sold by the manufacturer. The use of attachments not recommended or sold by the manufacturer may result in injuries to persons, damage to the appliance.
- Do not operate any appliance if the unit is malfunctioning or has been damaged. Do not attempt repairs on the pet feeder yourself. Contact our customer service immediately for further instructions.
- Keep the feeding area clean and free of food residue. Failure to do so may cause the power cord or plug to overheat causing a fire hazard and/or electric shock and injury to your pets.

CAUTION

- Do NOT allow pets to chew on or swallow any parts. If you are concerned about the power cord, purchase a shorter power cord or a protective cover for the power cord. Do not use an extension cord.
- If an extension cord is necessary, one with a proper rating should be used.
- Do NOT install or store the pet feeder where it will be exposed to weather or temperatures below 4°C/40°F.
- Do NOT use the pet feeder for food other than dry pet food.
- Check the batteries regularly. Remove worn or expired batteries, always replace batteries with new ones.
- Do NOT lift the pet feeder by its food tank, or food tray. Lift and carry it using both hands and the base, while keeping the unit in an upright position.
- Do NOT use batteries with metal case ranging from 3.8mm (5/32) in diameter, Larger sizes may operate in the food tank.
- Do not put your fingers into the feeder while an auger begins touch the entry.
- Read and observe all important notices listed on the pet feeder and in the packaging.

Product Description

Product Specifications

Product Model	F01
Input	6V⎓
Dimensions	L320*W250*H340mm 10kg
Dual Power	1pcs C cell D batteries
Capacity	6L(only dry food)
Programmable	100 portions, 10g per portion & meals per day

How to Install

1. Assemble the bowl, Plug in power adapter, turn on the power switch.

2. Recommended to install batteries to ensure that the feeder works properly when the power is off.

3. Press inward at the same time to open the lids.

Operation Interface

Icon Quick Guide

Icon	Meaning
10:08	Current Time/Feeding Time Initial setting time is 10:08
SF 00	Slow feeding mode, The interval time per portion can be set from 0~59min
F-00	Set the portion of each meal, up to 30 portions
1 2 3 4 5 6	Number of meals Setting mode: The dash flashing Feeding: The dash stays on Manual feeding: The dash stay on
	Set to Q-Voice format
	Low Battery indicator / Feeding No batteries Red Light: Low battery
	Light up when all buttons are locked

Made in China
Version: 1.0

If the power supplies by the adaptor only, the display will always be lit. If it's supported by 3*D batteries only without operation for 2 mins, the screen will turn off automatically. Press any button can awake it.

Button Quick Guide

Button	Description	Operating Mode Function
	Setting	Long press 2s to set current time, short press to set feeding parameters.Long press set setting mode
	Record	Long press 2s to record voice, short press to play back voice
	Setting mode: short press to next step	
	Recording	**Standby:** Short press: Stop recording Long press:Resume voice or cancel recording
	Down	**Standby:** Short press: Decrease value Long press: Decrease the value quickly
	Manual Feeding Up	**Standby:** Short press: Manual feeding **Setting mode:** Short press: Increase value Long press: Increase the value quickly
	Lock/Unlock	In unlocked state, press and hold for 5s at the same time to enter the factory settings
		Press and hold for 2s at the same time to lock/unlock

The screen will be locked automatically without operation for 90 sec.

Quick Programming Guide

1. Ensure the panel is unlocked – press and hold ⏻ & ⏷ until you hear two beeps.

2. Voice recording and playback

Start recording
In standby state, press and hold ⏺ until you hear a "beep" and continue to hold while recording up to 10 seconds. Release the button when you hear a beep to finish recording.

Play the recording
In standby state, press ⏺ to hear the recorded message.

Cancel recording
In standby, long press ⏺ until you hear a "beep" sound and release immediately to cancel the recording.

3. Manual Feeding

Short Press ⏺ & ⏷ the feeder starts manual feeding (one portion). Repeat this step for 5 times to make sure the feeder starts working.
NOTE: - If you unlock the food, the food of the first portion is less than the a.ual amount, and the 30 portion is accurate.

4. Set Current time

Long press ⏷ until the digits start flashing, Press ⏷ & ⏶ to set the correct hour and then short press ⏷ to confirm, Repeat to set the minute. Long press ⏷ to exit setting.

Example: set current time to 08:10 AM

5. Slow Feed Setting

Short press ⏷ to enter feeding parameters setting, Press ⏷ & ⏶ to set the interval time per portion, can be set from 0min to 59min.

6. Meal Time Setting

Short press ⏷ to enter first meal setting, When "1" starts flashing, Press ⏷ & ⏶ to adjust to the hour. Short press ⏷ to confirm and wait to change the meal time. ⏷ until "1" flashing, you can press ⏷ to set the meal portion.



Short press ⏷ to the next slot, Short press ⏷ & ⏶ to set feeding time.

Setting Feeding time (hour) Setting Feeding time (minute)

7. Feeding Portion Setting

Once feeding time is set and saved, the feeder will switch to portion mode, The screen will display "F-00" (0/3 for the number of 30g meals).
(For a 30g portion, choose F-3, Press ⏷ & ⏶ to set the portions and then press ⏷ again to confirm the portion selection.

For feeding interval 0min For a 30g portion choose F-05

8. Repeat for meals 2 through 6 Long press ⏷ to save once you set all meals.

Intelligent Detection Function

As shown, "E-01" appears on the screen to indicate that the food tank is detached. Please clean the food outlet in time.Otherwise, the feeder will no longer dispenser feed. You can adjust the speed and feeding portions according to your pet's habits.

As shown, E-02 appears on the screen to indicate the jamming of the feeder.Please check whether there are foreign objects in the hopper or the food is too large.

About Cleaning

(1) Open the lid and take out the dessicant.
(2) Remove the feeding bowl and empty the grain in the hopper.
(3) Rotate the hopper to separate the hopper from the base.

The base unit cannot be submerged in water.

Food bowl, stainless steel bowl, hopper and lid can be washed in the sink.

Warranty

We provide 1 year warranty for this appliance. Please email our support team at support@petory.net if you have any questions, and which your order ID in your email, We will get back to you within 24 hours.

@PetoryStore
support@petory.net
Petory Official

FC CE UK RoHS

Made in China

Get Operation Guide