oneisall

Automatic Pet Feeder with Dial

User Manual
ON-003EU

Video Tutorial | oneisall Support | oneisall Official Community

Thank you for choosing us! To use the feeder correctly, please take a moment to read this manual. If you encounter any issues during the installation or operation, or if there are quality issues, or you have any questions about this feeder's usage, please feel free to contact us via support@oneisall.com

For more information, you can visit our website www.oneisall.com

We otherwise buyer's voice on our website regularly. You are welcome to record and share your own experience of our products.

Use Precautions

1. Recommend for pets over 6 months old.
2. Indoor use. Avoid direct sunlight. Keep away from fire.
3. Use the attached adapter. Otherwise, the feeder may be damaged or fall to work.
4. DO NOT soak the main machine in water.
5. To prevent pets from pushing over the feeder, we recommend to use against a wall.
6. Children should use it under guidance.
7. Stop to use the descount bag if you find it is broken.
8. Remove the food bag before installing. Remove the batteries at the bottom if you would like to stop using the feeder.

Contents

English 01-11
Deutsch 12-23
Français 24-35
Italiano 36-47
Español 48-59

Contents

In the Package 01
Product Overview 01
LED Display Introduction 02
Assemble the Feeder 02
Program Settings 03
Statement for LED Display 06
The Desired Amount of Kibbles 07
Tips for Cleaning 09
Specification 09
Troubleshooting 10
Warranty 11

In the Package UK/US

Product Overview

LED Display Introduction UK/US

Assemble the Feeder

Please scan the QR code below to obtain detailed assembly video for the cat feeder.

Video Tutorial

Program Settings UK/US

You may need to know before setting: If the feeder is locked, press and hold the button for 3 seconds to unlock it.

Rotate to select menu and adjust numbers.

Current Time Setting

Tips:
You need to confirm the numbers of hours and minutes separately.
If you set the feeding plan without setting the current time, it will lead to inaccurate feeding, because the time may pass.

Fixed Point Meteringg

Tips:
1. The PORTION number shown on the display means the amount for each bowl.
2. It Does Not support to deliver different portions to each bowl.

Manual Feeding Setting

Record A Message:

Reset the Feeder

Tips:
You will hear 2 sounds of Beep when the feeder restore to factory

Statement for LED Display

5. The battery icon only occurs when using the battery as the only power supply. The icon would flash when the battery gets low.

6. The meal serial number would be off when the plan execution is completed. It would lights up again at 12:00 AM.

The Desired Amount of Kibbles

The size of the kibble we used in our lab: 0.3 inch. Here's the data from our experiment:

Cup	Portion	Gram
1/4	1	7
1/4	3	29
1/3	4	38
1/2	6	57
1/2	12	114

This data is for reference only. You need to test out the right amount for your pet, based on the dry food you used.

Tips:
1. The PORTION number shown on the display means the amount for each bowl.
2. It Does Not support to deliver different portions to each bowl.

Here are the steps:
1. In the following steps, let's assume that your two pets eat the same amount.
2. For example, ½ cup equals to 6 portions, so ¼ cup would equals to 3 portions.

3. Set the portion number to 3.

4. Measure the delivered kibbles. If the kibbles are measured as the amount you need, it means this setting is OK.

5. Otherwise, adjust the portion number to let it get close to the amount desired.

Tips for Cleaning UK/US

Please scan the QR code below for a detailed cleaning video of the cat feeder.

Specification

Model:	PFD-002
Product Size:	7.4 x 7.2 x 9.5 in
Capacity:	20 Cups (4.7 lb dry food)
Portion Size:	6 Portions=1/2 Cup=90 G
Material:	ABS+304 stainless steel
Input:	5V DC1A
Food:	Dry food, less than 0.3 inch in diameter
Power Supply:	Cord suggested/batteries for backup

Troubleshooting UK/US

Please attach your troubleshooting and order ID, contact us via email support@oneisall.com. We would help you solve the problem fast.

Problems	Solutions
The feeder can not work	Check if the cord connected well. Do not use batteries, use another type/C charging cord to see if the feeder works.
Descount Replacement	Please note that the Oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty covers manufacturing defects and does not encompass issues like wear and tear, and similar items. These parts may require regular replacement or maintenance.
Food stuck or show 0.47 error code	Check if the food bags try and fresh. If the food stop in the outlet, clean it. If you are without cord, replace the batteries.
LED Display is off	When using the battery as the only power source, the display would be off to save electricity. But the feeder would work normally.

Contact Us UK/US

WE ARE READY TO HELP

Oneisall offers a standard 2-year warranty. If you have any issues with your Oneisall product, please do not hesitate to contact us. Be sure to include your proof of purchase and order ID in your email, so we can swiftly process your inquiry and expedite the process. Our Oneisall support team is available 7 days a week and will respond to your inquiry within 24 hours. Thank you for choosing Oneisall.

Please note that the Oneisall warranty does not apply to used products or purchases made from unauthorized sellers. It's important to be aware that the warranty covers manufacturing defects and does not encompass issues like wear and tear, and similar items. These parts may require regular replacement or maintenance.

support@oneisall.com
+1 877-522-6079 (US) Mon-Fri: 8am-5pm(PST)
www.oneisall.com

Scan code

@Oneisall Official

Im Paket DE

In der Verpackung 13
Produktübersicht 13
Einführung LED-Anzeige 14
Zusammenbau des Futterautomats 14
Programmeinstellungen 15
Erklärung zur LED-Anzeige 18
Die gewünschte Menge an Trockenfutter 19
Tipps zur Reinigung 21
Spezifikation 21
Problembehebung 22
Garantie 23

In der Verpackung DE

Produktübersicht

Einführung LED-Anzeige DE

Aktuelle Uhrzeit
Manuelle Fütterung
Manuelle Fütterung Einstellung
Aufzeichnungseinstellung
Zurücksetzen des Futterautomaten
Die Niedrigen Ladestand
Die Ladestand ist ausreichend.