Product Manual




Massage Gun

SIDE VIEW



BACK VIEW



7

			
Ball head	U Shape head	Small round head	Flat head
			
A Shape head	D Shape head		

1.Brush-less Motor 2.Battery(voltage16.8V) 3.ON/OFF 4.Gear Display

5.Battery status 6.DC IN 7. six massage head

● *DIRECTION FOR USE*

1.Insert the massage head into the machine, Push it whole in.

2.Press the button 3 seconds to start the device and enter into the 1st level. You can use '+' and '-' button to control the level from 1 to 5. Press the button for pause and hold the button for 3 seconds for ON/OFF.

Battery Instructions

- Charging time: 2.5-3 Hours
- Battery life: around 6 hours (Depends on use)
- Keep the machine OFF during the charge.
- Long time charge can really hurt the battery. Please do not charge it for over 6 hours.
- Not using the massage gun when the battery is over heat, bulged or any other issue appeared.

Safety Instructions

To reduce the risk of electric shock, fire and personal injury, this product must be used in accordance with the following instructions:

1.Age 16+ only. Underage child should use it with the guide of adults.

2.Please gently press and move when use the massage gun. If you feel the massage gun is to strong with your skin, we suggest you use it with a clean and dry cloth or towel. Do not use it on one point for over 60 seconds.

3.High speed is only for soft tissue parts of your body. Please do not use high speed on your head or any other bone parts.

4.Use different massage head for different part of your body can get a better massage experience.

5.Frequent of high speed on same point of your body can result in bruising. Stop using it when you feel pain and discomfort.

6.Take care of your fingers, hairs and other body hair when you using the massage gun.

7. Keep the massage gun away from water.

8. Charge with original charger only.

9. Check the device and battery before use.

10.Do not make any modifications to the equipment.

● *Maintenance*

1.Rub the surface of the device with a slightly damp towel and then dry with a soft cloth.

2.Please keep the machine in the protect box during the long trip.

⚠ *WARNINGS*

1.Do not immerse in water. keep away from liquids or heat sources. keep ventilation free from dust and debris.

2.Do not remove screws or attempt to disassemble.

3.Maximum working time for the massage gun is 1 hour. If the battery is overheat, please wait until the battery is cooling down or at least 30 minutes before re-using.

4.Unplug the charger from device battery after charging or prior to use.

5.Do not use if injured, consult your doctor before using this product.

● *DISCLAIMER*

Please read the instructions carefully before using the product and use it correctly according to the instructions. If you do not use the product correctly, the company will not bear any legal obligations for any damage or loss caused to the customer.

If you have the following circumstances, without the doctor's permission, do not use high speed and high pressure or banning the use of equipment: pregnancy, diabetes and complications, such as neuropathy or retinal damage, wear pacemakers, recent surgery, or migraines, disc herniation, or back vertebra inflammation, recently worked in joint replacement or health intrauterine device, the weak adults or children need to be careful when using this equipment, advice to use the device in the doctor's permission.

We are studying the medical effects of this device, which may cause the above contraindications to be insufficiently detailed , and must be completed with the advice and guidance of a doctor or physiotherapist

● *WARRANTY*

IF WITHIN ONE YEAR FROM THE DATE OF PURCHASE, THIS PRODUCT FAILS DUE TO A DEFECT IN MATERIAL OR WORKMANSHIP WILL WILL REPAIR OR REPLACE THE PRODUCT, OR NECESSARY COMPONENTS, FREE OF CHARGE.THIS WARRANTY EXCLUDES:

1.Damage caused by accident, abuse, or transport.

2.Unauthorized repaired units.

3.Not accordance with instructions used units.

4.Damage exceeding the cost of the product.

5.Deterioration of the delivered product resulting from abnormal storage and/or safeguarding conditions on the client's premises, and

6.Failure to provide the dated proof of purchase.Some states and countries do not allow a limitation of damages, so the foregoing limitation may not apply to you. This warranty guarantees specific legal rights, and but other rights may vary from country to country and from state to state. This warranty service is available through the operating polices and international distributors.

● *CONFIGURATION MANUAL*

Product detail	Battery Capacity	massage head
Machine with brush-less motor, massage head,gear level, Hand bag, adaptor,	2500mAh	



Specification:

Model:	BD-V6
Weight:	1.67 lbs. (For Gun) 3.33 lbs. (For whole package)
Box Size:	11x3.9x9 in
Battery Capacity:	2500mAh/16.8V
Battery Life:	6 hour
Charge Time:	1 hour
Whisper Quiet:	Less than 40 dB
Package Includes:	User Manual, Massage Gun*1, Replace Head*6, Power Cord, Lint Bag