

# Pro X2 wireless memory card user guide

## Welcome

Eye-Fi's Pro X2 wireless memory card adds the power of WiFi to the camera you already own. Use this guide to learn how the Pro X2 card can streamline your photography workflow by putting photos where you want them, quickly.

## Setup instructions

Before your Pro X2 card can transfer photos over WiFi, you need to set up the card using a Windows or Mac computer.

**Note:** ProX2 cards do not come with a 10-digit activation code. Only Mobi cards have the activation code.

1. Download and install our free Eye-Fi Center software onto your supported Windows or Mac computer from <http://support.eye.fi/downloads/>, then launch Eye-Fi Center software.
2. Insert the Pro X2 card into the USB card reader included in the box, then insert the USB card reader into your computer.
3. After a few moments, Eye-Fi Center will open a dialog instructing you to activate your card. Start by creating your Eye-Fi account, then follow the on-screen instructions for setting up your Eye-Fi card to deliver photos to your computer.

For additional help with activation and set up go to <http://support.eye.fi/x2/> and click on Get started.

**Pro Tip:** Be sure to leave the Pro X2 card plugged into the USB card reader for the entire activation process until you are instructed to remove it.

## Preview photos on your smartphone or tablet as you take them.



Your Eye-Fi Pro X2 card can help ensure that you've gotten the right shot by allowing you to quickly review your photos on your iOS device (iPhone®, iPad®, iPad mini®, iPod touch®), Android™ smartphone or tablet, or Kindle Fire..

This setup takes advantage of Eye-Fi's brilliance and relies on the Pro X2 card to create its own WiFi network that the Eye-Fi app on your iOS, Android, or Kindle Fire device connects to.

**Pro Tip:** Configuring your Pro X2 card for this type of setup requires a computer running Eye-Fi Center software and a supported smartphone or tablet running the iOS or Android Eye-Fi app. Be sure to configure this setup before you leave your house or office. Visit <http://support.eye.fi/downloads/> to download all the necessary software to your supported devices.

## Part 1: Eye-Fi Center Settings

1. Insert the Pro X2 card into the USB card reader provided by Eye-Fi and then insert the USB card reader into the computer running Eye-Fi Center software.
2. Launch Eye-Fi Center if it's not already running and select your card from the Devices list, then click Settings.
3. From the Networks option, select the 'Direct Mode' tab.
4. Check the box for "When no known Wi-Fi networks are in range, start the Direct Mode network", then click Save.

## Part 2: Smartphone / Tablet Settings

### iOS:

1. Launch the Eye-Fi app. Sign out of the app and then sign in again with your Eye-Fi account.
2. On the Eye-Fi Card Setup screen, tap the Yes button to receive photos from your Eye-Fi card.
3. Tap the Add Network button, then the Install button.
4. Tap the Install Now button to add your Pro X2 card's network profile to your device.
5. Tap the Done button, then tap the Next button on the Direct Mode screen.
6. Lastly, tap the Done button on the FAQ screen.
7. Return to Settings and select Application Preferences.
8. Slide the option for Full Screen ON.
9. Return to the main screen of the app.

### Android:

1. Launch the Eye-Fi app and sign in to your Eye-Fi account.
2. Tap the Menu button on the phone, then tap the Settings icon.
3. Select Eye-Fi device settings then select your Eye-Fi card from the list of available devices to pair.
4. Tap the check box next to your Eye-Fi card.
5. Select the media types you would like to transfer. If you are changing the pairing from another device, press switch, then tap the OK button when you are finished.
6. Go back to Settings and select Application Preferences.
7. Tap the check box for Full Screen.
8. Return to the main screen of the app.

For step-by-step instructions with screen shots, visit:

<http://support.eye.fi/features/direct/ios-eye-fi-app/>

For step-by-step instructions with screen shots, visit:

<http://support.eye.fi/features/direct/eye-fi-android-app/>

## Part 3: Watch your shots appear on your smartphone or tablet

Insert your Pro X2 card into your camera & begin taking photos and be sure to leave your camera powered on until all photos have transferred.

### iOS:

1. On your iOS device, go to general device Settings .
2. Select Wi-Fi.
3. Tap the name of the Eye-Fi Card network (it should appear within 30 seconds).
4. Go to the Eye-Fi app. Photos should begin appearing in the app as they finish transferring.

### Android:

1. Go to the Eye-Fi app.
2. Tap Connect if prompted on your device to connect to the Eye-Fi Card's WiFi network (this should happen automatically).
3. Photos should begin appearing in the app as they finish transferring.

**Pro Tip:** If you shoot RAW format, we recommend that you shoot RAW + JPEG and configure your Pro X2 card to send only the JPEG's to your smartphone or tablet for previewing. You can transfer your RAW files after the fact to your computer for editing. Read more about it here: <http://support.eye.fi/software/media/destination-for-raw-files/>

## Helpful links

Troubleshooting & Customer support ..... [support.eye.fi](http://support.eye.fi)  
Warranty ..... [www.eye.fi/wug](http://www.eye.fi/wug)  
End User License Agreement / Terms of Service ..... [support.eye.fi/eula-and-tos](http://support.eye.fi/eula-and-tos)