

Product Data Sheet

Qualification: PingaOculto Bluetooth Earpiece VIP Pro Exams Hidden Invisible for Mobile with Microphone without Cables and Adhesive Strips - Wireless Spy Earpiece (Pinganillo VIP Pro UltraMini Bluetooth Piece)

ASIN: B0CG9SCHHP

Creation date: 09/12/2024

Product Overview

The Vip Pro Bluetooth Induction Collar + Earpiece is one of the most discreet models on the market, with a secret operation thanks to its small size and multiple concealment possibilities. It works with both recordings and phone calls by connecting the induction collar via Bluetooth to a mobile phone/MP3 player. We must always keep the Bluetooth induction collar near the earpiece, placing it hidden under clothing and attached to the body with adhesive tape or tape. For phone calls, it includes an integrated microphone that allows you to communicate by whispering.

Brand

PingaHidden

Manufacturing Materials

- Key components: miniaturized electronic materials
- Design: High quality durable plastics
- Color: Black, designed for maximum invisibility

Technical Specifications

- Dimensions: 1.2 x 0.68 cm
- Device Type: Bluetooth Earpiece
- Technology: Electromagnetic induction
- Connection: Bluetooth 4.0
- Compatibility: Mobile phones and MP3 players
- Microphone: built-in

Battery Specifications

- Battery Type: 337 / SR416SW
- Autonomy: Approximately 4 hours
- Power supply method: Battery (non-rechargeable)
- Part: Charges via included USB cable, with 3 hours of autonomy

Instructions for Use

1. Insert the battery into the earpiece.
2. Insert the earpiece into your ear.
3. Connect the inductor piece to the mobile device or mp3 via Bluetooth.

4. Place the piece on the neck.
5. Adjust the volume to the desired level.
6. Use the built-in microphone to make calls.

Maintenance and Care

- Store in a dry and clean place
- Avoid exposure to extreme temperatures
- Protect from moisture
- Clean only with dry cloth
- Do not immerse in water
- Charge only with the supplied head

Security Measures

Choking Hazards

- Keep out of reach of children and pets
- Risk of ingestion due to small size

Electromagnetic Interference

- Avoid use near sensitive medical equipment
- Do not use near pacemakers
- Keep distance from sensitive electronic devices

Hearing Hazards

- Keep volume at moderate levels
- Avoid volumes that block ambient sounds
- Use with caution to prevent hearing damage

Risks of Misuse

- Use only in legally permitted environments and situations
- Comply with local regulations
- Avoid use for illegal or unauthorized activities

End-of-Life Disposal

- Do not dispose of as general waste
- Take to a recycling center specializing in electronic devices
- Contact manufacturer for recycling options
- Comply with local environmental regulations for the disposal of electronic waste

Legal Notice: The use of this device must strictly comply with local regulations and respect the privacy rights of third parties.

Manufacturer data

Shenzhen Texon Technology Limited

Address: 3rd Bl, Ze Hao Industry Garden, TongFuYu industry Estate, Guang Ming area, Baoan District, ShenZhen City, China, 518107

Tel.: +86-755-2675 0507 Email:

sales@texoncamera.com

Product manager details

PINGOC NOW SL

CIF: B72491368

Address: Calle Lucio del Valle 12, Local 1 Madrid, Madrid, 28003, Spain Tel.:

+34 91 417 04 02

Email: contact@pingaoculto.com