

Attention

Dear Amazon Customer, thanks for buying Oasser Electric Air Compressor with built-in battery. Prior to use, please read the Do's and Don'ts as follows so as to prevent any mistakes in use and storage due to improper operation. We appreciate it if you could read this attention for a few minutes.

- 1 Please charge the product battery to the fullest prior to the very first use to “wake up” the battery and make sure the battery is at its best performance.
- 2 Don't make the air compressor work when it is being charged with home charger (except that it is connected to 12DC power).
- 3 Please prevent the product from being over-charged. When the indicating light on the charger turns red to green, it means that the battery is fully charged. Please cut off the power in time.
- 4 Please charge the product battery to the fullest after every use so as to prevent the battery from being over-discharged when it is placed for quite some time without any use. (The charger is equipped with low-voltage protection, so when the battery voltage is too low, the battery may not be charged with the charger).
- 5 Please see to it that the product should be charged every one month when it is placed for a long time without any use.

- 6 Under low-pressure circumstance (≤ 50 PSI), it's NOT advised for the product to work for more than 10 minutes consecutively. Under high-pressure circumstance (≥ 50 PSI), however, don't make the air compressor work for above 5 minutes continuously. Please let the unit "rest" for 5-10 minutes before it starts to work again.
- 7 If you have any issue regarding the use of the product, please do not hesitate to contact us via e-mail. Oasser after-sales team will be responsive within 24 hours with a satisfactory solution. Thank you so much for your support to Oasser.

Contact us

US: support-us@oasser.net
CA: support-ca@oasser.net
UK: support-uk@oasser.net
DE: support-de@oasser.net

IT: support-it@oasser.net
ES: support-es@oasser.net
FR: support-fr@oasser.net
JP: support-jp@oasser.net