

What should I do if my Tapo smart devices (smart plug, smart lighting) keeps losing connection or going Offline?

There are some circumstances that Tapo smart devices do not work stably or lost connection from time to time, this could be due to the network environment or some other reasons, this article provides some helpful tips to fix the situation.

Step 1 Ensure Router is working properly. Reboot the router and tapo device and see if the smart device reconnects.

Step2 Ensure Tapo smart device is receiving a Good Wi-Fi signal by checking RSSI (Received Signal Strength Indicator)


Tapo APP->tap  in the left top > **Device Settings**->**Device info** ->tap **Wi-Fi** icon to see signal strength (the value of RSSI)

Strong: more than **-50 dBm**

Good to Average: among **-70 dBm** to **-50 dBm**

Poor: less than **-70 dBm**

Note: If RSSI is less than -70dBm, the signal is too weak, device disconnections are likely, relocate the smart device or router to get a stronger Wi-Fi signal.



Step 3. Update the firmware of the Tapo device

Step 4. Ensure Tapo APP is up to date in the APP store or Google Play

Step 5. Turn off Advanced Wi-Fi settings on the router like **Band Steering** (also called 'Smart Connect' or 'Whole-Home Wi-Fi '), Wi-Fi Optimizing or 'Channel optimization' etc.

Step 6. Try changing Router's DNS Settings

Primary DNS 8.8.8.8

Secondary DNS: 8.8.4.4

Step7. [Optional] Try to configure the smart device to another router's 2.4G Wi-Fi or a mobile Hotspot Wi-Fi to verify whether this issue is related to the specific router.

If the issue is still the same, contact [TP-Link technical support](#) and provide the information below for our support to look into further:

1. Led status on a smart device when it is offline: Red/ Flashing Green/ Solid Green etc.(For tapo plug)
2. MAC address of the device
3. TP-Link ID email address

4. When an issue occurs, does smart device work in **the local network**?

For a test, connect your mobile device to the home Wi-Fi network at that time and see if Tapo device is still accessible in the local network?

3. The model number Wi-Fi router and your network topology:

e.g. ISP Spectrum-Archer C7 router<Wireless> tapo device

5. How often does the issue happen, and how does recover the connection, like rebooting the smart plug or rebooting the router?