

Important

Read this user manual carefully before you use the appliance and save it for future reference.

Some parts of the iron have been slightly greased and as a result the iron might slightly smoke when connected for the first time. After a short while, however, this will cease.

1. Danger:

Never immerse the iron in water.

2. Warning:

- Check if the voltage indicated on the type plate corresponds to the local mains voltage before you connect the appliance.
- Do not use the appliance if the plug, the cord or the appliance itself shows visible damage, or if the appliance has been dropped.
- If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- Never leave the appliance unattended when it is connected to the mains.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

- Do not let the mains cord come into contact with the hot soleplate of the iron.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
- The iron is not to be used if it has been dropped, if there are visible signs of damage.

3. Caution:

- Only connect the appliance to an earthed wall socket.
- Check the mains cord regularly for possible damage.
- Always place and use the iron on a stable level and horizontal surface.
- The soleplate of the iron can become extremely hot and may cause burns if touched.
- When you have finished ironing, when you clean the appliance and also when you leave the iron even for a short while put the iron on its heel and remove the mains plug from the wall socket.
- The appliance is intended for household use only.

Quick start guide

- Remove any sticker or packaging material.
- Plug the mains cord in to the power socket.
- Set the temperature using the temperature dial according to the fabric to be ironed.
- When the temperature light has gone out, the iron is ready for use (fig.1).



Setting the temperature

1. Put the iron on its heel.
2. Set the temperature dial to the required ironing temperature by turning it to the position of the temperature indicator (fig.2).
 - Check the garment label for the required ironing temperature.
 - • Synthetic fabrics (e.g. acrylic, viscose, poly amide, polyester)
 - • Silk
 - • Wool
 - • Cotton, linen
 - When you do not know what kind of fabric(s) the article is made of, try to iron on a spot which will be invisible when you wear it.
 - Silk, woolen and synthetic materials: iron the reverse side of the fabric to prevent shiny spots.
 - Start ironing the articles that require the lowest ironing temperature, such as those made of synthetic fibers.
3. Put the mains plug in an earthed wall socket.

Tips

1. Before using the first time remove any sticker or protective foil from the soleplate. Clean the soleplate with a soft cloth.
2. Keep the sole plate smooth: do not scratch metal object (e.g. rack of ironing board, buttons, zippers).
3. The ironing results are best if the fabric is slightly damp.
4. Velvet and other textures which rapidly acquire shiny spots should be ironed in one direction only (with the nap) applying only light pressure.
5. Always keep the iron moving.
6. Iron with a straight back. Adjust the height of the ironing board so that the handle of the iron is on the same level as your elbow.
7. Pressing onto the iron is not necessary, provided that the temperature has been set correctly. Ironing is most effective if the laundry is slightly damp.

Cleaning and maintenance

1. Remove the mains plug from the wall socket and let the iron cool down.
2. Wipe the soleplate with a damp cloth and a non-abrasive (liquid) cleaner. Keep the soleplate smooth: avoid hard contact with metal objects.
3. Clean the upper part of the appliance with a damp cloth.
4. Always store the iron standing on its heel in a safe and dry place.

Trouble shooting

Problem	Possible cause(s)	Solution
The iron is plugged in but the soleplate is cold.	Connection problem.	Check the mains cord, the plug and the wall socket.
	The temperature control dial is probably set at minimum position.	See setting the temperature section for appropriate temperature setting.