


INCLUDES: Computer, Magnet Cluster, Battery & M6 Screw

NOTE: This computer is equipped with an auto on/auto off function. The computer will come on automatically if the exercise machine is in motion. If not exercising for over 4 minutes, the computer will turn itself off.


INSTALLATION: TOOLS REQUIRED - Phillips Screwdriver

Step 1: Push in release tabs on both sides to separate top and bottom of computer:




Step 2: Install two AAA batteries in the top of the computer housing. Match + on battery with the + on battery housing.


Step 3: Push the Magnet Cluster over the left section of tubing, then work the boss into its mating hole in the tubing. (Make sure magnets face in as shown).



Step 4: Place the bottom case of the computer underneath the bar. Insert the M6 Screw into the center hole on the bottom housing and the hole on the bottom side of the axle tube. Tighten the screw.



Step 5: Align the top half of the case with the bottom half and snap them together.



Note: If your display screen cannot be easily read when using the unit, you can adjust it by loosening the bolts at both ends of the axle tubes. Reposition the computer and retighten the bolts.




INCLUDES: Computer, Magnet Cluster, Battery & M6 Screw

NOTE: This computer is equipped with an auto on/auto off function. The computer will come on automatically if the exercise machine is in motion. If not exercising for over 4 minutes, the computer will turn itself off.


INSTALLATION: TOOLS REQUIRED - Phillips Screwdriver

Step 1: Push in release tabs on both sides to separate top and bottom of computer:




Step 2: Install two AAA batteries in the top of the computer housing. Match + on battery with the + on battery housing.


Step 3: Push the Magnet Cluster over the left section of tubing, then work the boss into its mating hole in the tubing. (Make sure magnets face in as shown).



Step 4: Place the bottom case of the computer underneath the bar. Insert the M6 Screw into the center hole on the bottom housing and the hole on the bottom side of the axle tube. Tighten the screw.



Step 5: Align the top half of the case with the bottom half and snap them together.



Note: If your display screen cannot be easily read when using the unit, you can adjust it by loosening the bolts at both ends of the axle tubes. Reposition the computer and retighten the bolts.



FUNCTIONS AND OPERATIONS:

Mode or Function	Action
SCAN	Press the button until "A" appears on the display screen. Scan allows the monitor to automatically cycle between Speed, Distance, Time & Calorie every 4 seconds.
SPEED	Press the button until "S" appears to display the current speed.
TRIP DISTANCE	Press the button until "D" appears to display the trip distance you are traveling during this workout.
TIME	Press the button until "T" appears. This indicates elapsed time of any exercise.
CALORIE	Press the button until "CA" appears. This is the approximate calorie consumption accumulated.
RESET	Press the button for more than 3 seconds. This will reset all functions to zero.

HOW TO REMOVE BATTERIES:

1. Remove upper case by pressing in the release tabs on both sides, then lift off.
2. Replace the batteries with two AAA batteries.
3. Ensure that the batteries are correctly fitted.
4. If the display is illegible or partial segment appeared, please remove the batteries. Wait for 15 seconds, and then reinstall them.
5. Removal of batteries will reset all functional values to zero.

FUNCTIONS AND OPERATIONS:

Mode or Function	Action
SCAN	Press the button until "A" appears on the display screen. Scan allows the monitor to automatically cycle between Speed, Distance, Time & Calorie every 4 seconds.
SPEED	Press the button until "S" appears to display the current speed.
TRIP DISTANCE	Press the button until "D" appears to display the trip distance you are traveling during this workout.
TIME	Press the button until "T" appears. This indicates elapsed time of any exercise.
CALORIE	Press the button until "CA" appears. This is the approximate calorie consumption accumulated.
RESET	Press the button for more than 3 seconds. This will reset all functions to zero.

HOW TO REMOVE BATTERIES:

1. Remove upper case by pressing in the release tabs on both sides, then lift off.
2. Replace the batteries with two AAA batteries.
3. Ensure that the batteries are correctly fitted.
4. If the display is illegible or partial segment appeared, please remove the batteries. Wait for 15 seconds, and then reinstall them.
5. Removal of batteries will reset all functional values to zero.