


W1 User Guider



Getting Started

Plugging the adaptor into a standard household outlet.

Time Setting

1. Short press "TIME" button to enter time setting, press "+" or "-" button to change the hour setting;
2. Press "TIME" button to confirm and enter minute setting, press "+" or "-" button to adjust the minute;
3. Press "TIME" button to confirm and exit the time setting.

Note: 12-hour time display with "AM/PM" led indicator.

Alarm Setting

1. Short press "ALARM" button to enter alarm time setting, press "+" or "-" button to change the hour setting;
2. Press "ALARM" button to confirm and enter minute setting, press "+" or "-" button to adjust the minute;
3. Press "ALARM" button to confirm and exit the alarm setting.

Using The Alarm/Snooze

1. Press "-" button to turn on/off the alarm. The ALARM indicator will be lit when it is on.
2. The alarm will sound for 1 minute; slightly touch the "SNOOZE" area to activate snooze function and the alarm will sound again in 10 minutes.

Note: When the clock rings, press any button to stop the alarm, it will ring again on next day same time.

Using The USB Port

One for clock power supply, another for charging phone or other tablets.

Using The Dimmer

Rolling the "DIMMER" wheel to adjust 0-100 brightness of the display.

Outlet Powered with Battery Backup

Insert 2 new "AAA" batteries (not included) to keep the ALARM and TIME settings if the power is interrupted. No need reset if power failed with battery backup. There will be no display under battery power and the ALARM will not sound at the correct time.

Support

If you experience any problems with this clock then contact service@welgonow.com where we will deal with your issue within 24 hours.