

MERACH S26 Indoor Exercise Bike Troubleshooting Guide

This guide provides useful tips and solutions for troubleshooting our brand of fitness equipment, as well as scenarios of possible accessory and Bluetooth (App) problems.

What to do when the handle shakes slightly?

1. Check whether the connecting screws of the handle and the front column tube are firmly fixed.
2. Check if the retaining knob is locked.

What to do when pedals loose?

1. Make sure the "R" and "L" marks on the crank are aligned with the "R" and "L" marks on the pedal respectively before installing the pedals.
2. Following the setup instruction, to check whether the left and right pedals are locked on the first step.
3. Following the setup instruction, to check whether the inner fixing nut of the second stage of setting up the pedal is locked.

What to do when the whole machine is slightly tilted?

1. Check whether the four adjusting foot pads at the bottom of the front and rear foot tubes are on the same plane.
2. Adjust and rotate the raised foot pads parallel to the floor.

What to do when the monitor does not display?

1. Check whether the positive and negative electrodes of the battery are installed correctly.
2. Replace the battery with a new one.

How do I troubleshoot Bluetooth connection issues?

Please follow these steps:

1. Check if the machine is powered on.
2. Make sure the Bluetooth indicator light is on by waking up the machine.
3. Ensure that the Bluetooth function on your phone is turned on.
4. Make sure no one is using the machine during the Bluetooth connection.

What should I do if I find missing parts when installing the machine?

Our package is very compact, please check if all the parts inside the package have been taken out first. If you cannot find the corresponding parts, please feel free to contact us.

WARM TIPS

- Please follow the instructions in this manual to use this machine. Please stop using and operating immediately when you find any defective parts or hear any abnormal sound. Make sure all issues are resolved before using it again.

IMPORTANT!

Please read all details before use, and keep this guide for future reference.

PLEASE CONTACT US BEFORE THE RETURN:
Mon-Fri, 9:00 am-5:00 pm PST/PDT
support@merach.com