


# Avatar<sup>®</sup> Wi-Fi Smart Bulb User Manual



service@avatarcontrols.com

## English


### 1. Preparation content

- AvatarControls APP (Also compatible with the "smart life" app)
- AvatarControls APP account (users need to register their own account)
- Smart Bulb
- Reset switch on-off-on-off-on within 10 seconds  
Until the bulb fast flashing state. If not operate within 3 minutes, the bulb will restore to stable white light.
- 2.4 GHz WIFI environment (turn off 5GHz)

### 2. Add device

#### 2.1. Download AvatarControls APP

- Please download AvatarControls APP first:





- Please scan the QR Code, or get AvatarControls downloaded from App Store, Android Market

2

## English

### 2.2. Register an account in AvatarControls

- Open AvatarControls into account registration page, click on the "Register"



- At the registration page, select your region and enter the email to create a new account. (Phone number is not available)

- After successful registration, you can add device on your App now.

#### 2.3. Add devices ( Smart Bulb)

- After login to AvatarControls APP, click on "+".

3

## English

### 2.4. Add devices ( Smart Bulb)

- AvatarControls APP supports two types of distribution network modes: EZ mode and AP mode.



- EZ mode: The Smart Bulb is in a state of fast flashing .(About two times a second) .

- AP mode: The Smart Bulb is in a state of slow flashing .(About once

2 seconds)

If the bulb can not be paired in EZ mode(rapid blink), please switch to AP mode(blink slowly)

- After entering the "Add Device" page , confirm whether the Smart Bulb is EZ mode, if not, can switch to EZ mode by a continuous operation of "on-off-on-off-on" . Then click on "indicator light is flashing fast" to start adding Smart Bulb.



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be


4

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be



5

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be



6

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be


7

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be



8

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

9

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

10

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

11

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

12

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

13

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

14

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

15

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

16

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

17

### Troubleshooting

1. Cannot connect to Wi-Fi

- Check if you have selected a 2.4-GHz wifi which is the same that your phone is connected with. (If your router is dual band make sure your phone and the smart bulb are connected to the 2.4-G signal.)

- Check if you have entered the correct Wi-Fi password.

- Check if there are any internet problems. If necessary, reset your Wi-Fi router and try again.

2. Cannot control the devices with Alexa/Google voice control

- Check if you have enabled "AvatarControls" in Alexa or Google APP.

- Check if the bulb is online on the app (Do not turn off the bulb through your wall switch otherwise it will go offline.)

- Check if you are using proper commands when talking to Alexa/ Google Assistant, repeat your question, speak clearly to Alexa/Google Assistant in English.

- Check if you have modified the name of the

18

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

19

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

20

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

21

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

22

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

23

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

24

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

25

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

26

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).



- Select the Device Work Wi-Fi and enter the password, then start the configuration of the device. "Device added Successfully" will be

27

## English

### 2.4. Rename the device

- After the device be added successfully, click the device description text to modify device name.

The name of the device is recommended to use easy pronunciation of the English words. (Amazon Echo only supports English temporarily).

