

WARRANTY

Flybar warrants the original purchaser, that the product is free of defects in material and workmanship for a period of one year from the original date of purchase. This warranty does not apply to defects of physical damage resulting from abuse, neglect, improper repair, improper fit, alterations, or use unintended by the manufacturer. If your Flybar pogo stick is found to be defective in materials or workmanship within one year from the date of purchase, Flybar will, at its discretion, either repair or replace the pogo stick free of charge. Proof of purchase is required. Go to www.flybar.com for complete warranty information.

ABOUT US

In 1918 George Hansburg was inspired to invent the pogo stick. Soon after developing & patenting the original pogo stick, Hansburg brought his idea to personal friend, Florenz Ziegfield, of the world-famous Ziegfield Follies. Ziegfield, the eminent Broadway impresario of the day immediately choreographed a pogo routine into his Follies show. The Follies made pogo sticks the latest craze and demand went through the roof. To meet the demand, Hansburg opened a factory in NY.

We are still passionate about pogos after over 100 years, and are proud that Flybar pogos are “the standard by which all pogos are measured” and the “masters of bounce”

Flybar today is not just pogos. New products for toddlers, stilts, scooters, swings and skateboards are all designed and developed with the passion and innovation George Hansburg first demonstrated over 100 years ago.

Flybar, Since 1918



Flybar, Inc, Freehold, NJ 07728
All Rights Reserved. 2019

www.flybar.com



MASTER

New Master Pogo Stick

OWNER'S MANUAL

FBPS-MAS6030
FBPS-MAS6040
FBPS-MAS6010
FBPS-MAS6020

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING YOUR NEW POGO STICK. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE. ALWAYS ADHERE TO THE BELOW AGE AND WEIGHT RESTRICTIONS:

New Master Pogo Stick FOR AGES 9+, 80-160 LBS.

SAFETY

Use your head—play hard, but play safe. Using it safely is mostly common sense.

1. Wear a helmet. Play it safe! Worn properly, helmets prevent hundreds of serious head injuries every year.

2. Check for hazards before you start. Never jump without first making sure that the surface is safe—solid, flat, clean, well lit, and dry. The best bet: concrete. Stick to outdoor areas that are free of hazards and give you plenty of room to maneuver.

3. Hazards to watch out for:

- **Traffic:** Steer clear of streets, parking lots, and other area vehicles use.
- **Humans:** Using your Velocity too close to other people is dangerous.
- **Slippery/Uneven Ground:** Don't try to jump on a surface which is wet, oily, or even lightly covered with sand, gravel, leaves, or litter—you'll greatly reduce the traction of your tip.
- **Steep Inclines:** Remember, you want to maintain a position perpendicular to the ground. If the surface slopes sharply, that's just not possible, and it's far more likely you'll skid sideways and fall.
- **Soft or Weak Surfaces:** Don't jump on plank flooring, lawns, or any other surface you wouldn't be confident driving a car across.

REMEMBER - USE YOUR HEAD, ALWAYS WEAR A HELMET AND OTHER PROTECTIVE GEAR!



IMPORTANT: PLEASE NOTE

1. This pogo stick is ready to use—no assembly is required.
2. The Inner spring is not adjustable.
3. The inner spring is deliberately "tight" in all new pogo sticks.
4. It takes several successive bounces to gain the momentum necessary to compress the spring.

USER Guidelines

- Check your pogo before first use and on a regular basis.
- NEVER use your pogo with bare feet. Always wear athletic shoes.
- Hold the pogo vertically, and develop balance by pulling the Pogo up with you.
- Do not use your pogo without the rubber tip properly in place.

Stay within your abilities

With experience and skill, you'll be able to react to pretty much any situation reflexively. But skill develops slowly, so take your time. As you put in the hours, you'll become instinctively aware of how much traction you have, how high you're going to bounce, how to correct for balance, and where you're going to land. Be prepared to bail out at any time. If and when you find you do have to bail, even from low elevations, be sure to land with your knees slightly bent to help absorb some impact.

RUBBER TIPS

Flybar recommends checking your rubber tip on a regular basis for wear & damage. Never use a pogo with a heavily worn or missing tip.

Warning: Only adults should perform tip replacements.

To remove a worn tip, use a flat screw driver to work all around the edges of the tip. This should loosen the tip and allow you to pry it off. Replace new tip by twisting into place. Flybar recommends adding heavy duty adhesive like Gorilla Glue. Allow 30-60 minutes to set.



Lubricating Your Pogo Stick

Your pogo stick has been lubricated at the factory but will require additional lubrication on a regular basis. Proper lubrication can be maintained with automotive oil.

To lubricate :

1. Turn pogo stick upside down
2. Squirt a little oil around the edges of the bottom steel shaft
3. Let oil seep in for about 5 minutes, then do a few bounces to spread lubricant.