




GO GRAINS!

RICE & GRAINS COOKER


QUICK START GUIDE

PARTS



HOW TO USE

MEASURE THE RICE WITH LEVEL SCOOPS. DON'T OVERFILL.




Use the provided measuring cup or your own measuring cup for dry ingredients (white rice, brown rice, steel cuts and quinoa). Use the measuring line on the removable bowl for water level. (Measurements are based on measuring cup provided. Ok to use your own.)

White
Rice

2
1

Brown
Rice

1.5
1



COOKING

1. Use the provided measuring cup to add the desired amount of the rice to the inner pot.
2. Rinse rice or grain to remove excess starch and drain.
3. Fill with water to the line matching the number of cups of rice being cooked.
4. Place the inner pot into the rice cooker.
5. Close the lid.
6. Plug the rice cooker into an available 120V AC outlet.
7. Press Menu to select White Rice or Brown Rice, depending upon the type of rice being cooked.
Use the same operation for Quinoa, and Steel Cut Oats, but no need to rinse.
8. Press START, the rice cooker will begin cooking. LED display will countdown the cooking time.
9. Once cooking is finished, the rice cooker will automatically switch to Keep Warm.
10. When finished serving rice, press Stop and unplug the power cord.

TIPS & HINTS

Function	Rice/Grain Amount	Water Amount	Default Time	Cooking Time
White Rice	1 Cup 2 Cup	Line 1 Line 2	35 Minutes	25-60 Minutes
Brown Rice	1 Cup 1 1/2 Cup	Line 1 Line 1 1/2	65 Minutes	50-90 Minutes
Quinoa	1/2 Cup	1 Cup	30 Minutes	20-40 Minutes
Steel Cut Oats	1 Cup	3 Cup	25 Minutes	20-40 Minutes

- Rinse rice prior to cooking to remove excess bran and starch. This will help reduce browning.
- For Quinoa and Steel Cut Oats, use caution to avoid escaping steam, open the lid and stir occasionally with a long-handled wooden spoon.

DELAY TIMER

Want perfect brown rice without the wait? Use the Delay Timer. Simply add rice and water in the morning and set the Delay Timer for when rice will be needed that night.

Option One

1. After plugging the unit in, press Delay Timer.
2. Press – or + to adjust to the desired time.
3. Press Menu to select the desired function.
4. Press Start.


Option Two

1. After plugging the unit in, press Menu to select the desired function.
2. Press Delay Timer.
3. Press – or + to adjust to the desired time.
4. Press Start.

CLEANING

1. Detach the inner cover and steam valve from lid by gently pulling it outward.
2. Inner pot, inner cover, and all accessories are top-rack dishwasher safe.
3. Wipe body, base, and top cover clean with a damp cloth.
4. Thoroughly dry body and accessories. Reassemble for next use.

- DO NOT use harsh abrasive cleaners, scouring pads, or products that are not considered safe to use on nonstick coatings.
- If using the dishwasher, a slight discoloration to the inner pot and accessories may occur. This is cosmetic only and will not affect performance.



IMPORTANT

Do not throw away. Read before operating your new Go Grains. Keep for future reference.

These helpful hints are intended to be a supplement to the Instruction Booklet. In order to ensure safe operation and optimum performance, please read the entire Instruction Booklet.

NOTICE

This appliance has a polarized plug. To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.