



panaride instruction




How to inflate bicycle, scooter, and car tires with an AV-valve




How to inflate a bicycle tire with an FV-valve




How to inflate football, basketball, volleyball, and other balls



How to inflate fitness balls, swimming accessories, and other items:




The angled adapter is used for situations where the main valve cannot be accessed easily or where the primary valve does not fit.




1. Screw the angled adapter onto the nipple;
2. Remove the cap from the adapter;
3. Put the valve onto the adapter with the lever raised;
4. Secure the valve by lowering the lever;
5. Inflate to the desired pressure;
6. Raise the lever and remove the valve from the adapter;
7. Unscrew the adapter from the nipple.

What the cap on the angled adapter is used for




For unscrewing the valve core from the nipple for rapid tire deflation.




For screwing the valve core back into the nipple after releasing air or if the tube valve is leaking.

How to assemble the pump



1. Put a plastic cap on the pipe.



2. Screw on the handle.

panaride

